Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anker A2667111

Anker 65W Max 3-Port USB C Charger Block User Manual

Model: A2667111

1. Introduction

Welcome to your Anker 65W Max 3-Port USB C Charger Block. This compact and powerful charger is designed to efficiently charge multiple devices simultaneously, leveraging advanced GaN II technology for high-speed performance. Please read this manual carefully to ensure proper use and optimal performance of your device.

What's in the Box:

- Anker 735 Charger (Nano II 65W) / PowerPort III 3-Port 65W Pod
- Welcome Guide

2. Safety Information

To prevent injury or damage to your device, please observe the following safety precautions:

- Read all instructions before using the product.
- Do not expose the charger to liquids, moisture, or extreme temperatures.
- Do not disassemble, modify, or attempt to repair the charger.
- Use only with compatible devices and cables.
- Keep out of reach of children.
- Avoid dropping or subjecting the charger to strong impacts.
- Unplug the charger during lightning storms or when unused for long periods.

3. Setup

Follow these steps to set up your Anker 65W Max 3-Port USB C Charger Block:

1. **Unfold the Plug:** Gently pull out the foldable AC prongs from the charger body until they lock into place.
2. **Connect to Power Outlet:** Plug the charger into a standard wall outlet (100-240V).
3. **Connect Devices:** Use appropriate USB-C or USB-A cables (not included) to connect your devices to the charger's available ports.



Image: The Anker 65W charger plugged into a wall outlet, providing high-speed charging to a MacBook Pro 13-inch. The charger is compact and features a foldable plug.

4. Operating Instructions

The Anker 735 Charger features two USB-C ports and one USB-A port, designed for intelligent power distribution.

Single-Port Charging:

- When using a single USB-C port, it can deliver up to 65W max output, sufficient for charging a 2020 MacBook Pro

13" at full speed.

- When using the USB-A port alone, it can deliver up to 22.5W max output.




Image: A diagram illustrating the maximum power output when only one port is in use: 65W for either USB-C port and 22.5W for the USB-A port.

Multi-Port Charging:

When multiple devices are connected, the charger intelligently distributes power to optimize charging speed for each device.



Image: The Anker 65W charger simultaneously charging a laptop, a smartphone, and a tablet, demonstrating its multi-device capability.

Two-Port Charging Scenarios:




Image: A diagram detailing power distribution when two ports are used concurrently, showing various wattage combinations.

Three-Port Charging Scenario:



Image: A diagram illustrating the power distribution when all three ports are in use, with specific wattage allocations for each port.

Important Note: For optimal charging of Apple Watch, use the USB-C ports. If you choose to use the USB-A port, ensure that no cables are plugged into the USB-C 2 port to avoid potential conflicts in power delivery.

5. Maintenance

Proper care and maintenance will extend the life of your Anker charger:

- **Cleaning:** Keep the charger clean and dry. Use a soft, dry cloth to wipe the surface. Do not use liquid cleaners or aerosols.
- **Storage:** Store the charger in a cool, dry place when not in use. Ensure the foldable prongs are retracted for compact storage and to prevent damage.
- **Handling:** Avoid dropping the charger or subjecting it to strong impacts.
- **Repair:** Do not attempt to repair or modify the charger yourself. Any unauthorized repairs will void the warranty.

6. Troubleshooting

If you encounter issues with your Anker charger, refer to the following common problems and solutions:

- **Device not charging:**
  - Ensure the charger is securely plugged into a working power outlet.
  - Verify that the charging cable is properly connected to both the charger and your device.
  - Try a different charging cable or a different port on the charger.
  - Confirm that your device is compatible with the charger's output specifications.
- **Slow charging:**
  - Ensure you are using a high-quality cable that supports fast charging.
  - If charging multiple devices, the power output per port will be lower. Disconnect other devices to maximize charging speed for a single device.
  - Check your device's charging specifications to ensure it supports the charger's output.
- **Charger feels warm during use:**
  - It is normal for the charger to become warm during operation, especially during high-power charging or when charging multiple devices.
  - If the charger becomes excessively hot to the touch, disconnect it immediately and allow it to cool down. If the issue persists, contact customer support.

7. Specifications




Image: A visual representation of the GaN II technology, emphasizing its benefits in terms of efficiency, thermal management, and compact design.

Feature	Detail
Brand	Anker
Model Number	A2667111

Connector Type	USB Type C (x2), USB Type A (x1)
Total USB Ports	3
Max Wattage Output	65W
Input Voltage	100-240V ~ 50/60Hz
Output Voltage	5V (variable based on device and port usage)
Output Current	3A (variable based on device and port usage)
Special Features	Fast Charging, Retractable Plug, GaN II Technology
Dimensions (Folded)	Approx. 1.50 × 1.15 × 2.60 inches
Weight	Approx. 3.95 ounces
Certifications	FCC, CE, UL
Material	Plastic

Note: Dimensions and weight are approximate and may vary slightly.

Compatible Devices:

- **Laptops:** MacBook Pro/Air, Dell XPS 13, Microsoft Surface Book 2, HP Spectre Folio, Google Pixelbook, ThinkPad E490
- **Tablets:** iPad Pro, iPad (2018 and later)
- **Smartphones:** iPhone 18 Pro / 17 / 17 Pro / 17 Pro Max / 16 / 16 Pro / 15 / 15 Pro / 14 / 14 Plus / 14 Pro / 14 Pro Max / 13 mini / 13 / 13 Pro / 13 Pro Max / 12 mini / 12 / 12 Pro / 12 Pro Max / SE (2nd Gen), Samsung Galaxy S20 / Note 20 / 10+, Google Pixel 3 and Later, Sony XZ3 / Xperia 1
- **Other:** Smartwatches, AirPods, Nintendo Switch



Image: A visual guide to the universal compatibility of the Anker 65W charger with a wide range of laptops, tablets, and smartphones.

8. Warranty and Support

This Anker product is covered by an **18-month worry-free warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product functions as intended under normal use.
For technical support, warranty claims, or further assistance, please visit the official Anker support website or contact their customer service team:

Anker Support Website

Please have your model number (A2667111) and proof of purchase ready when contacting support.

© 2023 Anker Innovations Limited. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09C5RG6KV

More documents and user manuals: **https://manuals.plus/**