Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Braun D601, Type 3767

Braun Oral-B Replacement Power Handle User Manual

Model: D601, Type 3767

1. Introduction

This manual provides essential information for the proper setup, operation, and maintenance of your Braun Oral-B Replacement Power Handle D601, Type 3767. Please read these instructions carefully before first use to ensure optimal performance and safety.

2. Important Safety Information

- This appliance is intended for household use only.
- Do not immerse the power handle in water. It is water-resistant but not designed for submersion.
- Do not modify or repair the product yourself. Contact an authorized service center for any repairs.
- Keep out of reach of children.
- Ensure the voltage of your charger is compatible with your local power supply.
- If the product is dropped, even if no damage is visible, the brush head should be replaced before the next use.

3. Product Overview

The Braun Oral-B Replacement Power Handle D601, Type 3767 is designed to provide an effective oral cleaning experience. It features a Li-Ion battery, 5 distinct brushing modes, and a pressure sensor light to guide your brushing technique.



Image 1: Front view of the Braun Oral-B Replacement Power Handle D601. This image displays the white handle with its power button, mode indicator lights, and the shaft where the brush head attaches. The design is sleek and ergonomic.

To identify your specific model type, refer to the bottom of the power handle. The type number is typically printed there.




Image 2: Diagram illustrating how to locate the type number on the bottom of an Oral-B power handle. The image shows two examples of the base of a toothbrush handle with the 'Type 3765' and 'Type 3768' circled, indicating where to find this information.

4. Setup

4.1 Initial Charging

This replacement power handle is designed to work with your existing Oral-B charger. Place the handle on your charger for a full charge before its first use. A full charge typically takes approximately 12-16 hours. The charging indicator light will provide feedback on the battery status.

4.2 Attaching a Brush Head

Align your Oral-B compatible brush head with the metal shaft on the power handle and push it down firmly until it clicks into place. Ensure the brush head is securely attached before use.

5. Operating Instructions

5.1 Power On/Off

Press the power button once to turn the toothbrush on. Press it again to turn it off.

5.2 Selecting Brushing Modes

Your D601 handle features 5 distinct brushing modes. To switch between modes, press the mode button (usually located below the power button) repeatedly until you reach your desired mode. The indicator lights will show the currently selected mode.

5.3 Pressure Sensor Light

The integrated pressure sensor light illuminates if you are brushing too hard. This feature helps protect your gums and teeth from excessive pressure. Reduce pressure immediately when the light activates.

5.4 Brushing Technique

Wet the brush head and apply a small amount of toothpaste. Place the brush head on your teeth at a slight angle towards the gumline. Guide the brush head slowly from tooth to tooth, allowing it to clean each surface for a few seconds. Do not scrub. The built-in timer (if applicable to your specific model) will signal when to move to another quadrant of your mouth.

6. Cleaning and Maintenance

6.1 After Each Use

- After brushing, rinse the brush head thoroughly under running water with the handle switched on.
- Turn off the handle and remove the brush head.
- Rinse both the brush head and the handle separately under running water.
- Wipe the handle dry with a soft cloth.

6.2 Charger Cleaning

Unplug the charger before cleaning. Wipe the charger surface with a damp cloth. Do not immerse the charger in water.

6.3 Brush Head Replacement

Dentists recommend replacing your brush head every 3 months, or sooner if the bristles are splayed or worn. Indicator bristles will fade halfway to signal when to replace your brush head.

7. Troubleshooting

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Battery is depleted.	Place the handle on the charger for a full charge.
Toothbrush does not charge.	Charger is not plugged in or faulty.	Ensure the charger is securely plugged into a working outlet. Try a different outlet.
Brush head does not oscillate or vibrates weakly.	Brush head is not properly attached or is worn.	Remove and reattach the brush head firmly. Replace the brush head if it is old or damaged.
Pressure sensor light constantly illuminates.	Brushing too hard.	Reduce the pressure applied during brushing.

Problem	Possible Cause	Solution

8. Specifications

- **Model:** D601
- **Type:** 3767
- **Battery Type:** Li-Ion
- **Brushing Modes:** 5
- **Features:** Pressure Sensor Light
- **Compatibility:** Fits Oral-B Types 3754, 3756, 3766, 3767. Fits Models Smart 4, Smart 5, Smart 5000, Smart Teen, Smart Professional, D601xxx, Pro 2, Pro 1000, Pro 2000, Pro 3000, D501xxx.
- **Manufacturer:** Braun
- **Item Weight:** 8 ounces
- **ASIN:** B09CG5ZSNQ

9. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your original Oral-B product or visit the official Braun Oral-B website. You may also contact Braun customer service directly for assistance.

© 2025 Braun. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09CG5ZSNQ

More documents and user manuals: **https://manuals.plus/**