Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

BEITONG BEITONG G2

BEITONG G2 Mobile Wireless Game Controller User Manual

Model: BEITONG G2

1. Introduction

Thank you for choosing the BEITONG G2 Mobile Wireless Game Controller. This high-performance gamepad is designed to enhance your mobile gaming experience on both iPhone (iOS 10.0 or above) and Android devices. Featuring low-latency connectivity, passthrough charging, and a comfortable grip, the G2 controller offers precise control and extended playtime.
This manual provides detailed instructions on setting up, operating, maintaining, and troubleshooting your BEITONG G2 controller to ensure optimal performance and longevity.

2. Product Features

- **Advanced Manipulator Elements:** Equipped with ALPS push-down large rockers for smooth movement, micro-switch shoulder buttons for shorter trigger life and extended durability, and crisp touch-switch cross keys.
- **Magnetic Combination Technology:** Innovative design allows the two controller halves to combine magnetically, making it chic and portable for gaming on the go.
- **Customizable Back Button:** Features an additional back button on the right side, ergonomically designed for easy access. Its function can be customized for continuous moves in games.
- **Modular Interchangeable Components:** Joysticks and arrow keys are modular and interchangeable, allowing adaptation to different player preferences and game types.
- **Stepless Stretch Design:** The controller features a stepless stretch structure, compatible with most mainstream mobile phones ranging from 67-92mm in width, even accommodating phone cases up to 10.5mm thick.
- **Dual Wireless Protocol Connection:** Utilizes an innovative dual-mode connection with stable and fast Bluetooth 5.0 and WiFi 2.4G chips for seamless wireless connectivity between the phone and controller.
- **Combined Magnetic Fast Charging:** Supports fast charging for both controller halves simultaneously.

3. Package Contents

Upon unboxing your BEITONG G2 Mobile Wireless Game Controller, please verify that all the following items are included:

- BEITONG G2 Mobile Wireless Game Controller (Left and Right halves)
- USB Charging Cable
- User Manual
- Interchangeable Joystick Caps (if applicable)
- Interchangeable D-Pad (if applicable)



Image: The BEITONG G2 controller shown with its retail packaging and included accessories, such as the USB cable and interchangeable components.

4. Setup Guide

4.1 Charging the Controller

Before first use, fully charge both halves of the BEITONG G2 controller. Connect the provided USB charging cable to a power source and to the charging port on the controller halves. The charging indicator light will show the charging status.



Image: Close-up view of the BEITONG G2 controller showing the charging port and connection point for power.

4.2 Attaching Your Phone

The BEITONG G2 features a stepless stretch design to securely hold your smartphone. Gently pull apart the two halves of the controller and insert your phone. Ensure your phone is centered and securely gripped by the controller's clamps. The controller is compatible with phones 67-92mm wide and phone cases up to 10.5mm thick.



Image: The BEITONG G2 controller with a smartphone securely mounted, demonstrating its adjustable grip mechanism.

4.3 Bluetooth Pairing

1. Ensure your phone's Bluetooth is enabled.
2. Turn on the BEITONG G2 controller. Refer to the specific power button location in the diagram.
3. The controller will enter pairing mode (indicator light will flash).
4. On your phone, search for Bluetooth devices and select "BEITONG G2" from the list.
5. Once paired, the indicator light on the controller will become solid.



Image: An internal view of the BEITONG G2 controller, highlighting its magnetic connection and wireless communication components.

5. Operating Instructions

5.1 Basic Controls

The BEITONG G2 controller features standard gamepad controls:

- **Left Joystick:** For movement and navigation.
- **D-Pad (Cross Key):** For directional input.
- **Action Buttons:** (A, B, X, Y - if labeled, otherwise generic action buttons) for in-game actions.
- **Shoulder Buttons (L1/R1):** For quick actions or firing.
- **Back Button (Customizable):** Located on the right side, can be programmed for specific in-game functions.



Image: A hand demonstrating the ergonomic placement and use of the customizable back button on the BEITONG G2 controller.

5.2 Customizing Components

The BEITONG G2 allows for modular interchangeability of joysticks and arrow keys. To change these components, gently pull them off and replace them with your preferred alternatives. This allows for customization based on game type or personal preference.



Image: Exploded view of the BEITONG G2 controller showing how joystick caps and D-pad can be interchanged for customization.

6. Maintenance

To ensure the longevity and optimal performance of your BEITONG G2 controller, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe down the controller. For stubborn dirt, a slightly damp cloth can be used, but ensure no moisture enters the ports or internal components. Avoid harsh chemicals or abrasive cleaners.
- **Storage:** Store the controller in a cool, dry place away from direct sunlight and extreme temperatures. When not in use, consider combining the two halves magnetically for compact storage.

- **Battery Care:** Avoid fully discharging the battery frequently. If storing for an extended period, charge the controller to about 50% to preserve battery health.

7. Troubleshooting

Problem	Possible Cause	Solution
Controller does not turn on.	Low battery.	Charge the controller fully using the provided USB cable.
Unable to pair via Bluetooth.	Bluetooth not enabled on phone; controller not in pairing mode; interference.	Ensure phone Bluetooth is on. Put controller in pairing mode. Move closer to phone. Try unpairing and re-pairing.
Buttons or joysticks unresponsive.	Connection issue; software glitch; physical damage.	Reconnect the controller. Restart your phone and the controller. Check for physical obstructions or damage.
Phone does not fit in the grip.	Phone width exceeds limits; phone case too thick.	Ensure phone width is between 67-92mm. Remove phone case if it exceeds 10.5mm thickness.

8. Specifications

Feature	Detail
Model Number	BEITONG G2
Product Dimensions	3.77 x 3.28 x 1.81 inches
Item Weight	4.6 ounces
Batteries	2 Lithium Ion batteries (included)
Connectivity	Bluetooth 5.0, WiFi 2.4G
Compatible Phone Width	67-92mm
Max Phone Case Thickness	10.5mm
Manufacturer	BEITONG

9. Warranty and Support

The BEITONG G2 Mobile Wireless Game Controller comes with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty period and coverage details.
For technical support, troubleshooting assistance, or warranty claims, please contact BEITONG customer service through their official website or the contact information provided in your product documentation. Keep your purchase receipt as proof of purchase for warranty purposes.
For more information, visit the official BEITONG store:BEITONG Store on Amazon

© 2024 BEITONG. All rights reserved.
This manual is subject to change without notice. Please refer to the latest version available on the manufacturer's website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09G2ZX1RG

More documents and user manuals: **https://manuals.plus/**