Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JIUYOTREE JYLYJJBK

JIUYOTREE Metal Clothing Rack Instruction Manual

Model: JYLYJJBK

1. Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your JIUYOTREE Metal Clothing Rack. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of the product. This garment rack is designed for organizing clothes and shoes, offering a practical storage solution for various spaces.

2. Safety Information

- Ensure all parts are securely fastened before use.
- Do not exceed the maximum load capacity of 50 pounds for the hanging rod and 80 pounds total for the entire unit. Overloading may cause instability or damage.
- Keep small parts and packaging materials away from children to prevent choking hazards.
- Place the rack on a flat, stable surface to prevent tipping.
- Avoid placing the rack in areas with high humidity or direct sunlight for extended periods to preserve the finish.

3. Package Contents

Before beginning assembly, verify that all components are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Main Hanging Rod
- Side Support Frames (2)
- Bottom Shelf Rods (2)
- Connecting Screws and Allen Wrench

- Anti-slip Foot Pads (4)

4. Setup and Assembly

Assembly is straightforward and typically takes less than 30 minutes. An Allen wrench is included for your convenience.

1. **Step 1: Attach Side Support Frames**
   Place the two side support frames on a flat surface. Ensure the openings for the bottom shelf rods are facing inward.
2. **Step 2: Install Bottom Shelf Rods**
   Insert the two bottom shelf rods into the designated holes on the lower section of the side support frames. Secure them using the provided screws and Allen wrench. Ensure they are tightened firmly for stability.
3. **Step 3: Connect Main Hanging Rod**
   Align the main hanging rod with the top openings of the side support frames. Insert the rod and secure it with the remaining screws using the Allen wrench. The anti-slip beads on the ends of the rod should face outwards.
4. **Step 4: Attach Anti-slip Foot Pads**
   Press the four anti-slip foot pads onto the bottom of each side support frame. These pads provide stability and protect your floor.




Figure 1: Detailed view of key components and assembly points.

5. Operating Instructions

Your JIUYOTREE Metal Clothing Rack is designed for versatile use in various settings.

- **Hanging Clothes:** Use the top rod to hang shirts, coats, skirts, and sweaters. The anti-slip beads at the ends prevent hangers from sliding off.
- **Bottom Shelf Storage:** The integrated bottom shelf provides additional storage space for shoes, shoe boxes, or other accessories. This also contributes to the rack's overall stability.
- **Load Capacity:** The rack can support up to 50 pounds on the hanging rod and a total maximum weight of 80 pounds. Distribute weight evenly to maintain stability.



Figure 2: JIUYOTREE Metal Clothing Rack in a typical usage scenario.



Figure 3: The rack functions as both a coat rack and a shoe rack.

6. Maintenance

Regular maintenance will help preserve the appearance and functionality of your clothing rack.

- **Cleaning:** Wipe the metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the rust-proof coating.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary.
- **Rust Prevention:** The rack features an environmentally friendly paint coating designed to prevent rust. If the coating is scratched, consider applying a rust-inhibiting touch-up paint to prevent corrosion.

7. Troubleshooting

- **Rack feels wobbly:** Ensure all screws are fully tightened. Verify the rack is placed on a level surface. The anti-

slip foot pads should provide adequate grip.

- **Clothes sliding off the ends:** The main hanging rod is equipped with anti-slip beads at each end to prevent hangers from falling. Ensure hangers are placed within the main rod area.
- **Rack appears to sag in the middle:** This indicates potential overloading. Reduce the number or weight of items hanging on the rod. Distribute weight evenly across the rod. The maximum load capacity for the hanging rod is 50 pounds.

8. Specifications

Feature	Specification
Brand	JIUYOTREE
Model Number	JYLYJJBK
Material	Alloy Steel (Iron)
Color	Black
Product Dimensions (D x W x H)	15.75" x 43.31" x 59.06" (40cm x 110cm x 150cm)
Item Weight	4.6 pounds
Load Capacity (Hanging Rod)	50 pounds
Maximum Weight Recommendation (Total)	80 pounds
Special Feature	Rust-Proof Coating, Anti-slip Beads, Bottom Shelf
Assembly Required	Yes




Figure 4: Product Dimensions.

9. Warranty and Support

JIUYOTREE is committed to providing high-quality products. For any questions, concerns, or assistance with your product, please contact JIUYOTREE customer support through your retailer's platform or the official brand website. Please have your model number (JYLYJJBK) and purchase information ready when contacting support.

© 2025 JIUYOTREE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09GN4J8B3

More documents and user manuals: **https://manuals.plus/**