Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paw Patrol 6063595

Paw Patrol Rescue Knights Rubble and Dragon Blizzie Action Figures Instruction Manual

Brand: Paw Patrol | **Model:** 6063595

Introduction

This manual provides instructions for the Paw Patrol Rescue Knights Rubble and Dragon Blizzie Action Figures. This set allows children to recreate exciting medieval rescue missions with Rubble and his dragon companion, Blizzie. The figures feature interactive elements designed for imaginative play.



Image: The Rubble action figure, wearing yellow armor with a working tool, stands next to the purple and blue dragon Blizzie, which has translucent blue wings.

Safety Information

For the safety of the child, please observe the following:

- Remove all packaging attachments, including ties, plastic clips, and any other components not part of the toy, before giving this product to a child.
- This product contains small parts and is recommended for ages 36 months to 5 years. Adult supervision is advised during play.

What's in the Box

Your package should contain the following items:

- 1 x PAW Patrol Rubble Figure
- 1 x Dragon Blizzie Figure



Image: The product packaging showing Rubble and Dragon Blizzie figures inside a castle-themed box.

Setup

The Paw Patrol Rescue Knights Rubble and Dragon Blizzie figures are ready for play directly out of the packaging after removing all protective materials.

1. **Unpack Figures:** Carefully remove Rubble and Blizzie from their packaging. Ensure all plastic ties and protective films are discarded safely.

2. **Inspect Figures:** Check both figures for any visible damage or loose parts before play.



Image: A front-facing view of the Rubble figure and the Blizzie dragon figure, highlighting their detailed designs.

Operating Instructions

Engage in exciting rescue missions with Rubble and Blizzie by utilizing their unique features:

1. **Rubble's Rescue Tool Activation:**

   To activate Rubble's backpack tool, locate the badge button on his armor. Press this button firmly to make the tool transform and pop open from his backpack, ready for action.

2. **Blizzie's Flapping Wings:**

   For Blizzie's wings to flap, first, clip the Rubble figure onto Blizzie's back. Then, locate the button on Blizzie's tail. Push this button to make Blizzie's glittery translucent wings flap, simulating flight.



Image: A side view of Rubble and Blizzie, illustrating the position of Blizzie's wings and Rubble's backpack tool.



Image: A child engaging in imaginative play with several Paw Patrol Rescue Knights figures, including Rubble and Blizzie, on a white table.

Maintenance

To ensure the longevity of your Paw Patrol figures, follow these simple maintenance guidelines:

- **Cleaning:** Wipe figures with a damp cloth to remove dust and dirt. Do not submerge in water or use harsh chemicals.
- **Storage:** Store figures in a cool, dry place away from direct sunlight and extreme temperatures to prevent material degradation.
- **Handling:** Avoid excessive force when operating movable parts to prevent damage.

Troubleshooting

If you encounter any issues with your figures, consider the following:

- **Tool/Wing Not Activating:** Ensure the respective buttons (Rubble's badge, Blizzie's tail button) are pressed firmly. Check for any obstructions in the mechanism.

- **Loose Parts:** If any parts appear loose, discontinue use and contact customer support. Do not attempt to repair the toy yourself.

Specifications

Feature	Detail
Product Dimensions	9.88 x 2.5 x 7.5 inches
Item Weight	7 ounces
ASIN	B09J8J7NF4
Item Model Number	6063595
Manufacturer Recommended Age	36 months - 5 years
Release Date	January 1, 2022
Manufacturer	Spin Master

Warranty and Support

This product is manufactured by Spin Master. For any inquiries regarding product defects, missing parts, or operational issues not covered in this manual, please contact Spin Master customer support directly.
For additional information or to explore other Paw Patrol products, please visit the officialPaw Patrol Store on Amazon.

© 2022 Spin Master Ltd. All Rights Reserved. PAW Patrol and all related titles, logos, characters, and SPIN MASTER logo are trademarks of Spin Master Ltd. Used under license.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09J8J7NF4

More documents and user manuals: **https://manuals.plus/**