Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-T13

Joyroom JR-T13 Pro True Wireless Earphones User Manual

Model: JR-T13 Pro

Introduction

Thank you for choosing the Joyroom JR-T13 Pro Bilateral True Wireless HD Stereo Sounds Earphones. These earphones are designed to provide a superior audio experience with features like IPX5 waterproofing, ergonomic design, and advanced Bluetooth 5.2 connectivity. This manual will guide you through the setup, operation, and maintenance of your new earphones to ensure optimal performance and longevity.



JR-T13 Pro
New upgrade
Wireless Audio
Bluetooth Earphone
Noise reduction
AUDIO

Image: A person wearing the white Joyroom JR-T13 Pro earphones, demonstrating their ergonomic fit and wireless design.

Safety Information

- Do not disassemble or modify the earphones or charging case.
- Keep the device away from extreme temperatures, humidity, and corrosive substances.
- Avoid prolonged exposure to high volume levels to prevent hearing damage.
- Clean the earphones with a soft, dry cloth. Do not use harsh chemicals.
- Dispose of the product responsibly according to local regulations.

Package Contents

Please check the package contents upon unboxing:

- Joyroom JR-T13 Pro True Wireless Earphones (Left and Right)
- Charging Case
- USB Type-C Charging Cable
- User Manual

Product Overview

Familiarize yourself with the components of your Joyroom JR-T13 Pro earphones.





Image: The Joyroom JR-T13 Pro white earphones shown with their charging case, illustrating their compact and sleek design.

- **Earbuds:** Each earbud features a touch control area, microphone, and charging contacts.
- **Charging Case:** Houses the earbuds for charging and storage, with a Type-C charging port and LED indicator.
- **High-fidelity Graphene Diaphragm:** Provides deep bass, clear mids, and crisp treble for a rich audio experience.
- **Infrared In-ear Detection IC:** Automatically pauses music when earbuds are removed and resumes when put back on.
- **Noise Reduction Microphone:** Enhances call clarity by filtering out ambient noise.



Image: A diagram highlighting the upgraded features of the JR-T13 Pro, including in-ear detection IC, diaphragm, Bluetooth 5.2, and noise reduction microphone.

Setup

1. Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case.

1. Place the earphones into the charging case. Ensure they are correctly seated.
2. Connect the USB Type-C cable to the charging port on the case and the other end to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator on the case will show charging status. A full charge typically takes about 1 hour for the earphones and case.
4. The charging case supports Qi-standard wireless charging. Place the case on a compatible wireless charging pad for convenient charging.



Image: The Joyroom JR-T13 Pro charging case with an earbud resting on a smartphone, illustrating its large battery capacity and charging capabilities. The image indicates 350h endurance, 1h charging time, and 20h listening time with the charging compartment.

2. Pairing with Your Device

1. Open the charging case. The earphones will automatically power on and enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth.
3. Search for "JR-T13 Pro" in the list of available Bluetooth devices and select it to connect.
4. Once connected, you will hear a confirmation tone, and the LED indicator on the earphones will change.
5. The earphones support seamless switching between binaural (both earbuds) and monaural (single earbud) modes.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case, or take the earphones out of the case. They will power on automatically.

- **Power Off:** Place the earphones back into the charging case and close the lid. They will power off automatically.

Music Playback Controls

Action	Control
Play/Pause	Single tap on either earbud
Next Track	Double tap on the right earbud
Previous Track	Double tap on the left earbud
Volume Up	Triple tap on the right earbud
Volume Down	Triple tap on the left earbud

Call Management

Action	Control
Answer/End Call	Single tap on either earbud
Reject Call	Press and hold either earbud for 2 seconds

Smart Features

- **In-ear Detection:** The earphones feature an infrared in-ear detection IC. Music will automatically pause when you remove an earbud and resume when you put it back on.



Image: A visual representation of the Infrared Smart IC In-ear Detection feature, showing how music auto-pauses when earbuds are taken off and auto-plays when put on.

Maintenance

- **Cleaning:** Regularly clean the earbuds and charging case with a soft, lint-free cloth. For stubborn dirt, slightly dampen the cloth with water. Do not use alcohol, benzene, or other chemical cleaners.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage. Store in a cool, dry place.
- **Water Resistance:** The earphones are IPX5 waterproof, meaning they are resistant to splashes and sweat. Do not submerge them in water or expose them to heavy rain. Dry them thoroughly if they get wet.

Troubleshooting

Problem	Possible Solution

Problem	Possible Solution
Earphones not pairing	Ensure earphones are charged. Turn off and on Bluetooth on your device. Forget "JR-T13 Pro" from your device's Bluetooth list and try pairing again.
Only one earbud working	Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. Ensure both are charged.
No sound	Check volume levels on both earphones and your connected device. Ensure earphones are properly connected to your device.
Charging case not charging	Check the USB cable and power adapter. Try a different cable or power source. Ensure the cable is securely connected.

Specifications

Feature	Detail
Model	JR-T13 Pro
Bluetooth Version	5.2
Music/Talk Time	Up to 6 hours (earbuds)
Total Listening Time	16-24 hours (with charging case)
Charging Time	Approx. 1 hour (earbuds & case)
Standby Time	24 hours
Charging Type	Type-C, Qi-standard Wireless Charging
Water Resistance	IPX5 (splash and sweat resistant)
Speaker Size	13mm large speaker
Audio Decoding	AAC high fidelity
Weight	140 Grams (total package)
Dimensions	21.1 x 16.7 x 3.3 cm




Image: A close-up illustration of the high-fidelity Graphene Diaphragm, emphasizing its role in delivering deep bass, clear, and loud treble.

Warranty and Support

Joyroom products come with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact Joyroom customer service through their official website or the retailer where you purchased the product.
For more information, visit the official Joyroom store:Joyroom Store on Amazon

© 2024 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09JHZS11C

More documents and user manuals: **https://manuals.plus/**