Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DeLUX DELUX-M618XSU

DeLUX Seeker Wired Ergonomic Vertical Mouse User Manual

Model: DELUX-M618XSU BLACK

1. Introduction

The DeLUX Seeker Wired Ergonomic Vertical Mouse (Model: DELUX-M618XSU BLACK) is designed to provide a comfortable and natural hand position, reducing strain during extended use. This manual provides comprehensive instructions for setting up, operating, customizing, and maintaining your mouse.
Key features include a thumb wheel for horizontal scrolling, 6 programmable buttons, adjustable DPI up to 4000, and an LED backlight. The magnetic detachable wrist rest further enhances ergonomic comfort.

2. Product Overview and Features

The DeLUX Seeker mouse incorporates several design elements for enhanced user experience and comfort.



Front view of the DeLUX Seeker ergonomic vertical mouse, showcasing its black finish, honeycomb-patterned LED backlight, and detachable wrist rest.




Illustration demonstrating the natural handshake position achieved with the vertical mouse compared to the pronated position of a traditional mouse, highlighting ergonomic benefits.

Key Features:

- **Ergonomic Vertical Design:** Promotes a natural handshake position to reduce wrist and arm strain.
- **Thumb Wheel:** Enables convenient horizontal scrolling for improved navigation in wide documents or applications.
- **Programmable Buttons:** Six customizable buttons for personalized functions and macros.
- **Adjustable DPI:** Up to 4000 DPI for precise tracking and sensitivity control (800/1200/1600/2400/4000).
- **LED Backlight:** Customizable lighting effects for aesthetic appeal and enhanced user experience.
- **Magnetic Detachable Wrist Rest:** Provides additional support and comfort, easily removable for preference.
- **Wired Connection:** 1.8m braided cable ensures stable and reliable performance without battery concerns.

3. Setup Guide


Follow these steps to set up your DeLUX Seeker mouse:

1. **Unpack the Mouse:** Carefully remove the mouse and its components from the packaging.

2. **Connect to Computer:** Plug the USB cable of the mouse into an available USB port on your computer.
3. **Driver Installation (Automatic):** For most Windows operating systems, the mouse will be recognized automatically, and standard drivers will be installed.
4. **Attach Wrist Rest (Optional):** If desired, attach the magnetic wrist rest to the base of the mouse for added ergonomic support.
5. **Install Customization Software (Recommended):** For full functionality, including button programming, DPI adjustment, and LED customization, download and install the official driver software from deluxworld.com/en-service.html. *Note: Software works under Windows and Linux systems. Backward/Forward buttons and driver are not available for macOS, but other buttons and functions can be used normally.*

4. Operating Instructions

The DeLUX Seeker mouse features intuitive controls for daily use.



Detailed view of the normal scroll wheel for vertical navigation and the thumb wheel for horizontal navigation.




Visual representation of the mouse's high precision tracking and the concept of less movement with higher DPI settings.

Button Functions:

- **Left Click:** Standard primary click function.
- **Right Click:** Standard secondary click function.
- **Scroll Wheel:** Used for vertical scrolling. Pressing it typically acts as a middle click.
- **Thumb Wheel:** Located on the side, this wheel allows for horizontal scrolling, useful for wide spreadsheets or timelines.
- **Forward/Backward Buttons:** Located near the thumb, these buttons facilitate navigation in web browsers and file explorers.
- **DPI Button:** Cycles through different DPI sensitivity levels (800/1200/1600/2400/4000) to adjust cursor speed.

5. Customization and Software

Unlock the full potential of your DeLUX Seeker mouse by utilizing its dedicated software (for Windows and Linux systems).



The software interface for customizing light settings, button functions, macros, and other mouse parameters.

Software Sections:

- **Light Section:** Customize the effects and colors of the LED backlight.
- **Button Section:** Program each of the 6 buttons with desired functions, including keyboard shortcuts or multimedia controls.
- **Macro Section:** Create and assign complex sequences of commands (macros) to buttons for automated tasks.
- **Other Settings Section:** Adjust advanced parameters such as DPI levels, polling rate (125Hz-250Hz-500Hz-1000Hz), and scroll speed.

The software allows for creating personalized profiles to optimize your workflow and gaming experience.

6. Maintenance

Proper care will ensure the longevity and optimal performance of your mouse.

- **Cleaning:** Use a soft, dry cloth to wipe the surface of the mouse. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the internal components.

- **Sensor Maintenance:** Keep the optical sensor on the underside of the mouse clean and free from dust or debris to ensure accurate tracking.
- **Cable Care:** Avoid sharp bends or excessive pulling on the braided USB cable to prevent damage.
- **Storage:** When not in use, store the mouse in a clean, dry environment away from extreme temperatures.

7. Troubleshooting

If you encounter issues with your DeLUX Seeker mouse, refer to the following common solutions:

Problem	Possible Cause	Solution
Mouse not responding	Loose USB connection, faulty USB port, driver issue.	Ensure USB cable is securely plugged in. Try a different USB port. Restart your computer. Reinstall mouse drivers.
Inaccurate tracking or cursor lag	Dirty optical sensor, unsuitable mouse pad surface, incorrect DPI setting.	Clean the optical sensor. Use a clean, uniform mouse pad. Adjust DPI settings using the DPI button or software.
Buttons not functioning as expected	Software configuration error, driver not installed (for programmable buttons).	Check button assignments in the customization software. Ensure the software is installed and running correctly. (Note: Backward/Forward buttons and driver are not available for macOS).
LED backlight not working or incorrect color	Software setting, power issue.	Verify LED settings in the customization software. Ensure the mouse is receiving sufficient power from the USB port.

8. Specifications

Model Number	DELUX-M618XSU BLACK
Connection Type	Wired (1.8m braided cable)
DPI Settings	800 / 1200 (default) / 1600 / 2400 / 4000 (adjustable via driver)
Buttons	6 Programmable Buttons (Left/Right click, Scroll wheel, Thumb wheel, Forward/Backward, DPI button)
Polling Rate	125Hz-250Hz-500Hz-1000Hz
Movement Detection	Optical
Dimensions (L*W*H)	165.8mm * 96.9mm * 81.7mm (6.54 x 3.82 x 3.23 inches)
Weight	167g (5.9 ounces)
Compatible Systems	Windows XP/7/8/10/11, Limited macOS (Driver software for Windows/Linux only; some functions limited on macOS)

9. Warranty and Support

All DeLUX products, including the Seeker mouse, come with a**12-month warranty** and **free lifetime technical support**.
For technical assistance, driver downloads, or warranty claims, please visit the official DeLUX website or contact their customer support.

- **Driver Download:** deluxworld.com/en-service.html
- **User Manual (PDF):** Download PDF

© 2024 DeLUX. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09KC7PTC9

More documents and user manuals: **https://manuals.plus/**