Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO THSL-009

TRESKO 2500W Infrared Heater User Manual

Model: THSL-009

1. Important Safety Instructions

Please read these instructions carefully before using the appliance and keep them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the heater is placed on a stable, level surface or securely mounted to a wall.
- Do not cover the heater. Covering the heater can cause overheating and fire.
- Keep flammable materials (curtains, furniture, paper, etc.) at least 1 meter (3 feet) away from the heater.
- Do not operate the heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Do not use the heater in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water.
- Unplug the heater when not in use.
- Ensure the power supply voltage matches the rating on the heater's label.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. Product Overview

The TRESKO Infrared Heater provides efficient and comfortable warmth for both indoor and outdoor environments. It features a durable aluminum housing, a stainless steel protective grill, and an integrated instant heat process for rapid warming.



The TRESKO Infrared Heater, showcasing its sleek design, included remote control, and protective cover.



Detailed view of the heater's LED display and the remote control, highlighting its quick heating, 2.0m cable, 1-24 hour timer, 3 heat levels, and 2500W max power.

Key Features:

- **Efficient Heating:** Quartz tube technology, 30% more economical than normal halogen tubes. Converts 90% of energy into heat.
- **Versatile Use:** Suitable for both indoor and outdoor environments. Corrosion-resistant design.
- **Adjustable Power:** Three power levels (850W, 1650W, 2500W) controlled by remote.
- **Timer Function:** Programmable timer from 1 to 24 hours.
- **Adjustable Angle:** Tilt angle can be adjusted for optimal heat direction.
- **Quiet Operation:** Extremely low noise level, suitable for various settings.
- **Durable Construction:** Robust stainless steel protective grill and aluminum housing.

3. Setup and Installation

The TRESKO Infrared Heater is designed for easy wall mounting. Ensure you have the necessary tools and follow these steps for secure installation.



The heater shown mounted on a wall, illustrating its easy installation and robust features like maximum reflection, stainless steel grill, weather resistance, aluminum housing, and light weight.



Diagram showing the dimensions of the heater: A (height) 18 cm, B (length) 87 cm, C (depth) 9 cm, and cable length 2.0 m. Also indicates individual adaptability and easy mounting.

Installation Steps:

1. **Choose Location:** Select a suitable wall location, ensuring it is away from flammable materials and has access to a power outlet. Consider the heater's dimensions (87 cm length x 18 cm height x 9 cm depth) for proper placement.
2. **Mark Drilling Points:** Use the provided mounting bracket as a template to mark the drilling points on the wall.
3. **Drill Holes:** Drill holes at the marked points and insert wall plugs if necessary.

4. **Attach Bracket:** Securely attach the mounting bracket to the wall using screws.
5. **Mount Heater:** Carefully attach the heater to the mounting bracket. Ensure it is firmly seated and stable.
6. **Adjust Angle:** Adjust the tilt angle of the heater to direct warmth as desired.

For outdoor use, ensure the heater is protected from direct heavy rain and is installed in a covered area.

4. Operating Instructions

The TRESKO Infrared Heater is operated using the included remote control, allowing for convenient adjustment of settings.

Remote Control Functions:

- **Power Button:** Turns the heater ON or OFF.
- **Power Level Selection:** Cycle through the three power levels:
  - **Level 1:** 850W (Low heat)
  - **Level 2:** 1650W (Medium heat)
  - **Level 3:** 2500W (High heat)
- **Timer Button:** Activates and adjusts the timer function. The timer can be set from 1 to 24 hours, after which the heater will automatically turn off.

Using the Heater:

1. Plug the heater into a suitable power outlet (220 Volts).
2. Press the Power button on the remote control to turn the heater on. The LED display on the heater will illuminate.
3. Select your desired heat level using the power level buttons on the remote.
4. If desired, set the timer for automatic shut-off.
5. To turn off the heater, press the Power button again.



The TRESKO Infrared Heater providing comfortable warmth for enjoyable evenings on a patio.



The heater providing cozy warmth in an indoor setting, demonstrating its versatility.

5. Maintenance

Regular maintenance ensures the longevity and optimal performance of your TRESKO Infrared Heater.

- **Cleaning:** Before cleaning, always unplug the heater and allow it to cool completely. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Storage:** When not in use for extended periods, store the heater in a cool, dry place. It is recommended to use the included protective cover to shield it from dust and moisture.
- **Inspection:** Periodically check the power cord and plug for any signs of damage. If damage is found, do not use the heater and contact customer support.



The heater is designed for both indoor and outdoor use and is resistant to corrosion, making maintenance easier.

6. Troubleshooting

If you encounter any issues with your TRESKO Infrared Heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Power button not pressed. Timer activated.	Check if the heater is plugged in and the outlet is working. Press the Power button on the remote. Check if the timer is set to 0 or has expired.
Heater produces no heat.	Low power level selected. Heating element failure.	Increase the power level using the remote control. Contact customer support if the element is visibly damaged or not glowing.
Remote control not working.	Dead batteries. Obstruction between remote and heater.	Replace batteries in the remote control. Ensure there is a clear line of sight to the heater's receiver.
Heater turns off unexpectedly.	Overheating protection activated. Timer expired.	Unplug the heater, let it cool down for 30 minutes, and ensure proper ventilation. Check the timer setting.

If the problem persists after trying these solutions, please contact TRESKO customer support.

7. Specifications

Detailed technical specifications for the TRESKO Infrared Heater Model THSL-009.

Specification	Value
Brand	TRESKO
Model Number	THSL-009
Color	Black
Dimensions (L x W x H)	87 x 18.01 x 18.01 cm
Weight	4 Kilograms
Power	2500 Watts (Max)
Voltage	220 Volts
Number of Speeds	3 (850W, 1650W, 2500W)
Automatic Shut-off Function	Yes (Timer)
Special Features	Remote Control, Timer (1-24 hours)
Heating Method	Radiant (Infrared)
Indoor/Outdoor Use	Yes
Mounting Type	Wall Mount

8. Warranty and Support

The TRESKO Infrared Heater Model THSL-009 comes with a commitment to quality and customer satisfaction.

Spare Parts Availability:

Spare parts for this product are available for a period of**2 years** from the date of purchase.

Customer Support:

For any questions, technical assistance, or warranty claims, please contact your retailer or the manufacturer directly. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09MD9NL2T

More documents and user manuals: **https://manuals.plus/**