Mimoglad OC-5188H

Mimoglad Ergonomic Office Chair OC-5188H User Manual

Model: OC-5188H

Important Safety Information

Please read and understand all instructions before assembly and use. Retain this manual for future reference.

- Ensure not to exceed the maximum weight capacity of **300 lbs (136 kg)** for safe usage.
- Adjust the lumbar support and reclining feature carefully to avoid injury.
- Inspect the chair regularly for any loose or worn-out components, especially the nylon and mesh materials, to prevent accidents.
- Keep children away from the chair during assembly. Small parts may pose a choking hazard.
- Do not stand on the chair.

Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Backrest
- Seat Cushion
- Armrests (2)
- Gas Lift Cylinder
- Star Base
- Casters (5)
- Headrest
- Hardware Kit (screws, washers, Allen wrench)

Assembly Instructions

Assembly typically takes approximately 20 minutes. All necessary tools are included.

1. **Attach Casters to Base:** Insert the five casters into the holes at the end of each leg of the star base. Push firmly until they

click into place.

2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled star base.
3. **Attach Armrests to Seat:** Secure the armrests to the underside of the seat cushion using the provided screws. Ensure the armrests are oriented correctly.
4. **Attach Backrest to Seat:** Align the backrest with the seat cushion and secure it using the designated screws.
5. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.
6. **Attach Headrest:** Slide the headrest into the slots at the top of the backrest until it is securely in place.



Figure 1: Chair dimensions and assembly overview.



Figure 2: Detail of base and caster assembly.

Operating Instructions

Familiarize yourself with the chair's adjustable features to optimize your comfort and ergonomic support.

1. Seat Height Adjustment

- To raise the seat: While seated, lift the lever located under the right side of the seat. The seat will rise. Release the lever at the desired height.
- To lower the seat: While seated, lift the lever located under the right side of the seat. The seat will lower. Release the lever at the desired height.

2. Lumbar Support Adjustment

- The adjustable lumbar support can be moved vertically by approximately 2 inches (5.08 cm) to conform to your lower back's natural curve. Gently push or pull the lumbar support pad to adjust its position.



Figure 3: Ergonomic lumbar support adjustment.

3. Headrest Adjustment

- The headrest can be adjusted vertically by approximately 1.2 inches (3.05 cm) to provide optimal neck and head support. Gently push or pull the headrest to set it to your preferred height.



Figure 4: Neck and head support adjustment.

4. Recline and Rocking Function

- To recline: Pull out the recline control lever located under the left side of the seat. Lean back to your desired angle (between 90° and 135°). Push the lever back in to lock the recline position.
- To activate rocking: Pull out the recline control lever. The chair will now allow a rocking motion.
- To adjust rocking tension: Rotate the tension device knob located under the front of the seat. Turn clockwise to increase tension (stiffer rock) or counter-clockwise to decrease tension (looser rock).




Figure 5: Rocking system controls and recline range.

5. Flip-Up Armrests

- The armrests can be flipped up to allow the chair to slide closer to a desk or to save space when not in use. Simply lift the armrests upwards until they lock into the vertical position. To lower, pull them down.



Figure 6: Flip-up armrests for flexibility.

Maintenance and Care

- **Cleaning:** Spot clean the chair as needed. Use a mild detergent and a damp cloth for fabric and mesh surfaces. Avoid harsh chemicals.
- **Inspection:** Periodically check all screws and bolts to ensure they are tight. Re-tighten if necessary.
- **Casters:** Keep casters free of debris (hair, dust) to ensure smooth movement.
- **General Care:** Avoid exposing the chair to direct sunlight for extended periods to prevent fading of materials.

Troubleshooting

If you encounter any issues with your Mimoglad office chair, please refer to the following common solutions:

- **Chair feels wobbly:** Ensure all assembly screws are securely tightened. Check that the gas lift is fully inserted into the base and the seat mechanism.
- **Chair does not adjust height:** Verify that the gas lift lever is functioning correctly and that the gas lift cylinder is properly

installed. If the issue persists, the gas lift may need replacement.

- **Casters not rolling smoothly:** Check for any debris (hair, lint) caught in the caster wheels. Clean them thoroughly.
- **Recline function not working:** Ensure the recline control lever is pulled out to allow rocking/recline. Check the tension device knob; it might be too tight.

For issues not resolved by these steps, please contact Mimoglad customer support.

Specifications

Feature	Detail
Brand	Mimoglad
Model Name	Home Office Desk Chair (OC-5188H)
Color	Spanish Pink
Product Dimensions	16.53"D x 19.68"W x 50.78"H
Maximum Weight Recommendation	300 Pounds
Special Features	Adjustable Headrest, Adjustable Height, Adjustable Lumbar, Ergonomic, Flip-up Armrests
Back Style	Solid Back with Breathable Mesh
Seat Height	Adjustable, up to 22.83 Inches
Seat Depth	16.53 inches
Reclining Position Count	2 (90-135 degrees)
Tilting	Yes
Included Components	Arm Pad, Caster, Cushion
Certifications	SGS & BIFMA PASSED
Item Weight	26 pounds
Manufacturer	Mimoglad

Warranty and Support

Mimoglad is committed to providing high-quality products and excellent customer service.

- **5-Year Warranty:** This product is covered by a 5-year warranty from the date of purchase, covering manufacturing defects.
- **90-Day Return Policy:** Enjoy peace of mind with a 90-day return and replacement service.
- **Dedicated Support:** Our responsive customer support team is available to assist you with any inquiries or issues. We aim to respond within 24 hours.
- **Contact Information:** For support, please refer to the contact details provided on the product packaging or the official Mimoglad website.



Figure 7: Mimoglad warranty and support information.

Video Resources

No official product videos from the seller were available for embedding in this manual based on the provided data.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Where can I find the assembly instructions for the Mimoglad OC-5188H Ergonomic Office Chair if I lost the original manual?

You can find the assembly instructions for your Mimoglad OC-5188H right here on this page. Assembly typically takes about 20 minutes and all necessary tools (Allen wrench) are included in the hardware kit.Assembly Steps:Attach...

Read full answer