Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP JC-82

ZOKOP JC-82 28-Bottle Compressor Wine Cooler User Manual

Model: JC-82

Introduction

Thank you for choosing the ZOKOP JC-82 28-Bottle Compressor Wine Cooler. This manual provides essential information for the safe and efficient operation, installation, and maintenance of your new appliance. Please read this manual thoroughly before use and retain it for future reference.

Safety Information

To reduce the risk of fire, electric shock, or injury when using your appliance, follow these basic precautions:

- Read all instructions before using the appliance.
- Do not touch cold surfaces, especially when the appliance is operating.
- Never clean appliance parts with flammable fluids. The fumes can create a fire hazard or explosion.
- Do not store or use gasoline or any other flammable vapors and liquids in the vicinity of this or any other appliance.
- Unplug the appliance from the outlet before cleaning or performing any maintenance.
- Do not allow children to play in, on, or around the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Ensure proper disposal of the appliance in accordance with local regulations for refrigerants and flammable blowing gas.

Setup

Unpacking

Carefully remove all packaging materials. Keep the packaging materials until you are sure the product is fully

functional and undamaged. Inspect the appliance for any damage during transit. If any damage is found, contact your retailer immediately.

Placement

Place the wine cooler on a flat, solid surface strong enough to support the unit when fully loaded. Ensure there is adequate ventilation around the unit. Allow at least 5 inches (12.7 cm) of space on the back and sides of the appliance for proper air circulation. Avoid placing the unit in direct sunlight or near heat sources such as ovens, radiators, or heaters, as this will increase power consumption.



Image: Angled view of the ZOKOP JC-82 Wine Cooler, showcasing its compact design and glass door. This view helps in planning placement.





Image: Front view of the ZOKOP JC-82 Wine Cooler, showing the full glass door and internal shelving for wine bottles. This image is useful for understanding the unit's footprint.

Power Connection

Before plugging in the appliance, ensure the voltage and frequency indicated on the rating label match your household power supply. Plug the appliance into a dedicated, grounded wall outlet. Do not use extension cords or ungrounded adapters.

Operating Instructions

Control Panel

The wine cooler features a touch control panel located on the top of the door frame. This panel allows you to adjust temperature, control the internal light, and lock/unlock the settings.




Image: Close-up view of the touch control panel, showing the LED light button, temperature display, temperature control buttons (up/down), and lock/unlock button. This image clarifies the function of each button.

Temperature Adjustment

The operating temperature range for this wine cooler is 41°F to 64°F (5°C to 18°C). Use the temperature control buttons (up/down arrows) on the touch panel to set your desired temperature. The digital display will show the current temperature setting.



Image: The ZOKOP JC-82 Wine Cooler displaying wine bottles and showing the digital temperature reading of 64°F on its control panel. This illustrates the temperature display in operation.

Recommended temperature settings for different wine types:

- **Champagne & Sparkling Red Wine:** 41-48°F (5-9°C)
- **White Wine:** 48-57°F (9-14°C)
- **Semi-Sweet & Sweet Red Wine:** 57-61°F (14-16°C)
- **Beers & Sodas:** 41-64°F (5-18°C)



Image: A visual guide illustrating recommended temperature ranges for various types of beverages, including Champagne, White Wine, Semi-Sweet & Sweet Red Wine, and Beers & Sodas, within the 41°F to 64°F range of the ZOKOP JC-82.

Internal Lighting

The wine cooler is equipped with an energy-saving LED soft light. Press the light bulb icon on the control panel to turn the internal light on or off. This allows you to view your collection without disturbing the wine.

Removable Shelves

The unit features durable chrome-plated metal shelves that can be rearranged to accommodate bottles of different sizes. To remove a shelf, gently pull it forward until it stops, then lift the front edge and slide it out. To reinsert, align the shelf with the rails and push it back until it is securely in place.




Image: A composite image highlighting key features: removable shelves for flexible storage, LED soft light for gentle illumination, and an air-tight seal ensuring constant temperature and humidity for optimal wine preservation.

Maintenance

Cleaning

- Always unplug the appliance before cleaning.
- Clean the interior with a soft cloth and a mild detergent solution. Avoid abrasive cleaners or solvents.
- Wipe the exterior with a soft, damp cloth.
- Clean the door gasket regularly to ensure a proper seal.
- Dust the condenser coils at the back of the unit periodically to maintain efficiency.

Defrosting

The appliance is designed with an automatic defrost system. Frost will melt and drain into a drip tray at the back of the unit, where it evaporates. No manual defrosting is typically required.

Troubleshooting

Before contacting customer service, please check the following common issues and solutions:

Problem	Possible Cause	Solution
Appliance does not operate	Not plugged in; Circuit breaker tripped; Temperature control set to OFF.	Ensure plug is secure; Reset circuit breaker; Set temperature control to desired setting.
Temperature is not cold enough	Door opened too frequently; Door not closed completely; Door gasket not sealing properly; Large quantity of warm items added; Unit located in a warm area; Temperature control set too high.	Minimize door openings; Ensure door is fully closed; Check gasket for damage; Allow time for new items to cool; Relocate unit; Lower temperature setting.
Vibrations	Appliance not level; Weak floor.	Adjust leveling legs; Ensure floor can support the unit.
Noise	Normal operating sounds (compressor, fan, refrigerant flow).	These sounds are normal. If noise is excessive or unusual, check for loose parts or contact support.

Specifications

Feature	Specification
Model	JC-82
Power Supply	115V / 60Hz
Amperage	1.2A
Capacity	28 Bottles / 2.8 Cubic Feet / 80 Liters
Adjustable Temperature Range	41-64°F (5-18°C)
Refrigerant	R600a/21g
Unit Dimensions (L x W x H)	16.93 x 17.72 x 33.07 inches (43 x 45 x 84 cm)
Net Weight	49.6 lbs (22.5 kg)
Certification	ETL Listing
Form Factor	Wine Cellar
Finish Type	Matte
Number of Shelves	Multiple (Removable Chrome Plated Metal)
Special Feature	Touch Control, LED Soft Light
Installation Type	Freestanding (Countertop, Tabletop)

Warranty and Support

This product comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, parts, or service inquiries, please contact the retailer or manufacturer's customer service department. Ensure you have your model number and purchase date available when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NDC4HPR

More documents and user manuals: **https://manuals.plus/**