Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO 2000W Infrared Heater

TRESKO 2000W Infrared Radiant Heater Instruction Manual

Model: 2000W Infrared Heater | Brand: TRESKO

1. Important Safety Information

Please read this instruction manual carefully before operating the appliance and keep it for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the heater is securely mounted before use.
- Do not cover the heater. Overheating can occur.
- Keep flammable materials at least 1 meter (3 feet) away from the heater.
- Do not operate the heater near water or in excessively damp conditions.
- Unplug the heater from the power outlet when not in use or before cleaning.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent, or similarly qualified persons in order to avoid a hazard.

2. Package Contents

Verify that all components are present and undamaged:

- TRESKO 2000W Infrared Radiant Heater
- Remote Control
- Wall Mounting Bracket
- Mounting Hardware (screws, anchors)
- Instruction Manual



Image 2.1: Overview of the TRESKO 2000W Infrared Radiant Heater, including the main unit, remote control, and wall mounting bracket.

3. Setup and Installation

The TRESKO Infrared Heater is designed for wall mounting. Ensure the mounting surface is sturdy and can support the weight of the heater (approximately 3 kg).

3.1 Dimensions



Image 3.1: Product dimensions for installation planning. The heater measures 63 cm in length, 16.5 cm in width, and 10.5 cm in height.

3.2 Wall Mounting Steps

1. **Choose Location:** Select a suitable wall location, ensuring sufficient clearance from ceilings, walls, and flammable materials. The heater can be used both indoors and outdoors.
2. **Mark Drilling Points:** Hold the wall mounting bracket against the wall at the desired height and mark the drilling points for the screws.
3. **Drill Holes:** Drill holes at the marked points using an appropriate drill bit. Insert wall anchors if necessary.
4. **Attach Bracket:** Securely fasten the wall mounting bracket to the wall using the provided screws.
5. **Mount Heater:** Carefully attach the heater to the bracket. Ensure it is firmly seated and stable. The bracket allows for an adjustable tilt angle.
6. **Connect Power:** Plug the power cord into a suitable 220V electrical outlet.



Image 3.2: Visual guide for wall mounting, highlighting the bracket and secure attachment.

4. Operating Instructions

The TRESKO Infrared Heater features 3 power levels and is operated via the included remote control.

4.1 Remote Control Functions



Image 4.1: The remote control allows selection of three power levels and power on/off.

- **Power Button ( ):** Press to turn the heater ON or OFF.
- **750W Button:** Selects the low heat setting (750 Watts).
- **1500W Button:** Selects the medium heat setting (1500 Watts).
- **2000W Button:** Selects the high heat setting (2000 Watts).

4.2 Initial Operation

1. Ensure the heater is properly installed and plugged into a power source.
2. Point the remote control towards the heater's receiver.
3. Press the Power button ( ) to turn on the heater. The heater will begin to emit heat almost instantly.
4. Select your desired power level (750W, 1500W, or 2000W) using the corresponding buttons on the remote.
5. To turn off the heater, press the Power button ( ) again.

5. Maintenance

Regular maintenance ensures optimal performance and longevity of your heater.

5.1 Cleaning

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior casing with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Do not immerse the heater in water or any other liquid.
- Periodically check the protective grille for dust or debris and gently clean with a soft brush or vacuum cleaner.

5.2 Storage

When not in use for extended periods, store the heater in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

6. Troubleshooting

If you encounter issues with your heater, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Remote control battery depleted.	Check if the power cord is securely plugged in. Check the circuit breaker. Replace remote control batteries.
Heater turns off unexpectedly.	Overheating protection activated.	Unplug the heater and allow it to cool for 30 minutes. Ensure there are no obstructions blocking airflow.
Heat output is low.	Incorrect power level selected.	Ensure the desired power level (e.g., 2000W) is selected on the remote control.

If the problem persists after attempting these solutions, please contact customer support.

7. Specifications

Brand:	TRESKO
Model:	2000W Infrared Heater
Color:	Silver
Product Dimensions (L x W x H):	63 x 16.5 x 10.5 cm
Item Weight:	3 Kilograms
Power:	2000 Watts (3 levels: 750W, 1500W, 2000W)
Voltage:	220 Volts
Automatic Shut-off Function:	Yes
Special Feature:	Energy Efficiency

Indoor/Outdoor Use:	Outdoor (also suitable for specific indoor applications like workshops)
Power Source:	Electric Cord
Heating Method:	Radiant
Mounting Type:	Wall Mount

8. Warranty and Support

The manufacturer provides a 2-year availability for spare parts. For any questions, technical support, or warranty claims, please refer to your purchase documentation or contact the seller directly.

For further assistance, you may visit the TRESKO brand page on Amazon.

© 2023 TRESKO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09NGYJJ1P

More documents and user manuals: **https://manuals.plus/**