Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

RECARO 89046260050

Recaro Kids Tian Pro Car Seat Instruction Manual

Model: 89046260050

Introduction

This manual provides essential information for the safe and correct use of your Recaro Kids Tian Pro car seat. The Tian Pro is designed for children from approximately 9 months to 12 years old, covering weight groups 1-2-3 (9-36 kg). It features the HERO safety system, adjustable backrest and headrest, and offers universal installation options.
Please read these instructions carefully before installing and using the car seat. Keep this manual in a safe place for future reference.

Safety Information

- Always ensure the car seat is correctly installed and secured in the vehicle according to these instructions.
- Never leave a child unattended in the car seat.
- Ensure the child's harness is snug and correctly adjusted, with no twists. The patented HERO safety system helps prevent twisting and slipping.
- Do not use the car seat if it has been involved in an accident, even if there is no visible damage. Internal damage may compromise safety.
- Regularly check all parts for wear and tear. Replace the car seat if any components are damaged.
- The car seat is designed for forward-facing use only for children in Group 1 (9-18 kg) with the integrated harness, and Group 2/3 (15-36 kg) using the vehicle's 3-point seat belt.
- The integrated Seatfix connectors for Group 2/3 are optional and provide additional stability, but the primary restraint is the vehicle's seat belt.

Setup and Installation

The Recaro Kids Tian Pro car seat offers universal installation using the vehicle's 3-point seat belt. For Group 2/3, optional Seatfix connectors can be used for enhanced stability.

Installation with Vehicle Seat Belt (Groups 1, 2, 3)

1. Place the car seat firmly on the vehicle's seat.
2. For Group 1 (9-18 kg), ensure the integrated 5-point harness is correctly adjusted to your child's height.
3. Route the vehicle's 3-point seat belt through the designated guides on the car seat. Ensure the lap belt is low across the child's hips and the shoulder belt rests across the child's shoulder and chest, not on the neck.

4. Pull the vehicle seat belt tight to remove any slack, ensuring the car seat is securely fastened.
5. For Group 2/3 (15-36 kg), the integrated harness is no longer used. Store it safely according to the instructions. The child is secured directly by the vehicle's 3-point seat belt.



Image: The Recaro Kids Tian Pro car seat, illustrating its universal installation capability using the vehicle's seat belt. The image shows the car seat ready for installation.

Optional Seatfix Connectors (Groups 2, 3)

- Locate the Seatfix connectors at the base of the car seat.
- Extend the connectors and attach them to the ISOFIX anchor points in your vehicle. Listen for a click to confirm secure attachment.
- Push the car seat firmly against the vehicle's backrest to ensure a tight fit.
- Even with Seatfix connected, the child must always be secured with the vehicle's 3-point seat belt in Group 2/3.

Operating Instructions

Adjusting for Child Growth

The Tian Pro car seat is designed to grow with your child, from approximately 9 months to 12 years. The backrest, headrest, and integrated harness (for Group 1) can be adjusted simultaneously with one hand.

1. Locate the adjustment lever, typically at the top or back of the headrest.
2. Squeeze the lever and raise or lower the headrest and backrest until the shoulder straps (for Group 1) are at or just below your child's shoulders. For Group 2/3, ensure the headrest supports the child's head and the vehicle seat belt passes correctly over the shoulder.
3. Release the lever to lock the headrest in position.



Image: A visual comparison of the Recaro Kids Tian Pro car seat, demonstrating its adaptability to a growing child. The left image shows the seat in a smaller configuration, while the right shows it extended for an older child.

HERO Safety System

The patented HERO safety system integrates shoulder pads, shoulder straps, and the headrest into a single unit. This design prevents the harness from twisting or slipping, ensuring optimal safety and comfort for your child.



Image: A detailed view of the Recaro Kids Tian Pro car seat's patented HERO safety system, highlighting the integrated shoulder pads and harness designed to prevent twisting and slipping.

Air Ventilation System

The car seat features an air ventilation system to ensure continuous air circulation, enhancing your child's comfort during travel, especially on longer journeys.



Image: A side profile of the Recaro Kids Tian Pro car seat, illustrating the integrated air ventilation system with arrows indicating airflow for continuous circulation.

Smart Protection Wings

The smart protection wings automatically adapt to suit the growing child, providing optimal side impact protection throughout the car seat's usage period.



Image: A close-up view of the Recaro Kids Tian Pro car seat's smart protection wings, designed to automatically adjust and provide enhanced side protection as the child grows.

Maintenance

- **Cleaning the Covers:** The fabric covers are removable and washable. Refer to the care label attached to the covers for specific washing instructions (e.g., machine wash cold, delicate cycle). Do not tumble dry.
- **Cleaning the Frame:** Wipe plastic and metal parts with a damp cloth and mild soap. Do not use abrasive cleaners or solvents.
- **Inspection:** Regularly inspect the car seat for any signs of damage, wear, or loose parts. Pay close attention to the harness, buckles, and seat belt guides.
- **Storage:** When not in use, store the car seat in a clean, dry place away from direct sunlight and extreme temperatures.

Troubleshooting

- **Car seat feels loose after installation:**

  Ensure the vehicle's seat belt is pulled tight and all slack is removed. For Group 2/3, if using Seatfix, ensure connectors are fully engaged and the seat is pushed firmly against the vehicle's backrest.

- **Harness is difficult to adjust or twists:**

  Check that the harness straps are not caught or tangled behind the seat. Ensure the HERO safety system components (shoulder pads, straps, headrest) are aligned. If twisting persists, remove the child and re-thread the harness carefully.

- **Child seems uncomfortable:**

  Verify that the headrest and harness (or vehicle seat belt for Group 2/3) are adjusted to the correct height for your child. Ensure clothing is not bulky and the child is not overheating (utilize the air ventilation system).

Specifications

Model Number	89046260050
Recommended Minimum Weight	9 Kilograms
Recommended Maximum Weight	36 Kilograms
Main Material	Foam
Cover Composition	100% Polyester
Special Features	ISOFIX (optional for Group 2/3), HERO Safety System, Air Ventilation System, Smart Protection Wings
Product Dimensions (L x W x H)	64.5 x 46 x 43.5 cm
Item Weight	7.3 Kilograms
Installation Type	Vehicle Seat Belt (Universal)
Color	Simply Grey

Note: The maximum weight capacity for Group 3 car seats is typically 36 kg. The specification "10100 Grams" from the source data is interpreted as 10.1 kg, which is inconsistent with Group 3. We assume the standard 36 kg for Group 3 based on the product description.

Warranty and Support

For warranty information, product registration, or technical support, please visit the official RECARO website or contact their customer service department. Details can typically be found on the product packaging or the official RECARO website.
Official Website: www.recaro-kids.com (This is a general link, specific regional sites may vary)

© 2023 RECARO. All rights reserved.
This manual is for informational purposes only. Always refer to the physical product manual for the most accurate and up-to-date instructions.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09Q6F47HX

More documents and user manuals: **https://manuals.plus/**