Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Anova Culinary ANHV01-US00

Anova Culinary Precision Port Handheld Vacuum Sealer User Manual

Model: ANHV01-US00

Introduction

The Anova Precision Port Handheld Vacuum Sealer is a compact and cordless solution designed for sous vide cooking, general food storage, and meal preparation. This device features a USB rechargeable battery, offering up to 150 seals per charge. Its Precision Port airway simplifies the sealing process, requiring users to align the valve, apply pressure, and activate with a single button. The system is compatible with Anova Precision Port Vacuum Bags, which are durable, resealable, and reusable for various mild, non-messy foods.



Image: The Anova Precision Port Handheld Vacuum Sealer shown with various vacuum-sealed food items, highlighting its compact design and application in food preservation.

Setup

1. **Unboxing and Initial Charge:** Remove the vacuum sealer and included accessories from the packaging. Before first use, fully charge the device using the provided USB cable. The battery indicator light will show charging

status. A full charge provides up to 150 seals.

2. **Familiarize with Components:** Identify the vacuum sealer unit, the Precision Port suction valve on the bottom, and the power/start button on top.
3. **Prepare Vacuum Bags:** Ensure you are using Anova Precision Port Vacuum Bags. These bags feature a circular valve designed to work with the sealer.



Image: The Anova Precision Port Handheld Vacuum Sealer displayed alongside a set of starter Precision Port Vacuum Bags, illustrating the included accessories.

Operating Instructions

Sealing Food Items

1. **Place Food in Bag:** Insert the food item into an Anova Precision Port Vacuum Bag. Ensure the food does not extend beyond the fill line and that the area around the circular valve is clean and dry.
2. **Close Zipper Seal:** Firmly close the zipper seal of the bag, ensuring it is completely sealed across the entire

width.

3. **Position Sealer:** Place the Precision Port Handheld Vacuum Sealer directly over the circular valve on the bag. Apply gentle downward pressure to ensure a good seal between the sealer and the bag valve.
4. **Start Sealing:** Press the power/start button on top of the sealer. The device will begin to extract air from the bag. Hold the sealer in place until the air extraction stops automatically, indicating a complete vacuum seal.
5. **Remove Sealer:** Once sealing is complete, lift the sealer from the bag. The bag is now vacuum-sealed and ready for storage or cooking.



Image: The Anova Precision Port Handheld Vacuum Sealer actively sealing an avocado in a vacuum bag, demonstrating the sealing process.

Re-sealing and Storage

- To open a sealed bag, simply pull apart the easy-zip top.
- To re-seal, ensure the zipper top is clean and dry, then close it firmly. Repeat the sealing process by placing the sealer over the valve and pressing the button.
- Vacuum sealing extends the shelf life of various foods, including meats, vegetables, cheeses, grains, and coffee.



Image: Various vacuum-sealed food items, including fish and vegetables, neatly stored in a refrigerator, illustrating the benefit of extended shelf life.

Maintenance

Cleaning the Vacuum Base

The Anova Precision Port Handheld Vacuum Sealer is designed to prevent liquids from entering the pump when sealing moist foods. However, if liquids do find their way inside, the vacuum base is removable for cleaning.

1. **Remove Base:** Gently twist and pull the vacuum base from the main unit.
2. **Clean:** Wash the removable base with warm, soapy water. Rinse thoroughly and ensure it is completely dry before reattaching.
3. **Reattach Base:** Align the base with the main unit and twist until securely in place.

General Cleaning

- Wipe the exterior of the sealer with a damp cloth. Do not immerse the main unit in water.
- Ensure the circular valve on the vacuum bags is clean and free of food debris before sealing to ensure an effective vacuum.

Battery Care

- Charge the device regularly, especially if it will be stored for an extended period, to maintain battery health.
- Use only the provided USB cable or a compatible charger.

Troubleshooting

Problem	Possible Cause	Solution
Sealer does not turn on or operate.	Low battery.	Charge the device using the USB cable until fully charged.
Poor vacuum seal or air leaks back into the bag.	• Zipper seal not fully closed. • Food debris or moisture on the bag's valve or zipper. • Sealer not properly aligned or pressed firmly on the valve. • Bag is damaged or not an Anova Precision Port Vacuum Bag.	• Ensure the zipper seal is completely closed. • Clean the bag's valve and zipper area thoroughly. • Re-position the sealer and apply firm, even pressure. • Inspect the bag for punctures or tears. Use only Anova Precision Port Vacuum Bags.
Liquid observed inside the vacuum base.	Sealing moist foods without proper care.	Remove and clean the vacuum base as described in the Maintenance section. Ensure the base is completely dry before reattaching.

Specifications

Brand: Anova Culinary

Model Number: ANHV01-US00

Material: Plastic

Color: Black

Product Dimensions (L x W x H):3.03" x 3.03" x 3.7"

Item Weight: 0.76 kg

Power Source: Battery Powered (Lithium-ion, USB rechargeable)

Operation Mode: Manual

Wattage: 150 watts

Included Components: 1 vacuum sealer, 10 reusable bags

UPC: 850026926095

Warranty Information

The Anova Culinary Precision Port Handheld Vacuum Sealer comes with a**2-year manufacturer's warranty**.

This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims. For specific terms and conditions, refer to the warranty documentation included with your product or visit the official Anova Culinary website.

Customer Support

For further assistance, technical support, or to inquire about replacement parts and accessories, please contact Anova Culinary customer service.

Online Support: Visit the official Anova Culinary website for FAQs, support articles, and contact forms.

Website: www.anovaculinary.com

Store Link: Anova Culinary Amazon Store

When contacting support, please have your product model number (ANHV01-US00) and proof of purchase readily available.

© 2023 Anova Culinary. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09R34V8P8

More documents and user manuals: **https://manuals.plus/**