Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone PP9948ST

Paladone Stranger Things VHS Logo Light User Manual

Model: PP9948ST

1. Overview

The Paladone Stranger Things VHS Logo Light is a decorative desk light designed to resemble a classic VHS tape. It features the iconic Stranger Things logo and emits a red light, creating a nostalgic atmosphere. This light is officially licensed merchandise and is suitable for indoor use.



Image: The Stranger Things VHS Logo Light, illuminated in red.



Image: The Stranger Things VHS Logo Light, unlit, showing its VHS tape design.

2. Package Contents

- 1 x Paladone Stranger Things VHS Logo Light
- 1 x Micro USB Power Cable

Note: 3x AAA batteries are required for battery operation and are not included in the package.

3. Powering the Device

The Stranger Things VHS Logo Light can be powered by two methods:

1. **USB Power:** Connect the included Micro USB cable to the light and plug the other end into a compatible USB power source (e.g., computer, USB wall adapter - not included).
2. **Battery Power:** Insert 3x AAA batteries (not included) into the designated battery compartment. Ensure correct polarity (+/-).

Choose the power method that best suits your needs. The light is cordless when operating on battery power.

4. Operation

The light features a simple touch-sensitive switch for operation.

1. **Turning On/Off:** Locate the touch switch, typically on the side or top of the unit. Gently touch or press the switch to turn the light on. Repeat the action to turn the light off.
2. **Light Modes:** The light emits a steady red glow. There are no multiple light modes.



Image: Close-up view of the light in operation, showing the red illumination.

▶ **Watch video online**
Stranger Things VHS Logo Light

Video: Demonstrates the Stranger Things VHS Logo Light turning on and off, showcasing its red glow and design.

5. Care and Maintenance

- **Cleaning:** Wipe the surface with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- **Storage:** Store the light in a cool, dry place when not in use. If storing for extended periods, remove batteries to prevent leakage.
- **Water Resistance:** This product is not waterproof. Avoid exposure to water or high humidity.

6. Troubleshooting

- **Light does not turn on:**
  - Check if the USB cable is securely connected to both the light and the power source.
  - If using batteries, ensure they are inserted correctly with the right polarity and are not depleted. Replace with fresh AAA batteries if necessary.
  - Try a different power source or USB cable.
- **Light is dim:**
  - If using batteries, they may be low. Replace with fresh AAA batteries.
  - Ensure the USB power source provides sufficient power (5 Volts).

7. Specifications

Model Number	PP9948ST
Brand	Paladone
Product Dimensions	1.38"D x 7.87"W x 4.65"H (approx. 3.5cm D x 20cm W x 11.8cm H)

Item Weight	0.035 ounces (approx. 1 gram)
Material	Plastic
Light Source Type	LED
Light Color	Red
Power Source	Battery Powered (3x AAA, not included) or Micro USB (cable included)
Voltage	5 Volts
Wattage	1 Watt
Switch Type	Touch
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant



Image: Product dimensions showing width and height measurements.

8. Safety Information

- This product is not a toy. Keep out of reach of small children.
- Do not attempt to disassemble or modify the light.
- Use only the specified power sources (Micro USB or AAA batteries).
- Avoid dropping or subjecting the light to strong impacts.
- Dispose of batteries responsibly according to local regulations.

9. Manufacturer Contact

For further assistance or inquiries, please contact Paladone Products Ltd. Refer to the product packaging or the official Paladone website for the most current contact information.
Brand: Paladone
Manufacturer: Paladone Products Ltd

© 2024 Paladone Products Ltd. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RKTL8QZ

More documents and user manuals: **https://manuals.plus/**