Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Paladone PP10211PS

Paladone PlayStation Glitter Flow Lamp Instruction Manual

Model: PP10211PS

1. Introduction

Thank you for purchasing the Paladone PlayStation Glitter Flow Lamp. This mood light is designed to enhance your gaming space or bedroom with its unique glitter flow effect and iconic PlayStation symbols. Please read this manual carefully before use to ensure proper setup and operation.

2. Important Safety Information

- This product is intended for indoor use only.
- Keep the lamp on a stable, flat surface to prevent tipping.
- Do not attempt to open or modify the lamp. Contains liquid that should not be ingested.
- Ensure the power source (batteries or USB cable) is correctly connected according to instructions.
- The lamp may become warm during operation. Avoid prolonged direct contact with the glass cylinder.
- Keep out of reach of small children and pets.

3. Package Contents

Please verify that all components are present:

- Paladone PlayStation Glitter Flow Lamp Unit
- USB Power Cable (Note: 3 AAA batteries are not included if using battery power)

4. Setup Instructions

1. **Unpack the Lamp:** Carefully remove all components from the packaging.
2. **Choose a Power Source:**
    - **USB Power:** Connect the provided USB power cable to the lamp's power port and plug the other end into a compatible USB power adapter (not included) or a powered USB port.

- **Battery Power:** Locate the battery compartment on the base of the lamp. Insert 3 AAA batteries (not included), ensuring correct polarity. Close the battery compartment securely.

3. **Placement:** Place the lamp on a flat, stable surface away from direct sunlight, extreme temperatures, or areas where it could be easily knocked over.



Figure 1: The Paladone PlayStation Glitter Flow Lamp. The lamp features a black base with the PlayStation logo and a clear cylinder filled with glitter and liquid.



Figure 2: Dimensions of the PlayStation Glitter Flow Lamp, measuring 33 cm (13 inches) in height. It can be powered by USB or 3 AAA batteries.

5. Operating Instructions

1. **Power On:** Locate the touch switch on the lamp's base. Tap the switch to turn the lamp on.
2. **Glitter Flow Activation:** Upon activation, the internal light will illuminate, and the glitter will begin to circulate. It may take a few moments for the glitter to achieve its full flow effect.
3. **Power Off:** Tap the touch switch again to turn the lamp off.

▶ **Watch video online**
PlayStation Flow Lamp

Video 1: Official Paladone video demonstrating the PlayStation Flow Lamp in operation, showcasing the glitter movement and illumination.



Figure 3: A close-up view of the four floating PlayStation icons (triangle, circle, cross, square) within the glitter flow lamp.

6. Care and Maintenance

- **Cleaning:** Wipe the exterior of the lamp with a soft, dry cloth. Do not use abrasive cleaners or immerse the lamp in water.
- **Storage:** When not in use for extended periods, store the lamp in a cool, dry place.
- **Battery Replacement:** If using batteries, replace them when the light dims or the glitter flow becomes sluggish.

7. Troubleshooting

Issue	Possible Cause	Solution
Lamp does not turn on.	No power or depleted batteries.	Ensure USB cable is securely connected to a powered source, or replace batteries with fresh ones.

Issue	Possible Cause	Solution
Glitter is not flowing.	Lamp is not warm enough.	Allow the lamp to operate for a period (up to an hour) to reach optimal operating temperature for glitter movement.
Liquid appears cloudy or discolored.	Exposure to extreme temperatures or improper storage.	Ensure the lamp is stored and operated within recommended temperature ranges. If the issue persists, contact customer support.

8. Product Specifications

Feature	Detail
Brand	Paladone
Model Name	Paladone PlayStation Glitter Flow Lamp Night Light
Model Number	PP10211PS
Dimensions	3.54"D x 3.54"W x 13.78"H (approx. 33 cm tall)
Item Weight	1.96 pounds (0.89 Kilograms)
Material	Plastic
Power Source	Battery Powered (3 AAA batteries, not included) or USB Cable (included)
Light Source Type	LED
Control Method	Touch Switch
Indoor/Outdoor Usage	Indoor

9. Warranty and Support

For warranty information or technical support, please refer to the packaging or contact Paladone customer service directly. Contact details can typically be found on the product packaging or the official Paladone website.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09RLQ5YJP

More documents and user manuals: **https://manuals.plus/**