Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Geepas GRH28532UK

Geepas 1500W Oil Filled Radiator Heater GRH28532UK User Manual

Model: GRH28532UK

Introduction

Thank you for choosing the Geepas 1500W Oil Filled Radiator Heater. This manual provides important information regarding the safe operation, installation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.



Image 1: Geepas 1500W Oil Filled Radiator Heater. This image shows the complete radiator heater with its 7 fins, control panel, and castor wheels, positioned in a room.

Important Safety Instructions

When using electrical appliances, basic precautions should always be followed to reduce the risk of fire, electric shock, and injury to persons, including the following:

- Read all instructions before using this heater.
- This heater is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Always unplug the heater when not in use.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors.
- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To disconnect heater, turn controls to OFF, then remove plug from outlet.

- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- This heater has an internal overheat safety cut-off feature. If the heater overheats, it will automatically shut off.
- The heater is equipped with a tip-over switch that automatically shuts off the unit if it is accidentally knocked over.



Image 2: Overheat Safety Cut-Off. This image illustrates the internal safety mechanism that automatically shuts off the heater if it reaches an unsafe temperature.



Image 3: Safety Tip-Over Switch. This image demonstrates the safety feature that automatically turns off the heater if it is accidentally knocked over.

Product Overview

The Geepas Oil Filled Radiator Heater is designed for efficient indoor heating. It features 7 heating fins, multiple power settings, and an adjustable thermostat for optimal comfort.

Components and Controls:

- **Power Selector Dial:** Allows selection of different heat output levels (600W, 900W, 1500W).
- **Thermostat Control Dial:** Adjusts the desired room temperature.
- **Power Indicator Light:** Illuminates when the heater is operating.
- **7 Heating Fins:** Efficiently radiate heat into the room.
- **Castor Wheels:** For easy portability.
- **Integrated Handle:** For convenient movement.
- **Cord Storage:** Keeps the power cord tidy when not in use.



Image 4: 3 Power Settings. This image highlights the power selector dial, allowing users to choose between 600W, 900W, and 1500W heat outputs.



Image 5: Adjustable Temperature Thermostat. This image focuses on the thermostat dial, which enables precise control over the desired room temperature.

Setup

Unpacking:

1. Carefully remove the heater from its packaging.
2. Check for any signs of damage. If the heater appears damaged, do not use it and contact customer support.
3. Ensure all packing materials are removed before use.

Attaching the Castor Wheels:

The heater comes with castor wheels for mobility. These may need to be attached before first use.

1. Turn the heater upside down carefully, ensuring it is stable.
2. Locate the wheel mounting brackets at the bottom of the heater.
3. Insert the castor wheel assemblies into the designated slots.

4. Secure the wheels firmly using the provided wing nuts or fasteners.
5. Return the heater to an upright position.



Image 6: Built-in Handle and Castor Wheels. This image shows the integrated handle for lifting and the castor wheels for easy movement of the heater.

Placement:

- Place the heater on a firm, level surface.
- Ensure there is at least 1 meter (3 feet) of clear space around the heater from walls, furniture, curtains, and other combustible materials.
- Do not place the heater directly below a power outlet.
- This heater is intended for indoor use only.

Operating Instructions

Powering On:

1. Ensure the heater is placed safely and the power selector dial is in the 'OFF' position.
2. Plug the power cord into a suitable electrical outlet (AC 220-240V, 50/60Hz).

Setting Heat Output:

1. Turn the power selector dial to your desired heat setting:
    - **I (Low):** 600W
    - **II (Medium):** 900W
    - **III (High):** 1500W
2. The power indicator light will illuminate, indicating the heater is active.

Adjusting the Thermostat:

1. Turn the thermostat control dial clockwise to increase the desired temperature, or counter-clockwise to decrease it.
2. For initial use, set the thermostat to its maximum position. Once the room reaches a comfortable temperature, slowly turn the thermostat dial counter-clockwise until the heater switches off. The heater will now maintain this temperature by cycling on and off automatically.

Powering Off:

1. Turn the power selector dial to the 'OFF' position.
2. Unplug the heater from the electrical outlet.

Maintenance

Cleaning:

- Always unplug the heater and allow it to cool completely before cleaning.
- Wipe the exterior surfaces of the heater with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Do not immerse the heater in water or allow water to drip into the interior of the heater.
- Ensure the heater is completely dry before plugging it back in.

Oil Maintenance:

This oil-filled radiator uses environmentally friendly oil that never needs to be bled or topped up. No special oil maintenance is required.



Image 7: Environmentally Friendly Oil. This image highlights that the heater's oil is sealed and requires no maintenance.

Storage:

- When not in use, store the heater in a cool, dry place.
- Use the integrated cord storage to keep the power cord neatly wrapped.
- If possible, store the heater in its original packaging to protect it from dust and damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Heater does not turn on.	No power supply. Power selector is OFF. Overheat protection activated. Tip-over switch activated.	Check if the plug is securely in the outlet. Ensure the power selector is set to I, II, or III. Unplug, let cool for 30 minutes, then restart. Ensure the heater is upright on a flat surface.

Problem	Possible Cause	Solution
Heater is on but not heating.	Thermostat set too low. Room temperature already reached.	Increase the thermostat setting. The heater will cycle on when the temperature drops.
Heater makes unusual noises.	Normal expansion/contraction of metal. Loose components.	Minor clicking sounds are normal during heating/cooling. If noises are loud or persistent, discontinue use and contact support.

Specifications

- **Model Number:** GRH28532UK
- **Power Output:** 1500W (Max)
- **Power Settings:** 600W / 900W / 1500W
- **Number of Fins:** 7
- **Heating Method:** Convection
- **Power Source:** AC
- **Voltage:** 220-240V, 50/60Hz
- **Product Dimensions:** Approximately 33 x 24 x 60 cm (L x W x H)
- **Item Weight:** Approximately 6.5 kg
- **Form Factor:** Pedestal
- **Color:** White
- **Special Features:** Adjustable Temperature, Energy Efficient, Overheat Protection, Tip-Over Protection
- **Indoor/Outdoor Use:** Indoor

Warranty and Support

This Geepas Oil Filled Radiator Heater comes with a**2-year warranty** from the date of purchase. Please retain your proof of purchase for warranty claims.
The warranty covers manufacturing defects and faults under normal use. It does not cover damage caused by misuse, neglect, accident, unauthorized modification, or normal wear and tear.
For technical support, warranty claims, or spare parts, please contact Geepas customer service through their official website or the retailer where the product was purchased. Please have your model number (GRH28532UK) and proof of purchase ready.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09SBDT7GL

More documents and user manuals: **https://manuals.plus/**