Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

UPBRIGHT S018-1B262060HU

UpBright 26.2V AC Adapter for Bissell PowerEdge 2900 Series Vacuum Charger Manual

Model: S018-1B262060HU | Brand: UPBRIGHT

1. Introduction

This manual provides instructions for the safe and effective use of your UpBright 26.2V AC Adapter, designed for compatibility with Bissell PowerEdge 2900, 2900A, and 2900N series cordless stick vacuums. Please read this manual thoroughly before use and retain it for future reference.



Image 1.1: The UpBright AC Adapter and its compatible Bissell PowerEdge 2900A vacuum, shown with product packaging.

2. Safety Information

To ensure safe operation and prevent damage, observe the following safety precautions:

- **Voltage Compatibility:** This adapter supports a worldwide input voltage range of 100-240VAC, 50/60Hz. Ensure your power outlet matches these specifications.
- **Protection Features:** The adapter includes Over Voltage Protection (OVP), Over Current Protection (OCP), and Short Circuit Protection (SCP) to safeguard your device.
- **Model Verification:** Always verify that your Bissell vacuum model (e.g., 2900, 2900A, 2900N) and part number match the compatibility listed for this adapter.
- **Battery Voltage Note:** The 21.6V specification refers to the vacuum's battery voltage, *not* the charger's output voltage. The charger provides 26.2V.
- **Indoor Use Only:** This adapter is intended for indoor use in dry conditions. Do not expose to moisture or extreme temperatures.
- **Unplug When Not in Use:** Disconnect the adapter from the power outlet when not charging or during electrical storms.

3. Package Contents

Carefully unpack the box and ensure all items are present:

- 2 x UpBright 26.2V AC Adapter

4. Setup Instructions

Follow these steps to set up your AC adapter:

1. **Unpack the Adapter:** Remove the AC adapter from its packaging.
2. **Inspect for Damage:** Check the adapter and its cable for any visible signs of damage. Do not use if damaged.
3. **Locate Charging Port:** Identify the charging port on your Bissell PowerEdge cordless stick vacuum.
4. **Connect to Power Outlet:** Plug the AC adapter into a standard wall power outlet (100-240VAC).
5. **Connect to Vacuum:** Insert the barrel connector of the adapter firmly into the charging port of your vacuum.



Image 4.1: The UpBright 26.2V AC Adapter, showing the main unit and its barrel connector.

5. Operating Instructions

Once connected, the adapter will begin charging your Bissell PowerEdge vacuum's battery. Refer to your vacuum's instruction manual for specific charging indicators and expected charging times.

Important Note: The voltage printed on your vacuum's battery (e.g., 21.6V) indicates the battery's nominal voltage, not the required input voltage for the charger. This UpBright adapter provides the correct 26.2V output for charging the compatible Bissell PowerEdge 2900 series vacuums.

6. Maintenance

Proper maintenance ensures the longevity and performance of your AC adapter:

- **Cleaning:** Use a dry, soft cloth to wipe the adapter. Do not use liquid cleaners or solvents.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or crimping the power cord excessively. Do not place heavy objects on the cord.
- **Disconnection:** Always pull the plug, not the cable, when disconnecting from the wall outlet or the vacuum.

7. Troubleshooting

If you encounter issues with your AC adapter, consider the following:

- **No Power/Charging:**
  - Ensure the adapter is securely plugged into both the wall outlet and the vacuum.
  - Test the wall outlet with another device to confirm it is functional.
  - Inspect the adapter cable and connector for any damage.
- **Vacuum Not Holding Charge:**
  - Rechargeable batteries have a limited lifespan, typically 1 to 3 years. If the vacuum's battery is old or dead, it may not accept a charge, which is not an issue with the charger itself.
  - To determine if the charger is working, a voltmeter can be used to check its output voltage.
- **Overheating:** If the adapter feels excessively hot, unplug it immediately and discontinue use. Contact support if the issue persists.

8. Specifications

Feature	Specification
Model Number	S018-1B262060HU
Input Voltage	100-240VAC, 50/60Hz
Output Voltage	26.2V DC
Output Current	0.6A (600mA)
Connector Type	Barrel Connector
Compatible Devices	Bissell PowerEdge 2900, 2900A, 2900N Series Cordless Stick Vacuums
Product Dimensions	3 x 3 x 1 inches
Item Weight	4 ounces
Special Features	OVP, OCP, SCP Protection

9. Warranty and Support

UpBright products are backed by a commitment to quality:

- **Refund Policy:** Enjoy a 30-day refund period from the date of purchase.
- **Exchange Policy:** The product is covered by a 24-month exchange warranty.

For technical support or warranty claims, please refer to the contact information provided with your purchase or visit the official UpBright website.



Image 9.1: Example of international plug adapters and a product warranty certificate, indicating global compatibility and support.

© 2026 UPBRIGHT. All rights reserved. Information in this manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09SHG9KGP

More documents and user manuals: **https://manuals.plus/**