Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dreo DR-HTF004S

Dreo Smart Tower Fan User Manual

Model: DR-HTF004S | Brand: Dreo

Introduction

The Dreo Smart Tower Fan (Model DR-HTF004S) is designed to provide efficient and quiet cooling for your home or office. Featuring smart control capabilities, multiple speed settings, and customizable oscillation, this fan offers a tailored cooling experience. Its bladeless design ensures safety and a modern aesthetic.

Included Components

- Pilot Max S Tower Fan Body
- Power Adapter
- Remote Control
- User Manual
- Quick Start Guide

Setup

The Dreo Pilot Max S Tower Fan features tool-free assembly for quick and easy setup.

1. Unpack all components from the box.
2. Attach the base to the main fan body. Ensure it clicks securely into place.
3. Place the fan on a stable, flat surface.
4. Connect the power adapter to the fan and plug it into a suitable power outlet.



Figure 1: The Dreo Pilot Max S Tower Fan, its remote control, and a smartphone displaying the control app. The fan is shown in its Starlight color.



Figure 2: Close-up of the Dreo Pilot Max S Tower Fan, its remote, and a smartphone demonstrating app control, highlighting the smart features.




Figure 3: Detailed dimensions of the Dreo Pilot Max S Tower Fan, showing its height, width, and depth for proper placement.

Operating Instructions

Control Panel & Remote

The fan can be operated using the touch-sensitive control panel on top of the unit or the included remote control. The remote provides full functionality from a distance.



Figure 4: Overhead view of the fan's control panel, showing touch buttons for various functions and a digital display.

Modes & Speeds

The Pilot Max S offers 12-speed settings and 4 distinct modes to suit various preferences and environments:

- **Normal Mode:** Provides a consistent airflow at your selected speed.
- **Natural Mode:** Simulates a natural breeze by varying fan speeds.

- **Sleep Mode:** Gradually reduces fan speed and dims the display for undisturbed sleep.
- **Auto Mode:** Automatically adjusts fan speed based on ambient room temperature.

Customizable oscillation angles (30°, 60°, 90°, 120°) ensure wide air distribution.




Figure 5: Visual representation of the fan's four wind modes (Sleep, Auto, Normal, Natural) and 12-speed settings.



Figure 6: Illustration of the fan's ultra-wide customizable oscillation, with options for 30°, 60°, 90°, and 120° horizontal movement.

Smart Features (App & Voice Control)

Control your fan remotely using the Dreo app on your smartphone or integrate it with Amazon Alexa and Google Assistant for voice commands. This allows for convenient operation from anywhere, scheduling, and advanced settings.



Figure 7: A smartphone screen showing the Dreo app interface for controlling the tower fan, including temperature and mode settings.

Maintenance

Regular cleaning ensures optimal performance and longevity of your Dreo Tower Fan. The fan is designed for easy cleaning.

1. Unplug the fan from the power outlet before cleaning.
2. Remove the rear grille by unscrewing it (if applicable, refer to the Quick Start Guide for specific instructions).
3. Wipe down the exterior surfaces with a soft, damp cloth.
4. Clean the fan blades and interior components using a soft brush or vacuum cleaner to remove dust buildup.
5. Ensure all parts are dry before reassembling and plugging in the fan.




Figure 8: A woman demonstrating the easy removal and cleaning of the fan's internal filter, emphasizing the tool-free maintenance.

Troubleshooting

If you encounter any issues with your Dreo Smart Tower Fan, please refer to the following common troubleshooting tips:

- **Fan not turning on:** Ensure the power adapter is securely plugged into both the fan and a working electrical

outlet. Check if the power button on the control panel or remote is pressed.

- **Weak airflow:** Verify that the fan grille and blades are clean and free from dust or obstructions. Increase the fan speed setting.
- **Unusual noise:** Check for any foreign objects caught in the fan blades or grille. Ensure the fan is placed on a stable, level surface to prevent vibrations.
- **App/Voice control issues:** Confirm that the fan is connected to your Wi-Fi network and that the Dreo app is updated to the latest version. Ensure your Alexa or Google Assistant device is properly linked to the Dreo account.

For further assistance, please contact Dreo customer support.

Specifications

Feature	Detail
Brand	Dreo
Model Name	DR-HTF004S
Color	Starlight
Product Dimensions	12.76"D x 12.76"W x 42.52"H
Item Weight	10.12 pounds
Power Source	DC
Wattage	36 watts
Noise Level	25 dB
Number of Power Levels	12
Control Method	App, Remote, Voice
Special Feature	Timer
Air Flow Capacity	1475 Cubic Feet Per Minute

Warranty & Support

The Dreo Smart Tower Fan comes with a **12-month default warranty**. This warranty can be extended up to **30 months** by registering your product.
For detailed warranty information, product registration, or technical support, please visit the official Dreo website or refer to the contact information provided in your Quick Start Guide.
You can also find the full user manual in PDF format here.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09STD4XJH

More documents and user manuals: **https://manuals.plus/**