Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Skullcandy S7PZZ-P917

Skullcandy Fat Stash 2 Portable Charger User Manual

Model: S7PZZ-P917 | Brand: Skullcandy

Introduction

The Skullcandy Fat Stash 2 Portable Charger is a high-capacity 10000mAh power bank designed to keep your devices charged on the go. With versatile charging options including a 20W USB-C fast charging port and two 18W USB-A charging ports, it provides reliable power for various electronic devices. This manual provides essential information for the safe and efficient use of your Fat Stash 2 Portable Charger.

What's in the Box

- Skullcandy Fat Stash 2 Portable Charger
- USB-A to Micro USB / Type-C Dual Charging Cable

Key Features

- **10000 mAh Battery Capacity:** Extends the life of your devices for up to 40 hours.
- **USB-C (Type-C) Power Delivery:** Provides faster Fat Stash recharge times (18W) and Fast Charging for compatible USB-C devices (20W).
- **Dual USB-A Outputs:** Two 18W USB-A ports deliver flexibility in charging multiple devices simultaneously.
- **Digital Battery Life Percentage Display:** Easily monitor the remaining power.
- **Included Dual Charging Cable:** Comes with a USB-A to dual Micro USB / USB-C splitter cable for convenience.





Image: Key features of the Skullcandy Fat Stash 2 Portable Charger, including its 10,000 mAh capacity, included dual charging cable, and digital battery display.

Setup Guide

Initial Charging of Your Power Bank

1. Locate the USB-C input port on your Fat Stash 2 Portable Charger.
2. Connect the included USB-A to USB-C end of the dual charging cable, or any compatible USB-C charging cable, to the power bank's USB-C input port.
3. Connect the other end of the cable to a USB power adapter (not included) or a powered USB port.
4. The digital display on the power bank will illuminate and show the charging percentage. Charge the power bank until it reaches 100% for optimal initial use.



Image: The Skullcandy Fat Stash 2 Portable Charger, ready for use after initial charging.

Operating Instructions

Charging Your Devices

1. Identify the appropriate charging port on your Fat Stash 2: USB-C (20W output) or USB-A (18W output).
2. Connect your device's charging cable to one of the available output ports on the power bank.
3. Connect the other end of the cable to your device.
4. The power bank will automatically begin charging your device. The digital display will show the remaining battery percentage of the power bank.

Checking Battery Level

To check the remaining battery percentage of your Fat Stash 2, simply press the power button located on the side of the unit. The digital display will show the current charge level.



Image: The side of the Skullcandy Fat Stash 2, illustrating the various charging ports for device connectivity.

Care and Maintenance

- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cleaning:** Use a soft, dry cloth to clean the surface of the power bank. Do not use harsh chemicals or abrasive materials.
- **Avoid Drops:** Protect the device from drops and impacts, which can damage internal components.
- **Water Exposure:** Keep the power bank away from water and liquids. It is not waterproof.
- **Charging Cycles:** For optimal battery life, fully charge and discharge the power bank at least once every three months if not in regular use.

Troubleshooting

Issue	Possible Cause	Solution
Power bank not charging	Cable not connected properly; faulty cable/adapter; power bank fully charged.	Ensure cable is securely connected. Try a different cable or power adapter. Check digital display for 100% charge.
Device not charging from power bank	Power bank battery low; incorrect cable/port; device not compatible.	Recharge the power bank. Ensure you are using the correct cable and port for your device. Verify device compatibility.
Digital display not working	Power bank is off; internal malfunction.	Press the power button to activate the display. If issue persists, contact customer support.

Technical Specifications

Feature	Detail
Product Dimensions	3 x 6 x 1 inches
Item Weight	8.8 ounces
Model Number	S7PZZ-P917
Battery Type	2 Lithium Polymer batteries (included)
Battery Capacity	10000 mAh
USB-C Output	20W Power Delivery
USB-A Outputs	2 x 18W
Connector Type	Micro USB, USB-C
Color	90s Vacation

Warranty and Customer Support

The Skullcandy Fat Stash 2 Portable Charger comes with a **1-year US warranty** from the date of purchase. This warranty covers manufacturing defects and ensures your product performs as expected under normal use.
For warranty claims, technical assistance, or any other inquiries, please contact Skullcandy Customer Support through their official website or the contact information provided with your product packaging. Please have your model number (S7PZZ-P917) and proof of purchase ready when contacting support.

© 2024 Skullcandy. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09T98PN7W

More documents and user manuals: **https://manuals.plus/**