Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Weehom B09TB3ZF1C

Weehom Metal Bed Frame Instruction Manual

Model: B09TB3ZF1C (Full Size, Black)

Introduction Safety Information Package Contents Assembly Operating Maintenance Troubleshooting Specifications Warranty & Support

1. Introduction

Thank you for purchasing the Weehom Metal Bed Frame. This manual provides detailed instructions for the safe assembly, operation, and maintenance of your new bed frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

2. Safety Information

- **Read all instructions:** Ensure you understand all steps before assembly.
- **Adult assembly required:** This product should be assembled by adults.
- **Keep children away:** Small parts may pose a choking hazard. Keep children and pets away during assembly.
- **Use on a level surface:** Assemble the bed frame on a soft, clean, and level surface to prevent scratches and ensure stability.
- **Tighten all fasteners:** Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as needed.
- **Do not exceed weight capacity:** The maximum weight capacity for this bed frame is 600 lbs.
- **No jumping:** Do not jump on the bed frame.
- **Proper mattress use:** This platform bed frame does not require a box spring. Use a suitable mattress directly on the slats.

3. Package Contents

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.
Included Components: Bed Frame parts, Instruction Manual, Hardware Set.



Image: Overview of bed frame components and hardware.

4. Assembly Instructions

This bed frame is designed for easy assembly with no additional tools required beyond what is provided in the hardware set.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface. Refer to the parts list in the package contents section to identify each piece.
2. **Attach Headboard and Footboard Legs:** Secure the legs to the headboard and footboard sections using the provided bolts and Allen wrench. Ensure they are firmly attached.
3. **Connect Side Rails:** Attach the side rails to the headboard and footboard. Make sure the connections are secure and aligned.
4. **Install Center Support Beam:** Position and secure the center support beam(s) to the frame. This provides crucial stability.

5. **Place Slats:** Lay the metal slats across the frame, ensuring they fit into the designated slots or connectors. Evenly space the slats if adjustable.
6. **Tighten All Fasteners:** Double-check all bolts and screws to ensure they are fully tightened. This prevents wobbling and squeaking.



Image: Detail of easy assembly process with labeled parts.



Image: Reinforced structure of the bed frame.

5. Operating Instructions

5.1 Mattress Placement

Place your mattress directly onto the assembled metal slats. This bed frame is designed to be used without a box spring. The headboard and footboard help to keep the mattress firmly in place.



Image: Anti-slipping mattress design.

5.2 Under-bed Storage

The bed frame offers 11.2 inches of clearance underneath, providing ample space for storage. Utilize storage bins or containers to keep your belongings organized.



Image: Under-bed storage space.

6. Maintenance

- **Cleaning:** Wipe the metal frame with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Regular Inspection:** Periodically inspect all bolts and connections to ensure they remain tight. Re-tighten if necessary to maintain stability and prevent squeaking.
- **Avoid Overloading:** Do not place excessive weight on the bed frame beyond its stated capacity.

7. Troubleshooting

7.1 Squeaking Noises

- **Check Connections:** Ensure all bolts and screws are securely tightened. Loose connections are a common cause of squeaking.

- **Lubrication:** Apply a small amount of lubricant (e.g., silicone spray) to metal-on-metal contact points if squeaking persists after tightening.

7.2 Instability/Wobbling

- **Verify Assembly:** Re-check all assembly steps to ensure the frame was put together correctly.
- **Level Surface:** Ensure the bed frame is placed on a flat, level surface. Uneven flooring can cause wobbling.
- **Tighten All Fasteners:** As with squeaking, loose fasteners can lead to instability.

8. Specifications

Brand	Weehom
Model	B09TB3ZF1C
Size	Full
Color	Black
Product Dimensions (L x W x H)	77.5" x 55.8" x 34.8"
Material	Metal (Steel)
Item Weight	45.9 Pounds
Weight Capacity	Maximum 600 lbs
Under-bed Clearance	11.2 inches
Assembly Required	Yes




Image: Product dimensions diagram.

9. Warranty & Support

For warranty information or customer support, please refer to the documentation included with your purchase or contact Weehom directly through their official channels. Keep your purchase receipt for warranty claims.

10. Product Videos

No official seller-provided product videos are available for embedding in this manual.

© 2024 Weehom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TB3ZF1C

More documents and user manuals: **https://manuals.plus/**