Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

JOYROOM JR-X2

User Manual for Joyroom JR-X2 Wireless Air Conduction Headphones

Model: JR-X2

Product Overview

The Joyroom JR-X2 Wireless Air Conduction Headphones are designed for comfortable and stable wearing, utilizing air conduction technology for a healthy listening experience. These headphones are suitable for various activities, including sports, and offer convenient one-hand operation for music and call control.



Figure 1: Overview of the Joyroom JR-X2 Wireless Air Conduction Headphones, showcasing their ergonomic design.

What's in the Box

- Joyroom JR-X2 Wireless Air Conduction Headphones
- Charging Cable
- User Manual

Setup

1. Charging the Headphones

Before first use, fully charge the headphones. Connect the provided charging cable to the charging port on the headphones and a suitable USB power source. The LED indicator will show charging status and turn off when fully charged.

2. Powering On/Off

- **Power On:** Press and hold the multi-function button for approximately 3 seconds until the indicator light flashes.
- **Power Off:** Press and hold the multi-function button for approximately 5 seconds until the indicator light turns off.

3. Bluetooth Pairing

1. Ensure the headphones are powered off.
2. Press and hold the multi-function button for approximately 5-7 seconds until the indicator light flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "JR-X2" from the list of found devices.
5. Once connected, the indicator light on the headphones will flash blue slowly.

4. Wearing the Headphones

The JR-X2 headphones feature an ergonomic ear-hook design for a secure and comfortable fit. Place the ear hooks over your ears, ensuring the sound units rest comfortably near your ear canal without entering it. Adjust for optimal comfort and sound.



Figure 2: Illustration of the ergonomic ear-hook design ensuring comfortable and stable wearing during activities.




Figure 3: Visual representation of the air conduction technology, highlighting how the headphones sit outside the ear canal for comfort and hygiene.

Operating Instructions

The JR-X2 headphones are designed for simple, one-hand operation using the multi-function button and volume buttons located on the side.



Figure 4: Detailed view of the control buttons and their corresponding functions for easy operation.

Headphone Control Functions

Action	Function
Click (Multi-function button)	Play/Pause music
Click (Multi-function button)	Answer incoming call
Click (Multi-function button)	Hang up call
Long press for 2 seconds (Multi-function button)	Reject incoming call
Double click (Multi-function button)	Next song
Press three times (Multi-function button)	Previous song
Short press '+' button	Volume Up
Short press '-' button	Volume Down

Maintenance

- Clean the headphones regularly with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the headphones to extreme temperatures, humidity, or direct sunlight.
- Do not immerse the headphones in water or other liquids.
- Store the headphones in a cool, dry place when not in use.
- Avoid dropping or subjecting the headphones to strong impacts.

Troubleshooting

Common Issues and Solutions

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Headphones not in pairing mode; Bluetooth off on device; device too far.	Ensure headphones are in pairing mode (flashing red/blue). Turn on Bluetooth on your device. Move device closer to headphones (within 10 meters).
No sound or low volume.	Volume too low on headphones or device; headphones not connected; media paused.	Increase volume on both headphones and device. Reconnect headphones. Check if media is playing.
Intermittent connection.	Interference; device too far; obstacles.	Move away from sources of interference (Wi-Fi routers, other Bluetooth devices). Reduce distance between headphones and device. Remove obstacles.

Specifications

Feature	Detail
Model Name	JR-X2
Brand	JOYROOM
Connectivity Technology	Wireless (Bluetooth)
Ear Placement	Open Ear (Air Conduction)
Form Factor	In Ear (referring to the general category, but specifically open-ear design)
Colour	Black
Material	Silicone
Product Dimensions	70 x 70 x 50 cm
Item Weight	23 g
Batteries	1 Lithium Ion batteries required (included)
Manufacturer	Joyroom

Warranty and Support

For warranty information and technical support, please contact Joyroom customer service. Refer to the packaging or the official Joyroom website for contact details.
Note: Software updates are not guaranteed for a specific period.

© 2023 JOYROOM. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09TVM174L

More documents and user manuals: **https://manuals.plus/**