Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Joyroom JR-T03S Pro

Joyroom JR-T03S Pro TWS Bluetooth Earphones User Manual

Model: JR-T03S Pro

Introduction

Thank you for choosing the Joyroom JR-T03S Pro TWS Bluetooth Earphones. This manual provides detailed instructions on how to set up, operate, and maintain your earphones to ensure optimal performance and longevity. Please read this manual carefully before use and retain it for future reference.



Image: Joyroom JR-T03S Pro TWS Bluetooth Earphones in their open charging case, showcasing the earbuds and the case's interior.

Package Contents

Please check the package for the following items:

- Joyroom JR-T03S Pro TWS Earphones (Left and Right)
- Charging Case
- USB Charging Cable
- Silicone Ear Tips (Various Sizes: Small, Medium, Large)

- User Manual



Image: A close-up of the customizable silicone ear tips in small, medium, and large sizes, designed for an optimal seal and active noise cancellation.

Setup

1. Charging the Earphones and Case

Before first use, fully charge the earphones and the charging case. Place the earphones into the charging case. Connect the USB charging cable to the charging port on the case and a power source. The indicator light on the case will show charging status.

- **Charging Case:** Connect to a USB power adapter. The indicator light will illuminate during charging.
- **Earphones:** Place them into the charging case. They will charge automatically.



Image: The Joyroom JR-T03S Pro charging case, highlighting its compact design and the 360 mAh battery capacity for extended use.

2. Bluetooth Pairing

1. Ensure the earphones are charged.
2. Open the charging case. The earphones will automatically enter pairing mode, indicated by a flashing light (refer to specific light patterns in the full manual if available).
3. On your device (smartphone, tablet, etc.), enable Bluetooth.
4. Search for "JR-T03S Pro" in the list of available Bluetooth devices.
5. Select "JR-T03S Pro" to connect. Once connected, a voice prompt or indicator light will confirm successful pairing.

Note: The earphones will automatically reconnect to the last paired device when taken out of the case, if Bluetooth is enabled on the device.

Operating Instructions

Power On/Off

- **Power On:** Open the charging case, and the earphones will power on automatically.
- **Power Off:** Place the earphones back into the charging case and close the lid. They will power off automatically and begin charging.

Touch Controls

The JR-T03S Pro earphones feature touch-sensitive controls on each earbud. Specific functions may vary slightly, but common controls include:

- **Play/Pause:** Single tap on either earbud.
- **Next Track:** Double tap on the right earbud.
- **Previous Track:** Double tap on the left earbud.
- **Answer/End Call:** Single tap on either earbud.

- **Reject Call:** Long press on either earbud.
- **Activate Voice Assistant:** Triple tap on either earbud.

Noise Cancellation and Transparency Modes

The earphones support Active Noise Cancellation (ANC) and Transparency modes. These modes can be switched by a long press on the side touch position of an earbud.

- **Active Noise Cancellation (ANC):** Reduces ambient noise for an immersive audio experience.
- **Transparency Mode:** Allows you to hear your surroundings clearly while still enjoying your audio, facilitating interaction without removing the earbuds.



Image: A diagram highlighting the core upgrade in intelligent noise reduction technology for the T03SPro Active Noise Cancellation Wireless Earphone.



Image: An illustration demonstrating the Active Noise Cancellation (ANC) experience, indicating up to 90% noise reduction achieved by the earphone's technology.




Image: A woman wearing the Joyroom JR-T03S Pro earbuds in an urban setting, illustrating the seamless switching between Noise Cancelling and Transparency modes for various environments.

Call Quality and Microphone

The earphones are equipped with an auxiliary call noise-cancelling microphone to enhance call clarity by reducing environmental noise.




Image: A comparative diagram showing how the imported microphone assists in call noise cancellation, distinguishing between clear voice capture and reduction of environmental noise.

Maintenance

- **Cleaning:** Regularly clean the earbuds, ear tips, and charging case with a soft, dry, lint-free cloth. Do not use liquids or abrasive cleaners.
- **Storage:** When not in use, store the earphones in their charging case to protect them from dust and damage.
- **Battery Care:** To preserve battery life, avoid fully discharging the earphones and charging case frequently. Charge them regularly, even if not in constant use.
- **Water Resistance:** These earphones are not waterproof. Avoid exposure to water or excessive moisture.

Troubleshooting

Problem	Solution

Problem	Solution
Earphones not pairing	• Ensure earphones are charged. • Turn off and on Bluetooth on your device. • Forget "JR-T03S Pro" from your device's Bluetooth list and re-pair. • Place earphones back in case, close, then reopen to reset pairing mode.
No sound from one earbud	• Ensure both earbuds are charged. • Try placing both earbuds back in the case, closing the lid, and then taking them out again. • Check device audio balance settings.
Charging case not charging	• Check the USB cable and power adapter. • Ensure the charging port is clean and free of debris.
Noise Cancellation not effective	• Ensure ear tips provide a good seal. Try different sizes. • Confirm ANC mode is activated via touch controls.

Specifications

Key technical specifications for the Joyroom JR-T03S Pro TWS Bluetooth Earphones:

- **Model Name:** JR-T03S Pro
- **Item Model Number:** JR-T03S
- **Brand:** Joyroom
- **Connectivity Technology:** Wireless, Bluetooth
- **Headphones Form Factor:** In Ear
- **Noise Control:** Active Noise Cancellation
- **Sensitivity:** 93 dB
- **Driver Size:** 13mm dynamic
- **Charging Case Battery Capacity:** 360 mAh
- **Color:** White
- **UPC:** 6941237115584



Image: The retail packaging for the Joyroom JR-T03S Pro, detailing various product specifications and features.

Warranty and Support

Joyroom products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the official Joyroom website or contact your local distributor. Keep your purchase receipt as proof of purchase.

For further assistance, please visit the official Joyroom store:Joyroom Official Store

© 2024 Joyroom. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the

question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09VFBG1DJ

More documents and user manuals: **https://manuals.plus/**