Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Funsicle B09XSMWX1Z

Funsicle Whale Kingdom Playcenter Splash Pad Instruction Manual

Model: B09XSMWX1Z

Introduction

Thank you for choosing the Funsicle Whale Kingdom Playcenter Splash Pad. This manual provides essential information for the safe and proper setup, operation, and maintenance of your new splash pad. Please read all instructions carefully before use and retain this manual for future reference.



Image: The Funsicle Whale Kingdom Playcenter Splash Pad, showcasing its vibrant design and features.

Important Safety Information

WARNING: PREVENT DROWNING!

- Closely watch children who are in or near this pool. Children under 5 are at highest risk for drowning.
- Empty pool or prevent access when not in use.
- NO DIVING! You can break your neck.

Always ensure adult supervision when the splash pad is in use. Do not leave children unattended. This product is not a life-saving device. Always follow local regulations regarding pool safety.

Setup Instructions

1. **Choose a Location:** Select a flat, level, and clear area in your yard, free from sharp objects, rocks, or debris.

Ensure the area is large enough to accommodate the splash pad (80"L x 70"W x 50"H) and allow for safe play around it.

2. **Unfold the Splash Pad:** Carefully remove the splash pad from its packaging and unfold it completely on the chosen surface.
3. **Inflate the Splash Pad:** Locate the inflation valves. Using an air pump (not included), inflate each section until it is firm to the touch but not over-inflated. Do not use high-pressure air compressors. Ensure all valves are securely closed after inflation.
4. **Connect Water Hose:** Attach a standard garden hose to the built-in sprayer connection point on the splash pad. Ensure the connection is secure to prevent leaks.

Image: Detail showing how to connect a standard garden hose to the splash pad's water inlet for sprayer function.

5. **Fill with Water:** Slowly turn on the water supply to the garden hose. The splash pad will begin to fill and the sprayers will activate. Adjust water flow as desired.

Operating Instructions

- **Supervision:** Always ensure constant, active adult supervision of children using the splash pad.
- **Water Depth:** Maintain a shallow water depth suitable for the age and ability of the children using the splash pad.
- **Sprayer Adjustment:** Adjust the water pressure from your garden hose to control the intensity of the built-in sprayers.
- **Safe Play:** Instruct children to avoid running, jumping, or roughhousing in or around the splash pad to prevent slips and falls.

Maintenance

- **Cleaning:** Regularly clean the splash pad with mild soap and water. Rinse thoroughly with clean water and allow it to air dry completely before storage. Do not use harsh chemicals or abrasive cleaners.
- **Draining:** To drain the splash pad, locate the drain plug (if applicable) and open it. Alternatively, carefully tip the splash pad to empty the water.
- **Drying:** Ensure the splash pad is completely dry before deflating and storing to prevent mold and mildew growth.
- **Storage:** Deflate the splash pad by opening all air valves. Once deflated, fold it neatly and store it in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it away from pests and sharp objects.
- **Repair:** In case of small punctures, use a vinyl repair kit (not included) to patch the affected area. Follow the repair kit's instructions carefully.



Image: A hand demonstrating the process of deflating an inflatable by pressing the air valve.



Image: A close-up view of the dual-weld lines, highlighting the product's durable construction for puncture resistance.

Troubleshooting

- **Splash Pad Not Inflating:** Ensure all inflation valves are properly sealed after inflation. Check for any punctures or tears.

- **Water Sprayers Not Working/Weak:** Verify that the garden hose is securely connected and the water supply is fully turned on. Check for kinks in the hose or blockages in the sprayer nozzles.
- **Water Leaking:** Inspect the splash pad for any visible punctures or seam separations. Use a vinyl repair kit for small holes. Ensure drain plugs are securely closed.
- **Splash Pad Losing Air:** Check all inflation valves to ensure they are tightly closed. Inspect the entire surface for small leaks, which can sometimes be found by applying soapy water and looking for bubbles.

Specifications

Feature	Detail
Model Number	B09XSMWX1Z
Inflated Size	80"L x 70"W x 50"H (2.03 m x 1.78 m x 1.27 m)
Material	Plastic
Included Components	1 Splashpad
Brand	Funsicle
Item Weight	7.72 Pounds

Warranty and Support

Warranty information for the Funsicle Whale Kingdom Playcenter Splash Pad is not provided within this document. For details regarding product warranty, returns, or customer support, please refer to the manufacturer's official website or contact the retailer where the product was purchased.
For additional assistance or inquiries, please visit the Funsicle brand store or their official customer service channels.

© 2023 Funsicle. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09XSMWX1Z

More documents and user manuals: **https://manuals.plus/**