Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Bernstein 590PRO

BERNSTEIN 540 PRO WC Wall-Mounted Bidet Toilet User Manual

Model: 590PRO

Introduction

Thank you for choosing the BERNSTEIN 540 PRO WC Wall-Mounted Bidet Toilet. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new bidet toilet. Please read these instructions carefully before use and retain them for future reference.

Safety Instructions

- Ensure all electrical connections are performed by a qualified electrician in accordance with local regulations.
- Do not immerse the product or its electrical components in water.
- Keep the remote control dry and away from water splashes.
- Do not attempt to disassemble or repair the unit yourself. Contact qualified service personnel.
- Ensure the water supply is turned off before any installation or maintenance procedures.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Product Overview

The BERNSTEIN 540 PRO WC is a sophisticated wall-mounted bidet toilet designed for enhanced hygiene and comfort. Key features include:

- **High-Quality Materials:** Sanitary ceramic toilet bowl, plastic seat with sterilizer for fresh, germ-free water.
- **Comprehensive Cleaning:** Rear and feminine wash functions with adjustable water temperature (35°C to 42°C).
- **Adjustable Warm Air Dryer:** Temperature adjustable from 32°C to 57°C.
- **Odor Absorption:** Integrated active carbon odor filter.
- **Advanced Hygiene:** Sterilizer for germ-free water, removable antibacterial shower nozzle, rimless WC design.
- **Comfort Features:** Ergonomic toilet seat, soft-close function, adjustable heated seat (up to 42°C), sensor-controlled LED night light.
- **Control:** Functions controlled via a remote control and an innovative keypad on the toilet.



Image: The BERNSTEIN 540 PRO WC bidet toilet with its soft-close seat mechanism.

Setup and Installation

The BERNSTEIN 540 PRO WC is designed for wall-mounted installation. Professional installation by a qualified plumber and electrician is highly recommended to ensure proper function and safety.

Key Installation Considerations:

- **Water Supply:** Ensure a dedicated cold water supply line (G3/8 connection) is available at the installation point.
- **Electrical Connection:** A grounded electrical outlet (230V, 50Hz) is required for the bidet toilet's functions.
- **Mounting Frame:** A robust wall-mounting frame suitable for wall-hung toilets is necessary.
- **Drainage:** Connect to the standard waste pipe system.




Image: Detailed technical drawing showing the dimensions and connection points for the BERNSTEIN 540 PRO WC bidet toilet.

Refer to the detailed installation guide provided with the product for specific step-by-step instructions and safety warnings.

Operating Instructions

The BERNSTEIN 540 PRO WC can be operated using the included remote control or the integrated keypad on the toilet unit.

Remote Control Functions:



Image: The remote control for the BERNSTEIN 540 PRO WC, showing buttons for various bidet functions and settings.

- **STOP:** Stops all active bidet functions.
- **MASSAGE:** Activates a pulsating water spray for a massage effect.
- **REAR:** Initiates the standard rear wash function.
- **BIDET:** Initiates the feminine wash function.
- **SWING:** Moves the nozzle back and forth for a wider cleaning area.
- **TEMP (+/-):** Adjusts water temperature for washing.
- **DRY:** Activates the warm air dryer.
- **FLOW (+/-):** Adjusts water pressure/flow rate.
- **POSITION (Up/Down):** Adjusts the nozzle position.
- **SEAT (+/-):** Adjusts the heated seat temperature.



Image: The remote control conveniently mounted on the wall next to the bidet toilet.

General Operation:

1. **Power On:** Ensure the unit is connected to power. The sensor-controlled LED night light will activate in low light conditions.
2. **Seat Heating:** The seat heating function can be adjusted via the remote control.
3. **Washing Functions:** Select either REAR or BIDET on the remote. Adjust water temperature (TEMP), pressure (FLOW), and nozzle position (POSITION) as desired. The SWING and MASSAGE functions can be activated for enhanced cleaning.
4. **Drying:** After washing, press DRY to activate the warm air dryer. Adjust the air temperature as needed.
5. **Stopping Functions:** Press STOP to cease any active bidet function.




Image: Illustration of the various bidet nozzle functions, including rear wash, feminine wash, and self-cleaning.




Image: Visual representation of the warm air drying function (red arrows) and the odor absorption system (blue arrows) within the toilet bowl.

Maintenance

Regular maintenance ensures the longevity and hygienic performance of your BERNSTEIN 540 PRO WC.

- **Sterilizer:** The integrated sterilizer helps maintain germ-free water for washing functions. No user intervention is typically required for its operation.
- **Nozzle Cleaning:** The antibacterial shower nozzle is removable for easy cleaning. Regularly clean the nozzle with a soft cloth and mild, non-abrasive cleaner.
- **Toilet Bowl Cleaning:** The rimless design facilitates easy cleaning of the toilet bowl. Use standard toilet cleaners and brushes. Avoid harsh chemicals that may damage the ceramic or plastic components.
- **Odor Filter:** The active carbon odor filter helps absorb unpleasant smells. Replace the filter periodically as recommended in the full product manual (if applicable).
- **Exterior Cleaning:** Wipe down the exterior surfaces of the toilet and remote control with a damp, soft cloth. Do not

use abrasive cleaners or solvents.

- **Descaling:** In areas with hard water, periodic descaling of the water-related components may be necessary. Consult the full manual or contact support for descaling procedures.



Image: Close-up view of the bidet nozzle retracting into the toilet and the illuminated heated seat function.

Troubleshooting

If you encounter issues with your BERNSTEIN 540 PRO WC, refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
No power / Unit unresponsive	Power cord unplugged, circuit breaker tripped, remote control batteries low.	Check power connection. Reset circuit breaker. Replace remote control batteries.
Shower function not working / No water spray	Water supply valve closed, nozzle blocked, water pressure too low, internal malfunction.	Ensure water supply valve is open. Clean the nozzle. Check water pressure. Try resetting the unit (unplug and replug). If issue persists, contact support.
Heated seat not warming	Heated seat function not activated, temperature setting too low, internal fault.	Activate heated seat via remote. Increase temperature setting. If still not working, contact support.
Warm air dryer not working	Dryer function not activated, air vents blocked, internal fault.	Activate dryer via remote. Ensure air vents are clear. If still not working, contact support.
Odor absorption ineffective	Odor filter needs replacement.	Replace the active carbon odor filter.

For issues not listed here or if troubleshooting steps do not resolve the problem, please contact BERNSTEIN customer support.

Specifications

Feature	Detail
Brand	Bernstein
Model Number	590PRO
Part Number	540 PRO
ASIN	B09YDGNBBM
GTIN / UPC	049934041208
Color	White
Toilet Material	Ceramic
Seat Material	Plastic
Installation Type	Wall Mount
Shape	D-Shape
Package Dimensions	66 x 49 x 46 cm
Item Weight	36 kilograms
Included Components	Shower toilet with remote control
Water Temperature Range	35°C to 42°C
Air Dryer Temperature Range	32°C to 57°C

Feature	Detail
Heated Seat Temperature	Up to 42°C




Image: Energy label for the BERNSTEIN 540 PRO WC, indicating energy efficiency.

For detailed energy information, visit: https://eprel.ec.europa.eu/qr/1091063

Warranty and Support

For warranty information, technical support, or service requests, please contact BERNSTEIN customer service directly. Keep your purchase receipt and model number (590PRO) handy when contacting support.
Contact information can typically be found on the manufacturer's official website or in the packaging materials.

© 2024 Bernstein. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YDGNBBM

More documents and user manuals: **https://manuals.plus/**