Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Laica VT3306

Laica Smart Glass Vacuum Containers 0.5L and 1.5L User Manual

Model: VT3306

1. Introduction

Thank you for choosing Laica Smart Glass Vacuum Containers. This manual provides essential information for the safe and effective use of your 0.5L and 1.5L vacuum containers. Designed for optimal food preservation, these containers help keep your food fresh for up to 4 times longer.
Please read these instructions carefully before first use and retain them for future reference.

2. Product Overview

The Laica Smart Glass Vacuum Containers are designed to create an airtight, vacuum-sealed environment for your food. The set includes two containers of different capacities (0.5L and 1.5L) with corresponding lids.



Image: Two Laica Smart Glass Vacuum Containers, showcasing their design and capacity for storing various foods.

Components:

- 0.5L Glass Container
- 1.5L Glass Container
- Lids with integrated vacuum valve (ABS and silicone)

3. Key Features

- **Extended Freshness:** Preserves food up to 4 times longer by removing air.
- **Versatile Use:** Suitable for refrigerator, freezer, microwave (without lid), and oven (without lid).
- **Durable Materials:** 100% recyclable glass containers. Lids made of ABS and silicone.
- **Easy to Clean:** Glass containers are dishwasher safe. Lids require hand washing.
- **BPA-Free:** Ensures food safety.
- **Smart Integration:** Compatible with the free Laica Home Wellness app for food tracking and expiry notifications.



Image: A Laica vacuum sealer machine in operation with two glass containers, demonstrating the extended food freshness feature.



Image: Illustration of various food types (vegetables, meat, seafood, fruits, nuts) that can be stored in the Laica containers, highlighting their multi-use functionality.



Image: Two Laica Smart Glass Vacuum Containers with food, illustrating their use for marinating, which infuses flavors effectively.

4. Initial Setup

1. **Unpacking:** Carefully remove all components from the packaging. Inspect for any damage.
2. **First Wash:** Before initial use, wash the glass containers in the dishwasher or by hand with warm, soapy water. Hand wash the lids and silicone valves thoroughly. Rinse all parts and allow them to air dry completely.
3. **Assembly:** Ensure the silicone gasket on the lid is properly seated and the vacuum valve is clean and free of debris.



Image: Icons representing the versatility of the containers, including dishwasher, microwave, oven (without lid), freezer compatibility, and BPA-free material.

5. Operating Instructions

5.1. Vacuum Sealing Process

These containers require an external vacuum sealer (e.g., a Laica vacuum sealer machine) to create a vacuum. Ensure your vacuum sealer is compatible with external vacuum accessories.

1. **Fill Container:** Place your food inside the glass container. Do not overfill; leave at least 2-3 cm of space from the rim.
2. **Close Lid:** Place the lid firmly onto the container, ensuring the silicone gasket forms a tight seal around the rim.
3. **Connect Vacuum Sealer:** Connect the hose from your Laica vacuum sealer to the vacuum valve on the lid.
4. **Start Vacuum:** Activate the vacuum function on your sealer. The air will be extracted from the container.
5. **Seal Completion:** Once the vacuum process is complete (indicated by your sealer or when the valve is fully depressed), disconnect the hose. The container is now vacuum-sealed.

5.2. Opening the Container

To release the vacuum and open the container:

1. Locate the vacuum release button/valve on the lid.
2. Press or lift the valve to allow air to re-enter the container. You will hear a hissing sound.
3. Once the air has equalized, the lid can be easily removed.

5.3. Using with Laica Home Wellness App

Enhance your food management with the free Laica Home Wellness app:

1. **Download App:** Download the "LAICA HOME WELLNESS" app from your smartphone's app store.
2. **Scan QR Code:** Each lid features a QR code. Scan this code using the app.
3. **Enter Food Details:** Input information about the food stored, including the date of storage and expected expiry.
4. **Receive Notifications:** The app will provide reminders and notifications regarding the expiry dates of your stored food, helping to reduce waste.



Image: A smartphone showing the Laica Home Wellness app interface, demonstrating its functionality for tracking stored food via QR codes on the container lids.

6. Maintenance and Care

6.1. Cleaning

- **Glass Containers:** The glass containers are dishwasher safe. For hand washing, use warm, soapy water and a non-abrasive sponge.
- **Lids:** The lids, including the silicone valve, should be hand washed only. Use warm, soapy water and a soft cloth. Do not immerse the entire lid in water for extended periods.
- **Drying:** Ensure all parts are completely dry before reassembling or storing to prevent mold or odors.

6.2. Storage

Store the containers and lids in a clean, dry place when not in use. Avoid storing lids tightly sealed on empty containers to prevent potential odor buildup.

7. Troubleshooting

Problem	Possible Cause	Solution
Vacuum not holding / Air leaking	Lid not properly sealed; Silicone gasket dirty or misplaced; Vacuum valve dirty or damaged.	Ensure lid is firmly closed. Check and clean the silicone gasket and valve. Replace lid if damaged.
Lid difficult to remove after vacuuming	Vacuum not released completely.	Press the vacuum release valve firmly until all air has re-entered the container.
Food not staying fresh	Improper vacuum seal; Food already spoiled; Container stored incorrectly.	Ensure a proper vacuum seal. Only vacuum fresh food. Store in refrigerator or freezer as appropriate.

8. Product Specifications

- **Model:** VT3306
- **Capacities:** 0.5 Liters, 1.5 Liters
- **Material:** Glass (container), ABS & Silicone (lid)
- **Color:** Transparent
- **Dimensions (approx. for 1.5L container):** 22L x 16W x 15H cm
- **Weight (set):** Approximately 1.4 kg
- **Dishwasher Safe:** Yes (glass containers only)
- **Microwave Safe:** Yes (glass containers only, without lid)
- **Oven Safe:** Yes (glass containers only, without lid)
- **Freezer Safe:** Yes
- **BPA Free:** Yes

9. Warranty and Support

Laica products are manufactured to high-quality standards. This product is covered by a standard manufacturer's warranty against defects in materials and workmanship from the date of purchase. Please refer to the warranty card included with your product for specific terms and conditions.

For technical support, spare parts, or warranty claims, please contact Laica customer service through their official website or the contact information provided in your product packaging.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YJYW5Z6

More documents and user manuals: **https://manuals.plus/**