Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire ESC021-RED

Frigidaire ESC021-RED Countertop Snow Cone Maker User Manual

Model: ESC021-RED

1. Important Safety Information

Please read all instructions carefully before operating this appliance. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always unplug the appliance from the outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not immerse the motor base in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- This appliance is for household use only.

2. Parts and Features

Familiarize yourself with the components of your Frigidaire Snow Cone Maker.



Figure 2.1: Front view of the Frigidaire ESC021-RED Snow Cone Maker. This image shows the overall design, including the clear top, control knob, and ice shaving chamber.



Figure 2.2: Angled view of the appliance, highlighting the red finish and the transparent ice container with the internal ice pusher.

- **Clear Plastic Top:** Allows visibility of the ice shaving process.
- **Control Knob:** Used to select ice texture (Coarse/Fine).
- **Ice Shaving Chamber:** Where ice cubes are placed for shaving.
- **Stainless Steel Blade:** Durable blade for efficient ice shaving.
- **Ice Container/Pitcher:** Collects the shaved ice.
- **Motor Base:** Contains the 45-watt motor.

3. Setup

Before first use, and after each use, ensure all removable parts are clean.

1. Unpack all components and remove any packaging materials.
2. Wash the clear plastic top, ice container, and any other removable parts in warm, soapy water. Rinse thoroughly and dry.
3. Wipe the motor base with a damp cloth. Do not immerse the motor base in water.

4. Place the snow cone maker on a stable, flat, and dry surface.
5. Ensure the ice container is properly seated in the base.

4. Operating Instructions

Follow these steps to make shaved ice:

1. Ensure the appliance is unplugged.
2. Remove the clear plastic top.
3. Add regular ice cubes to the ice shaving chamber. Do not overfill.
4. Replace the clear plastic top, ensuring it is securely locked in place. The appliance will not operate if the lid is not properly secured.
5. Plug the appliance into a standard electrical outlet.
6. Turn the control knob to your desired ice texture: **COARSE** for larger ice flakes or **FINE** for a finer, snow-like consistency. The appliance will begin shaving ice immediately.
7. Observe the ice being shaved through the clear plastic top. The shaved ice will collect in the container below.
8. Once the desired amount of shaved ice is produced, turn the control knob to the OFF position and unplug the appliance.
9. Carefully remove the clear plastic top and the ice container to serve the shaved ice.



Figure 4.1: The snow cone maker actively shaving ice, demonstrating the clear view of the process and the collection of shaved ice in the pitcher.



Figure 4.2: A close-up of the appliance with a significant amount of

shaved ice collected in the transparent container, ready for serving.

5. Maintenance and Cleaning

Regular cleaning will ensure the longevity and optimal performance of your snow cone maker.

1. Always unplug the appliance before cleaning.
2. Remove the clear plastic top and ice container.
3. Wash the clear plastic top and ice container in warm, soapy water. These parts are not dishwasher safe. Rinse thoroughly and dry completely.
4. Wipe the exterior of the motor base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads.
5. Never immerse the motor base in water or any other liquid.
6. Ensure all parts are completely dry before reassembling or storing the appliance.
7. Store the appliance in a cool, dry place.

6. Troubleshooting

If you encounter issues with your snow cone maker, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in.	Ensure the power cord is securely plugged into a working electrical outlet.
	Clear plastic top not securely in place.	Ensure the clear plastic top is properly aligned and locked onto the base.
Ice is not shaving properly.	Too much ice in the chamber.	Reduce the amount of ice cubes. Do not overfill.
	Ice cubes are too large or irregularly shaped.	Use standard-sized ice cubes. Break larger cubes if necessary.
Shaved ice texture is inconsistent.	Control knob setting.	Adjust the control knob between 'COARSE' and 'FINE' to achieve desired consistency.

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Detail
Model Number	ESC021-RED
Power	45 watts
Dimensions (L x W x H)	12 x 12 x 12.25 inches
Item Weight	10 pounds
Blade Material	Stainless Steel
Ice Type	Uses regular ice cubes

8. Warranty and Support

For information regarding warranty coverage or technical support, please refer to the warranty card included with your product or visit the official Frigidaire website. You may also contact Frigidaire customer service directly for assistance with your ESC021-RED Snow Cone Maker.

© 2023 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09YYSPV5K

More documents and user manuals: **https://manuals.plus/**