Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Frigidaire EFIC239AMZ

Frigidaire Countertop Crunchy Chewable Nugget Ice Maker V2

Model: EFIC239AMZ

Introduction

Thank you for choosing the Frigidaire Countertop Crunchy Chewable Nugget Ice Maker V2. This manual provides important information for the proper use, maintenance, and troubleshooting of your new ice maker. Please read it thoroughly before operating the appliance and retain it for future reference.
This compact and powerful ice maker is designed to produce soft, crunchy nugget ice quickly, making it perfect for home use, parties, or even portable applications like camping. It features a high daily production capacity and an automatic water recycling system for efficiency.

Important Safety Information

WARNING:

- Always unplug the ice maker from the power outlet before cleaning, servicing, or when not in use.
- Do not immerse the appliance, power cord, or plug in water or any other liquid.
- This appliance is for household use only. Do not use outdoors.
- Keep the ice maker away from heat sources and direct sunlight.
- Ensure proper ventilation around the unit. Maintain at least 6 inches of clearance from walls and other objects.
- Use only potable water in the water reservoir.
- Do not operate the appliance with a damaged cord or plug. Contact customer support for assistance.
- Supervise children when the appliance is in use.

Product Overview



Front view of the Frigidaire Countertop Nugget Ice Maker with the lid closed, showing the ice basket filled with nugget ice.



Top view of the Frigidaire Countertop Nugget Ice Maker with the lid open, revealing the ice basket and an ice scoop.

The Frigidaire Nugget Ice Maker is designed for convenience and performance. Key components include:

- **Ice Basket:** Removable basket for collecting and serving ice.
- **Water Reservoir:** Located beneath the ice basket, where water is stored for ice production.
- **Control Panel:** Features indicator lights for "Ice Full" and "Add Water," and an "Ice/Clean" button.
- **Drain Plug:** Located at the bottom for easy draining during cleaning.

Setup

1. **Unpacking:** Carefully remove the ice maker from its packaging. Remove all packing materials, tape, and any labels.
2. **Placement:** Place the ice maker on a stable, level surface away from direct sunlight and heat sources. Ensure there is at least 6 inches of clearance around the unit for proper ventilation.

3. **Initial Cleaning:** Before first use, clean the interior of the ice maker.
    - Remove the ice basket.
    - Clean the interior with a soft cloth and warm, soapy water. Rinse thoroughly.
    - Drain any remaining water through the drain plug at the bottom.
    - Dry all parts thoroughly before reassembling.
4. **Power Connection:** Plug the ice maker into a grounded electrical outlet.

Operating Instructions

1. **Add Water:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
2. **Start Ice Production:** Press the "Ice/Clean" button to begin the ice-making cycle. The indicator light will illuminate.
3. **Monitor Ice Production:**
    - The first batch of ice may take approximately 15 minutes. Subsequent batches will be faster.
    - The "Ice Full" indicator will light up when the ice basket is full. The unit will automatically stop making ice.
    - The "Add Water" indicator will light up when the water reservoir is low. Add more water and press the "Ice/Clean" button to resume.
4. **Collect Ice:** Use the provided scoop to remove ice from the basket. For best results, transfer ice to a freezer for storage. The ice maker is not a freezer and will not keep ice frozen indefinitely.
5. **Automatic Water Recycling:** As ice melts in the basket, the water will return to the reservoir to be re-used for new ice production.



The Frigidaire Nugget Ice Maker on a countertop, ready to serve ice for beverages.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and extends the life of your ice maker.

1. **Daily Cleaning:**
    - Unplug the unit.
    - Remove any remaining ice from the basket.
    - Drain water from the reservoir using the drain plug.
    - Wipe the interior and exterior with a soft, damp cloth.
2. **Deep Cleaning (Monthly or as needed):**
    - Unplug the unit and drain all water.
    - Add a mixture of water and white vinegar (10:1 ratio) or a dedicated ice maker cleaning solution to the reservoir.
    - Press and hold the "Ice/Clean" button for 5 seconds to activate the self-cleaning cycle. The unit will run for

approximately 30 minutes.
    - After the cycle, drain the cleaning solution completely.
    - Rinse the reservoir thoroughly with clean water, draining completely multiple times to remove any residue.
    - Wipe down all surfaces.
3. **Storage:** If storing the ice maker for an extended period, ensure it is completely dry to prevent mold or mildew growth. Store in a cool, dry place.

Troubleshooting

Problem	Possible Cause	Solution
Ice maker not working.	No power; "Add Water" light on; "Ice Full" light on.	Check power connection; Add water to reservoir; Remove ice from basket.
Ice production is slow or ice is not forming.	Room temperature too high; Water temperature too high; Poor ventilation; Mineral buildup.	Ensure room temperature is below 90°F (32°C); Use cold water; Ensure proper clearance around unit; Perform deep cleaning.
"Add Water" light is on, but there is water in the reservoir.	Water level sensor issue; Unit not level.	Ensure unit is on a level surface; Unplug and replug the unit to reset. If problem persists, contact support.
Ice has an unusual taste or odor.	Unit needs cleaning; Stale water.	Perform deep cleaning; Use fresh, potable water.

Specifications

Feature	Detail
Model Number	EFIC239AMZ
Brand	Frigidaire
Product Dimensions (D x W x H)	13.5"D x 9.5"W x 15.5"H
Daily Ice Production Capacity	44 lbs per day
Ice Bin Capacity	3 lbs
Wattage	960 watts
Ice Type	Nugget (Chewable)
Manufacturer	CURTIS



Diagram showing the dimensions of the Frigidaire Countertop Nugget Ice Maker.

Warranty and Support

This Frigidaire ice maker is manufactured by CURTIS. For warranty claims, technical support, or service inquiries, please contact CURTIS customer support directly.
Please refer to the warranty card included with your product for specific warranty terms and conditions, as well as contact information for CURTIS customer service.
It is recommended to keep your purchase receipt as proof of purchase for warranty purposes.

© 2025 Frigidaire. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09ZGR6G89

More documents and user manuals: **https://manuals.plus/**