Manuals+
Q & A | Deep Search | Upload

SVAKOM E27575

SVAKOM Benedict Rechargeable Cock Ring User Manual

Model: E27575

1. Introduction

The SVAKOM Benedict is a rechargeable cock ring designed for personal stimulation. Crafted from flexible, body-safe silicone, it features multiple vibration modes and is fully waterproof for versatile use. This manual provides essential information for the safe and effective operation and maintenance of your device.

Image 1.1: SVAKOM Benedict device overview.

2. Safety Information

Please read all safety instructions before using the SVAKOM Benedict. Failure to follow these instructions may result in injury or damage to the product.

- **Material Safety:** The device is made from body-safe silicone. Clean thoroughly before and after each use.
- **Waterproof:** The device is fully waterproof. However, it is not intended for internal use.
- **Charging:** Use only the provided charging cable. Do not use the device while charging.
- **Storage:** Store in a cool, dry place away from direct sunlight and extreme temperatures. Keep out of reach of children.
- **Discontinue Use:** If you experience any discomfort, irritation, or pain during use, discontinue immediately and consult a healthcare professional.
- **Medical Conditions:** Consult your doctor before use if you have any medical conditions or are taking medication.

3. Product Features

The SVAKOM Benedict offers the following key features:

- **Powerful Vibrations:** Equipped with a motor designed to provide intense stimulation.
- **Flexible Design:** The highly flexible silicone material ensures a comfortable fit for various sizes.
- **Body-Safe Material:** Constructed from ultra-soft, skin-friendly silicone for a comfortable experience.
- **Waterproof Design:** Features a magnetic charging port, making the device fully waterproof for use in wet environments.
- **Multiple Vibration Modes:** Offers 5 distinct vibration modes with adjustable intensity levels for personalized experiences.

Image 3.1: The flexible design of the SVAKOM Benedict.

Image 3.2: The SVAKOM Benedict is fully waterproof.

4. Package Contents

Your SVAKOM Benedict package should contain:

- 1 x SVAKOM Benedict Rechargeable Cock Ring
- 1 x USB Magnetic Charging Cable
- 1 x User Manual (this document)

5. Setup

5.1 Initial Cleaning

Before first use, clean the device thoroughly with warm water and a mild, toy-safe soap. Rinse well and allow to air dry completely.

5.2 Charging the Device

The SVAKOM Benedict uses a magnetic charging port. Ensure the device is fully charged before its first

use.

1. Connect the USB magnetic charging cable to a standard USB power adapter (not included) or a computer USB port.
2. Attach the magnetic end of the cable to the charging contacts on the device. The magnets will help align it correctly.
3. The indicator light on the device will illuminate to show it is charging.
4. A full charge typically takes approximately 2-3 hours. The indicator light will change or turn off when charging is complete.

Note: The device contains 1 Lithium Polymer battery (included).

6. Operating Instructions

6.1 Power On/Off

- To **Power On**: Press and hold the power button (usually marked with a power symbol) for 2-3 seconds until the device vibrates or the indicator light turns on.
- To **Power Off**: Press and hold the power button for 2-3 seconds until the device stops vibrating and the indicator light turns off.

6.2 Changing Vibration Modes and Intensity

The SVAKOM Benedict features 5 different vibration modes and intensity levels.

- To **Change Mode**: Briefly press the mode button (often separate from the power button, or a short press of the power button if it's a single control). Each press will cycle through the available vibration patterns.
- To **Adjust Intensity**: Some models may have dedicated '+' and '-' buttons, or a long press on the mode/power button might adjust intensity within a mode. Refer to the specific button layout on your device for precise control.

7. Maintenance

7.1 Cleaning

Proper cleaning ensures hygiene and extends the life of your device.

1. Always clean the device immediately after each use.
2. Wash with warm water and a mild, antibacterial, toy-safe soap.
3. Rinse thoroughly to remove all soap residue.
4. Pat dry with a lint-free cloth or allow to air dry completely before storing.
5. Do not use cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone material.

7.2 Storage

Store the SVAKOM Benedict in a clean, dry, and dust-free environment. Keep it separate from other toys made of different materials to prevent potential reactions or damage to the silicone.

8. Troubleshooting

If you encounter issues with your SVAKOM Benedict, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no charge.	Charge the device fully as per Section 5.2.
Vibrations are weak or inconsistent.	Low battery.	Recharge the device.
Device not charging.	Charging cable not properly connected or damaged.	Ensure the magnetic cable is securely attached to the charging contacts. Try a different USB power source. Inspect the cable for damage.
Device feels uncomfortable or causes irritation.	Improper application or allergic reaction.	Ensure proper fit and lubrication. Discontinue use immediately if irritation persists and consult a healthcare professional.

9. Specifications

- **Model Number:** E27575
- **Material:** Silicone
- **Color:** Black
- **Product Dimensions:** 2.44 x 2.13 x 4.49 inches (L x W x H)
- **Weight:** 2.47 ounces
- **Battery:** 1 Lithium Polymer battery (included)
- **Waterproof:** Yes
- **Vibration Modes:** 5

10. Warranty and Support

For warranty information, product support, or to inquire about replacement parts, please contact SVAKOM customer service directly. Please retain your proof of purchase for any warranty claims.

You can visit the official SVAKOM store for more information and contact details:SVAKOM Store

© 2026 SVAKOM. All rights reserved.