Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

OUKITEL WP15S

OUKITEL WP15S Rugged Smartphone User Manual

Model: WP15S | Brand: OUKITEL

1. Introduction

The OUKITEL WP15S is a rugged smartphone designed for durability and extended use. It features a large 15600mAh battery, a 6.52-inch HD+ display, and a quad-camera system. This device is built to withstand challenging environments, boasting IP68 and IP69K waterproof and dustproof ratings, as well as MIL-STD-810G certification for shock resistance.



Image: Front and back view of the OUKITEL WP15S Rugged Smartphone, showcasing its robust design and camera module.

▶ **Watch video online**
OUKITEL WP15S 15600mAh Battery IP68 Waterproof Rugged phone

Video: An overview of the OUKITEL WP15S, highlighting its 15600mAh battery, IP68 waterproof rating, and rugged design features.

2. Setup

2.1. Unboxing

Upon opening the package, verify that the following items are included:

- OUKITEL WP15S Smartphone
- USB Cable
- OTG Cable (for reverse charging and peripheral connection)
- User Manual (this document)

2.2. SIM Card and SD Card Installation

To install your SIM card(s) and/or microSD card:

1. Locate the SIM card tray on the side of the device.
2. Use the provided SIM ejector tool to open the tray.
3. Carefully place your Nano-SIM card(s) and/or microSD card into the designated slots. Ensure proper orientation.
4. Gently push the tray back into the device until it is flush with the phone's body.

2.3. Initial Power On and Charging

To power on your device, press and hold the Power button located on the side until the OUKITEL logo appears. For initial use, it is recommended to fully charge the device. Connect the USB cable to the phone's charging port and plug the other end into a compatible 18W fast charger. The device supports fast charging.

3. Operating Instructions

3.1. Basic Navigation (Android 11)

The OUKITEL WP15S runs on Android 11. Navigate the interface using touch gestures:

- **Swipe Up:** Access the app drawer.
- **Swipe Down:** Access quick settings and notifications.
- **Tap:** Select an item.
- **Long Press:** Access contextual menus or move icons.

3.2. Calls and Messaging

Use the Phone app to make and receive calls. The Messages app allows you to send and receive SMS/MMS messages. Ensure your SIM card is active and has network coverage.

3.3. Camera Usage

The WP15S features a versatile quad-camera system on the rear and an 8MP front camera. Open the Camera app to capture photos and videos.

- **Rear Cameras:** 20MP Main, 2MP Microlens, 0.3MP Bokeh.
- **Front Camera:** 8MP.
- **Special Feature:** Supports underwater shooting. Activate this mode in the camera settings before submerging the device.



Image: Diagram illustrating the OUKITEL WP15S camera setup, including the 20MP main, 2MP microlens, 0.3MP bokeh, and 8MP front cameras.

3.4. Battery Management

The 15600mAh battery provides extended usage times. To optimize battery life:

- Adjust screen brightness.
- Close unused applications.
- Utilize Battery Saver mode when needed.
- The device supports OTG for reverse charging other devices.



Image: Graphic highlighting the OUKITEL WP15S's 15600mAh battery capacity, emphasizing its long-lasting power.

3.5. Display Features

The 6.52-inch HD+ display offers a wide viewing experience. It is protected by Corning Gorilla Glass for enhanced scratch and drop resistance.



Image: Graphic showcasing the OUKITEL WP15S's 6.52-inch HD+ Full View Screen with 720x1560 resolution and Corning Gorilla Glass protection.

3.6. Connectivity and Security

The device supports 4G LTE, GSM, WCDMA, and FDD networks. Other connectivity options include Bluetooth 5.0, NFC, and OTG. For security, the WP15S includes both Fingerprint ID and Face ID unlock features.

4. Maintenance

To ensure the longevity and optimal performance of your OUKITEL WP15S:

- **Cleaning:** Use a soft, damp cloth to clean the device. Avoid harsh chemicals.
- **Water Exposure:** While waterproof, ensure all port covers are securely closed before exposing the device to water. After water exposure, dry the device thoroughly before charging.
- **Temperature:** Avoid prolonged exposure to extreme temperatures (below -20°C or above 60°C).
- **Impact:** Despite its rugged design, avoid unnecessary drops or impacts to prevent potential damage.




Image: Graphic detailing the OUKITEL WP15S's rugged certifications: IP68 for water, IP69K for high-pressure water, and MIL-STD-810G for drop resistance.

5. Troubleshooting

If you encounter issues with your OUKITEL WP15S, refer to the following common solutions:

- **Device Not Powering On:** Ensure the battery is charged. Connect to a charger for at least 15 minutes before attempting to power on again.
- **Charging Issues:** Check the USB cable and charger for damage. Ensure the charging port is clean and free of debris.
- **No Network Signal:** Verify that your SIM card is correctly inserted and active. Check network settings and ensure airplane mode is off. Try restarting the device.
- **Apps Crashing/Freezing:** Close background apps. Clear the cache of the problematic app or reinstall it. If issues persist, consider a factory reset (back up data first).
- **Fingerprint/Face ID Not Working:** Ensure your fingers are clean and dry for fingerprint scanning. For Face ID, ensure adequate lighting and that your face is clearly visible to the front camera. Re-register your biometrics if necessary.

6. Specifications

Key technical specifications for the OUKITEL WP15S:

Feature	Specification
Model Name	WP15S
Operating System	Android 11.0
Processor	MT6762D Octa-core (2.2 GHz CPU Speed)
RAM	4 GB
Internal Storage	64 GB
Expandable Storage	Up to 2 TB (via microSD)
Battery Capacity	15600 mAh (Lithium Ion)
Charging	18W Fast Charge, OTG Reverse Charging
Display Size	6.52 Inches
Display Resolution	720 x 1440 (HD+)
Display Protection	Corning Gorilla Glass
Rear Camera	20MP Main, 2MP Microlens, 0.3MP Bokeh
Front Camera	8MP
Durability Ratings	IP68, IP69K, MIL-STD-810G
Wireless Technologies	Bluetooth 5.0, NFC, Cellular (4G LTE, GSM, WCDMA, FDD)
Security Features	Fingerprint ID, Face ID
Weight	1.72 pounds



Image: Graphic summarizing key features including 4GB RAM, 64GB storage, 6.52-inch display, waterproof/dustproof/shockproof ratings, NFC, GPS, 20MP camera, Mediatek Helio P22, 18W rapid charge, and 15600mAh battery.

7. Warranty and Support

Your OUKITEL WP15S is covered by a standard manufacturer's warranty. For specific warranty terms, conditions, and duration, please refer to the warranty card included with your product or visit the official OUKITEL website. For technical support, troubleshooting assistance, or service inquiries, please contact OUKITEL customer service through their official channels.

Visit the OUKITEL Store: OUKITEL Official Store

8. Safety Information

Please read the following safety information carefully to ensure safe and proper use of your device:

- Do not attempt to disassemble, repair, or modify the device yourself.
- Use only OUKITEL-approved chargers and accessories.
- Avoid exposing the battery to extreme heat or direct sunlight.
- Dispose of the device and its battery responsibly according to local regulations.
- Maintain a safe distance from medical devices when using the phone.

© 2023 OUKITEL. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B09ZV8P23Q

More documents and user manuals: **https://manuals.plus/**