Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Uniflasy DGF350CSP, DGF350CSP-D, DGC350CNP-D

Uniflasy Grill Replacement Parts Kit for Dyna-Glo DGF350CSP Series Gas Grills

Instruction Manual

1. Product Overview

This Uniflasy Grill Replacement Parts Kit is designed to refresh and restore the cooking performance of your Dyna-Glo 2-Burner Open Cart Propane Gas Grill. The kit includes essential components for heat distribution and cooking surfaces.

Kit Contents:

- 2 x Heat Plates (Porcelain Steel)
- 2 x Cooking Grates (Cast Iron)



Image: The complete Uniflasy Grill Replacement Parts Kit, featuring two heat plates and two cast iron cooking grates.

2. Compatibility

This replacement kit is specifically designed to fit the following Dyna-Glo 2-Burner Open Cart Propane Gas Grill models:

- Dyna-Glo DGF350CSP
- Dyna-Glo DGF350CSP-D
- Dyna-Glo DGC350CNP-D

Please verify your grill model number before installation to ensure proper fitment.

3. Features and Materials

Heat Plates:

- **Material:** Porcelain Steel
- **Function:** Prevents direct flame exposure to food, protects burners from dripping grease, and promotes even heat distribution for consistent cooking results.
- **Durability:** Designed for strong corrosion resistance and heat resistance.



Image: Detailed view of the porcelain steel heat plate, emphasizing its robust design and smooth finish for easy cleaning.

Cooking Grates:

- **Material:** Heavy Cast Iron
- **Performance:** Cast iron grates heat evenly and retain heat superbly, delivering professional searing and prominent sear marks on your food.
- **Longevity:** Made of heavy cast iron to ensure long-lasting use.



Image: The two heavy cast iron cooking grates, highlighting their robust build for durability and superior heat retention.

4. Installation Guide

Follow these steps to install your new Uniflasy grill replacement parts:

1. **Preparation:** Ensure your grill is completely cool and disconnected from its fuel source. Remove any existing grates and heat plates. Clean the interior of the grill thoroughly before installing new parts.
2. **Install Heat Plates:** Carefully place the new porcelain steel heat plates over the burners. Ensure they are seated correctly on their supports within the grill firebox.
3. **Install Cooking Grates:** Place the cast iron cooking grates onto the designated ledges above the heat plates. Ensure both grates are level and securely positioned.



Image: Heat plates correctly positioned over the grill burners, illustrating how they contribute to even heat distribution.

Installation Video:

Your browser does not support the video tag.

Video: This video demonstrates the installation process for the Uniflasy Grill Replacement Parts Kit, showing how to correctly place the heat plates and cooking grates into a compatible grill.

5. Maintenance and Care

Proper maintenance extends the life of your grill parts and ensures optimal cooking performance.

Avoiding Rust:

- **Scrape After Each Use:** Use a grill brush to scrape your grates after every use to remove food residue.
- **Season Grates:** After cleaning, brush the grates with cooking oil to season them. This creates a protective layer.
- **Ventilation:** Leave the grill dampers slightly open after use to prevent condensation buildup inside the grill.

- **Cover When Not in Use:** Always put the lid back on your grill and use a grill cover when it is not in use to protect it from elements.
- **Long-Term Storage:** For extended storage, heavily coat the grates in cooking oil, wrap them in a plastic bag, and store them in your covered grill.

Cleaning Heat Plates:

The porcelain steel heat plates are designed to be easy to clean. After the grill has cooled, wipe them down with a damp cloth to remove grease and residue.

6. Specifications

- **Product Dimensions:** 5.01 x 2 x 5.01 inches (approximate, for individual components)
- **Item Weight:** 7.58 pounds (total kit)
- **Heat Plate Material:** Porcelain Steel
- **Cooking Grate Material:** Cast Iron
- **Manufacturer:** Uniflasy

7. Important Safety Information

- Always ensure the grill is cool and disconnected from the fuel source before performing any maintenance or part replacement.
- Wear appropriate protective gear, such as gloves, when handling grill components.
- Keep children and pets away from the grill during installation and operation.
- Refer to your grill's original manufacturer manual for specific safety guidelines related to its operation.

8. Warranty and Support

For warranty information or technical support regarding your Uniflasy Grill Replacement Parts Kit, please contact Uniflasy customer service through the retailer where the product was purchased. Keep your proof of purchase for any warranty claims.

For additional product information or to explore other Uniflasy products, visit theUniflasy Store on Amazon.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B1MR3K1M

More documents and user manuals: **https://manuals.plus/**