Manuals+
Q & A | Deep Search | Upload

Micca Speck G3

Micca G3 2K Quad-HD Digital Media Player User Manual

Model: Speck G3

Introduction

The Micca G3 2K Quad-HD Digital Media Player is a versatile device designed to enhance your television by playing videos, music, and photos directly from USB drives and MicroSD cards. Its compact design and robust format support make it ideal for home entertainment and digital signage applications. This manual provides detailed instructions for setting up, operating, and maintaining your Micca G3 player.

What's in the Box

Please check the package contents to ensure all items are present:

- Micca G3 Digital Media Player
- Remote Control
- Power Adapter
- AV Cable
- User Manual (this document)

Product Features

The Micca G3 offers a range of features for a seamless media experience:

- **Make Your TV Smarter:** Easily play media from USB drives and MicroSD cards.
- **2K Quad-HD Video Playback:** Smoothly plays videos up to 2560x1440@60fps, with upscaling to UHD 4K/60Hz via HDMI output.
- **Dual USB and MicroSD Reader:** Supports USB flash drives and hard drives up to 8TB, and MicroSD cards up to 1TB.
- **Simple Digital Signage:** Features automatic video playback with endless repeat and looping, resume from last stopping point, and 90/180/270 degree video output rotation.

- **Robust Media Format Support:** Compatible with a wide range of video (MKV, MP4, AVI, MOV, MPG, VOB, M2TS, TS with H.265/HEVC, H.264/AVC), audio (MP3, OGG, WAV, FLAC, APE), and photo (JPG, GIF, BMP, PNG, TIF) formats.

The Micca G3 enhances your TV by enabling playback of various media files from external storage.

Utilize the Micca G3 for simple digital signage applications with automatic playback and looping.

Key features include 2K QHD video playback, extensive storage support, and HEVC H.265 compatibility.



The Micca G3 supports a robust array of media file formats, eliminating the need for conversion.

Setup

Follow these steps to set up your Micca G3 Digital Media Player:

1. **Insert Remote Control Batteries:** Open the battery compartment on the back of the remote control and insert two AAA batteries, observing the correct polarity.
2. **Connect to TV:**
    - **HDMI Connection (Recommended):** Connect one end of an HDMI cable (not included) to the HDMI OUT port (7) on the Micca G3 and the other end to an HDMI input on your TV or display.
    - **Analog AV Connection:** For older TVs, connect the included AV cable to the AV OUT port (5) on the Micca G3 and the corresponding composite video and stereo audio inputs on your TV.
3. **Connect Power:** Plug the power adapter into the DC 5V port (8) on the Micca G3, then plug the adapter into a wall outlet. The player will power on automatically.
4. **Insert Media:** Insert your USB flash drive or external hard drive into one of the USB 2.0 ports (3 or 6).

Alternatively, insert a MicroSD card into the MicroSD Reader slot (4).

The Micca G3 player and its accompanying remote control.

Detailed view of the Micca G3's front and back ports for connections.

Operating Instructions

Navigate and control your Micca G3 using the included remote control.

Basic Navigation

- Use the directional arrows (**UP**, **DOWN**, **LEFT**, **RIGHT**) to move through menus.
- Press **OK** to confirm a selection.
- Press **RETURN** or **EXIT** to go back to the previous screen or exit a menu.
- The colored buttons (**FILE**, **PHOTO**, **MUSIC**, **MOVIE**) provide quick access to media categories.

Media Playback

Once your media storage is connected, select the desired media type from the main menu (Movie, Music, Photo) or use the FILE button to browse all files.

- **Videos:** Select a video file and press**OK** to begin playback. Use the playback controls (Play/Pause, Stop,

Fast Forward, Rewind) on the remote.

- **Music:** Select an audio file or folder and press **OK**. The player supports various audio formats and can play music in the background.
- **Photos:** Select an image file to view it. You can also start a slideshow from a folder of images.

Digital Signage Features

The Micca G3 is equipped with features beneficial for digital signage:

- **Auto Playback:** Configure the player to automatically start playing media upon power-on.
- **Looping:** Set media to play in an endless loop for continuous display.
- **Resume Playback:** The player can resume from the last stopping point after being powered off.
- **Screen Rotation:** Adjust video output rotation to 90, 180, or 270 degrees for vertical displays. Access this setting in the player's display options.

Display Resolution Settings

For optimal viewing, configure the player's display resolution to match your TV's capabilities:

- Navigate to **Settings** > **Display Resolution**.
- Select **AUTO** (recommended for HDMI connections) or manually choose from available resolutions: 2160P, 1080P, 720P, 576P, 480P.

Maintenance

To ensure the longevity and optimal performance of your Micca G3 player:

- Keep the device in a cool, dry place, away from direct sunlight and excessive heat.
- Clean the exterior with a soft, dry cloth. Do not use liquid cleaners or aerosols.
- Avoid blocking ventilation openings on the device.
- Handle the remote control with care and replace batteries when necessary.

Troubleshooting

If you encounter issues with your Micca G3, refer to the following common problems and solutions:

- **No Power:** Ensure the power adapter is securely connected to the player and a working wall outlet.
- **No Picture/Sound:**
  - Check HDMI or AV cable connections to both the player and the TV.
  - Verify the correct input source is selected on your TV.
  - Ensure the display resolution setting on the player matches your TV's capabilities.
- **Cannot Play File:**
  - Confirm the file format is supported by the Micca G3 (refer to 'Robust Media Format Support' in Product Features).
  - Ensure the media file is not corrupted. Try playing another file.

- For MP4 files, if issues persist, consider converting them to a more standard MP4 profile using software like VLC Media Player.

- **External Hard Drive Not Recognized:** Ensure the hard drive is formatted with a Master Boot Record (MBR) partition style. Drives formatted with GPT (GUID Partition Table) may not be fully supported, especially for capacities over 2TB. Supported file systems include FAT/FAT32, exFAT, and NTFS.
- **Remote Control Not Responding:**
  - Check and replace the AAA batteries.
  - Ensure you are pointing the remote directly at the player's remote sensor (2) on the front. The remote is highly directional.
- **Firmware Updates:** Periodically check the official Micca website for firmware updates, which can improve performance and add new features. Updates can typically be found at miccatron.com.

SPECIFICATIONS

Product Dimensions	0.59 x 2.95 x 2.52 inches
Item Weight	2.19 ounces (62 Grams)
Model Name	Speck G3
Color	Black
Connectivity Technology	USB, HDMI
Connector Type	HDMI, Analog AV
Resolution	2K Quad-HD (upscaled to 4K HDMI output)
Manufacturer	Micca

Comparison of Micca media player models, highlighting key differences.

Warranty and Support

For warranty information and technical support, please visit the official Micca website or contact their customer service. Keep your purchase receipt for warranty claims.

Micca Store: Visit the Micca Store on Amazon

© 2024 Micca. All rights reserved.

Related Documents - Speck G3

	[Full HD 4K Digital Media Player User Manual] User manual for the Micca Speck G3/4K Digital Media Player (Model V8), detailing specifications, setup, connections, remote control functions, media playback for video, music, and photos, and system settings.
	[Micca MPLAY-HD Mini Digital Media Player Owner's Manual] User guide for the Micca MPLAY-HD Mini Digital Media Player, covering setup, connections, playback of movies, music, photos, settings, troubleshooting, and warranty information.
	[Micca Digital Photo Frame Owner's Manual: Setup, Features & Support] Explore the Micca Digital Photo Frame (Models M707Z, M808Z, M1010Z) with this owner's manual. Learn about setup, features like slideshows and media playback, troubleshooting tips, and warranty details. Visit miccatron.com for support.
	[Micca COVO-S Concentric Driver Bookshelf Speaker User Manual and Specifications] Detailed user manual and specifications for the Micca COVO-S Concentric Driver Bookshelf Speaker, covering setup, placement, amplifier considerations, and technical details.
	[Micca RB42 4-Inch 2-Way Bookshelf Speaker Manual and Specifications] Detailed information on the Micca RB42 4-inch 2-way bookshelf speaker, including placement recommendations, connection guides, technical specifications, and amplifier considerations.
	[Micca N-Series Digital Photo Frame Owner's Manual - N7, N8, N10] Comprehensive owner's manual for the Micca N-Series Digital Photo Frame (Models N7, N8, N10), covering setup, operation, features, troubleshooting, specifications, and warranty information.

[pdf] User Manual Owner's Manual Troubleshooting Guide Specifications Warranty

Micca Speck G3 4K User Manual rentex 2024 05 |||

micca Speck Digital Media Player Owner s Manual Models:**Speck G3**, Speck 4K Got a Question or Need Help Email our technical support team at: support miccatron.com for personalized assistance with the setup and use of this product. Please visit our product information website www.miccatron.com for t...

lang:en score:51 filesize: 860.43 K page_count: 22 document date: 2023-08-16

[pdf] User Manual Owner's Manual Troubleshooting Guide Specifications Warranty

Micca Speck G3 4K User s Manual Digital Media Player Electronics miccatron 2022 08 |||

Speck Digital Media Player Owner s Manual Models:**Speck G3**, Speck 4K Got a Question or Need Help Email our technical support team at: support miccatron.com for personalized assistance with the setup and use of this product. Please visit our product information website www.miccatron.com for the fol...

lang:en score:48 filesize: 1.46 M page_count: 22 document date: 2022-07-20

[pdf] User Manual Owner's Manual Troubleshooting Guide Specifications Warranty

Micca Speck G3 4K User s Manual Digital Media Player Electronics V240824 miccatron 2023 02 |||

micca Speck Digital Media Player Owner s Manual Models:**Speck G3**, Speck 4K Got a Question or Need Help Email our technical support team at: support miccatron.com for personalized assistance with the setup and use of this product. Please visit our product information website www.miccatron.com for t...

lang:en score:48 filesize: 1.07 M page_count: 24 document date: 2024-08-25

[pdf] User Manual Owner's Manual Troubleshooting Guide Specifications Warranty

Speck Digital Media Player 7 févr 2023 — Packing List G3 4K media player AC power adapter remote control analog AV cable user s manual Note All the information contained in this manual Micca User Manual miccatron 02 |||

Speck Digital Media Player Owner s Manual Models:**Speck G3**, Speck 4K Got a Question or Need Help Email our technical support team at: support miccatron.com for personalized assistance with the setup and use of this product. Please visit our product information website www.miccatron.com for the fol...

lang:en score:38 filesize: 850.31 K page_count: 22 document date: 2023-02-17

[pdf] User Manual Specifications Dimension Guide

Micca Speck G3 4K User Manual Full HD Digital Media Player▫ Weight 2 Ounce 62 gram player only ▫ Packing List media AC power adapter remote control analog AV cable user s manual Page A1F A4nHhTLm amazon images I A1F A4nHhTL |||

Full HD 4K Digital Media Player User Manual Models: V8 1 Introduction 1.1 Specifications 1.1.1 Vid ... ensions: 3 x 2.5 x 0.6 75 x 64 x 15mm Weight: 2.2 Ounce 62 gram , player only Packing List: **Speck G3**/4K media player, AC power adapter, remote control, analog AV cable, user s manual Page 1 ...

lang:en score:27 filesize: 1.3 M page_count: 17 document date: 2025-04-17

[pdf]

7 bigmao Aliyun Micca 4K Ultra HD Multimedia Player for USB and MicroSD Auto Playback Support H 265 HEVC 264 AVC MP4 MKV MP3 JPG HDMI Output Analog AV Digital Signage Amazon it Electronics A1QO5n6Z6oL m media amazon images I |||

micca Lettore Multimediale Digitale Speck Manuale del proprietario Modelli: **Speck G3**, Speck 4K Hai una domanda o hai bisogno di aiuto Invia un email al nostro team di supporto tecnico: support miccatron.com per assistenza personalizzata con l installazione e l uso di questo prodotto. Visita il no...

lang:it score:26 filesize: 1.39 M page_count: 23 document date: 2024-09-03

Full HD 4K Digital Media Player User Manual

User manual for the Micca Speck G3/4K Digital Media Player (Model V8), detailing specifications, setup, connections, remote control functions, media playback for video, music, and photos, and system settings.

lang:en score:25 filesize: 1.3 M page_count: 17 document date: 2025-04-17

[pdf] User Manual Specifications Dimension Guide

Micca Speck G3 4K User Manual Istruzioni per l uso ZUMKUNM Lettore multimediale digitale UHD e 1080P unità USB schede MicroSD Digital Signage H 265 HEVC 264 AVC MP4 MKV Video MP3 Music JPG Photos HDMI Analogico AV Auto Play and Resume Amazon it Elettronica B13f9o1quqL m media amazon images I |||

Full HD 4K Digital Media Player User Manual Models: X8 1 Introduction 1.1 Specifications 1.1.1 Vi ... ensions: 3 x 2.5 x 0.6 75 x 64 x 15mm Weight: 2.2 Ounce 62 gram , player only Packing List: **Speck G3**/4K media player, AC power adapter, remote control, analog AV cable, user s manual Page 1 ...

lang:en score:23 filesize: 2.29 M page_count: 22 document date: 2022-09-29

[pdf] User Manual

8 bigmao Aliyun Speck Digitaler MedienPlayer A1upDFYWFfL ref dp product quick view m media amazon images I |||

micca Speck Digitaler MedienPlayer Handbuch des Modelle:**Speck G3**, Speck 4K Hast du eine Frage oder brauchst du Hilfe E-Mail unserem technischen Support-Team unter: support miccatron.com Fr personalisierte Untersttzung bei der Einrichtung und Verwendung dieses Produkts. Bitte besuchen Sie unsere P...

lang:de score:20 filesize: 1.42 M page_count: 24 document date: 2024-09-03

[pdf] User Manual Instructions Guide

MediaPlayerQuickGuide d1bdilxpumkn65 cloudfront net assets media resources |||

Media Player Quick Guide The use of a USB Flash Drive is preferred. Avoid using SD cards if possibl ... AVI, MOV, MP4, codec H.264, NTSC Maximum Video Resolution Speck 4K: 4096x2304 30fps, up to 200mbps **Speck G3**: 2560x1440 60fps, up to 100mbps Speck G2: 1920x1080 30fps, up to 10mbps To loop your file,...

lang:en score:20 filesize: 38.99 K page_count: 1 document date: 2024-04-29