Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

MINISO 2011824210108

MINISO Gaming Mouse Pad Instruction Manual

Model: 2011824210108

1. Product Overview

The MINISO Gaming Mouse Pad is an extra-large desk mat designed to enhance your gaming and work experience. It features a spacious surface, vibrant RGB lighting, a durable waterproof coating, and a stable non-slip base. This manual will guide you through its setup, operation, and maintenance to ensure optimal performance.




Image 1.1: The MINISO Gaming Mouse Pad showcasing its extra-large size and illuminated RGB edges.

2. Setup Instructions

Setting up your MINISO Gaming Mouse Pad is a simple plug-and-play process.

1. **Unpack the Mouse Pad:** Carefully remove the mouse pad from its packaging. Unroll it and lay it flat on your desired desk surface. Allow some time for any creases from packaging to flatten out.
2. **Connect USB Cable:** Locate the integrated USB cable on the mouse pad. Plug the USB connector into an available USB port on your computer, laptop, or a compatible USB power adapter.
3. **Power On:** The RGB lighting should illuminate automatically upon connection. If not, locate the control button on the mouse pad (typically near the USB connection point) and press it to turn on the lighting.



Image 2.1: Top-down view of the mouse pad, showing the USB connection point for power.

3. Operating Instructions

The MINISO Gaming Mouse Pad features a single control button for managing its RGB lighting effects.

- **Changing Lighting Modes:** Press the control button repeatedly to cycle through the 10 available RGB lighting modes. These modes include various static colors and dynamic effects such as breathing lights.
- **Available Lighting Modes:**
  - Red
  - Blue
  - Green
  - Purple
  - Cyan
  - Yellow
  - Orange
  - Breathing Light Mode (cycles through colors)
  - And other dynamic lighting effects.
- **Adjusting Brightness:** Some modes may allow for brightness adjustment. Consult the product packaging or specific model details for this feature.
- **Turning On/Off:** Press and hold the control button for approximately 3 seconds to turn the RGB lighting on or off.

4. Care and Maintenance

Proper care will ensure the longevity and performance of your MINISO Gaming Mouse Pad.

- **Cleaning the Surface:** The mouse pad features a waterproof surface. In case of spills (coffee, tea, juice), gently wipe the surface with a damp cloth. Avoid using harsh chemicals or abrasive cleaners.
- **Dust Removal:** For general dust, use a soft, dry cloth or a microfiber cloth to wipe down the surface.
- **Avoid Submersion:** Do not submerge the mouse pad in water or expose the USB connector to liquids, as this can damage the electronic components.
- **Storage:** When not in use for extended periods, you can gently roll the mouse pad for storage. Avoid sharp folds or creasing the RGB light strip.




Image 4.1: Close-up view of the mouse pad's edge, highlighting the superfine fiber braided material and the integrated RGB lighting strip.

5. Troubleshooting Guide

If you encounter any issues with your MINISO Gaming Mouse Pad, please refer to the following common solutions:

Problem	Possible Cause	Solution
RGB lights do not turn on.	No power, loose connection, or lights are off.	Ensure the USB cable is securely plugged into a working USB port. Press the control button to turn on the lights. Try a different USB port or power source.
Lights are flickering or inconsistent.	Insufficient power or faulty connection.	Ensure the USB port provides sufficient power (e.g., a direct port on your computer, not a low-power hub). Re-plug the USB cable.
Mouse pad slides on desk.	Desk surface is too smooth or dirty.	Ensure the desk surface is clean and dry. The non-slip rubber base requires a clean surface for optimal grip.
Mouse tracking is inconsistent.	Surface dirt or mouse sensor issue.	Clean the mouse pad surface and the optical sensor of your mouse. Ensure your mouse settings are appropriate for a fabric surface.

6. Product Specifications

Feature	Detail
Model Number	2011824210108
Dimensions (L x W x H)	27.5 x 11.8 x 0.04 inches (70 x 30 x 0.1 cm)
Material	Superfine fiber braided material (surface), Non-slip rubber (base)
Lighting Modes	10 RGB lighting modes (including static colors and breathing effects)
Power Source	USB Powered (Plug and Play)
Special Features	Waterproof surface, Non-slip base, One-button control
Color	Black

7. Warranty and Support

MINISO is committed to providing high-quality products. For specific warranty details regarding your Gaming Mouse Pad, please refer to the warranty card included with your purchase or visit the official MINISO website.
If you require technical assistance, have questions about product functionality, or need to report a defect, please contact MINISO customer support through their official channels. Keep your purchase receipt or order number handy for faster service.
You can find more information and contact details on theMINISO Store on Amazon.

© 2023 MINISO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B2D1HDPH

More documents and user manuals: **https://manuals.plus/**