Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

NEBO Slim+ 1200

NEBO Slim+ 1200 Pocket Light User Manual

Powerful and Rechargeable 1200 Lumen Pocket Light with Power Bank

1. Product Overview

The NEBO Slim+ 1200 is a versatile and compact lighting solution designed for everyday use. It features a powerful 1200 lumen output, a rechargeable USB-C battery, and a built-in power bank to charge your mobile devices. Its sleek design, magnetic pocket clip, and magnetic base provide convenient hands-free lighting options.

Key Features:

- **1200 Lumen Output:** Provides bright illumination for various tasks.
- **USB-C Rechargeable:** Offers fast and efficient charging times.
- **Integrated Power Bank:** Allows you to recharge your devices on the go.
- **Compact and Slim Design:** Easy to carry and store.
- **Magnetic Pocket Clip:** Securely attaches to clothing or surfaces.
- **Powerful Magnetic Base:** Enables hands-free lighting on metallic surfaces.
- **Multiple Light Modes:** Includes white COB, red COB, and red laser.
- **IPX7 Waterproof:** Fully submersible in up to 1 meter of water for up to 30 minutes.





Image: Front view of the NEBO Slim+ 1200 pocket light, showcasing its main light and sleek design.

2. Setup

2.1 Unboxing

Carefully remove all components from the packaging. Ensure the following items are present:

- NEBO Slim+ 1200 Pocket Light
- USB-C Charging Cable
- User Manual (this document)

2.2 Initial Charge

Before first use, fully charge your NEBO Slim+ 1200. This ensures optimal battery performance and longevity.

1. Locate the USB-C charging port on the device.
2. Connect the provided USB-C cable to the light.
3. Plug the other end of the USB-C cable into a compatible USB power source (e.g., wall adapter, computer USB port).
4. The charging indicator light will show the charging status. Refer to the device's specific indicator behavior for full charge notification (e.g., solid green light).
5. Once fully charged, disconnect the cable.



Image: The NEBO Slim+ 1200 connected to a USB-C charging cable, illustrating its rechargeable capability.

3. Operating Instructions

3.1 Power On/Off

To turn the light on or off, press the power button located on the side of the device.

3.2 Light Modes

The NEBO Slim+ 1200 features multiple light modes. Cycle through the modes by pressing the power button repeatedly while the light is on.

- **White COB (Chip-on-Board) Light:** Provides a broad, even beam of white light. This is the primary illumination mode.
- **Red COB Light:** Emits a red light, useful for preserving night vision or for signaling.
- **Red Laser:** A focused red laser pointer for quick visual acquisition or pointing.



Image: The NEBO Slim+ 1200 emitting a red COB light, demonstrating its utility for preserving night vision.



Image: The NEBO Slim+ 1200 showing its red laser functionality, useful for quick visual acquisition.

3.3 Hands-Free Operation

Utilize the integrated magnetic features for convenient hands-free lighting:

- **Magnetic Pocket Clip:** Attach the light to your pocket, belt, or other fabric edges.
- **Powerful Magnetic Base:** Securely attach the light to any ferrous metal surface for stable, directional lighting.



Image: The NEBO Slim+ 1200 demonstrating its magnetic base, allowing it to attach to metal surfaces for hands-free use.

3.4 Power Bank Functionality

The Slim+ 1200 can act as a power bank to charge other USB-powered devices.

1. Connect your device's charging cable to the USB-A output port on the Slim+ 1200.
2. The Slim+ 1200 will begin charging your device.
3. Monitor your device's charging status.



Image: The NEBO Slim+ 1200 connected to a smartphone via a charging cable, illustrating its power bank capability.

4. Maintenance

4.1 Cleaning

To maintain the appearance and functionality of your Slim+ 1200:

- Wipe the exterior with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the USB-C port cover is securely closed to maintain water resistance.

4.2 Storage

When not in use for extended periods:

- Store the device in a cool, dry place.

- Avoid extreme temperatures.

4.3 Battery Care

To prolong battery life:

- Recharge the battery regularly, even if not fully depleted.
- Avoid completely draining the battery before recharging.

5. Troubleshooting

If you encounter issues with your NEBO Slim+ 1200, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Light does not turn on.	Battery is depleted.	Charge the device using the provided USB-C cable.
Light output is dim.	Low battery.	Recharge the device.
Device not charging.	Faulty cable or power source.	Try a different USB-C cable or power adapter. Ensure connections are secure.
Power bank not charging external device.	Slim+ 1200 battery is low or depleted.	Ensure the Slim+ 1200 is sufficiently charged.
Water ingress after submersion.	USB-C port cover not sealed properly.	Ensure the USB-C port cover is fully and securely closed before exposing to water.

6. Specifications

Feature	Detail
Model Name	Slim+ 1200
Light Output	1200 Lumens (White Brightness)
Light Source Type	LED (COB)
Power Source	Battery Powered (USB-C Rechargeable)
Battery Type	Lithium Ion (1 included)
Material	Aluminum
Color	Storm Gray
Item Weight	0.5 Pounds
Water Resistance Level	IPX7 Waterproof (Submersible up to 1 meter for 30 minutes)
Item Package Dimensions	6 x 3 x 2 inches

Feature	Detail
UPC	645397002888
ASIN	B0B2FBRRK3

7. Warranty Information

The NEBO Slim+ 1200 comes with a**1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or neglect.

Please retain your proof of purchase for warranty claims.

8. Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official NEBO store or contact their customer service:

- **NEBO Official Store:** Visit NEBO Store on Amazon
- Refer to the product packaging or NEBO's official website for direct contact information.

© 2025 NEBO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B2FBRRK3

More documents and user manuals: **https://manuals.plus/**