Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

DURACELL SIOC AA+AAA 56ct

Duracell Coppertop AA + AAA Batteries User Manual

Dependable power for your everyday devices.

Introduction

The Duracell Coppertop AA and AAA batteries with POWER BOOST™ Ingredients are designed to deliver dependable power to a wide range of your everyday devices. This pack contains 28 Double A Batteries and 28 Triple A Batteries, offering a versatile solution for household and office electronics.

These batteries are formulated for lasting performance and come with a guarantee of 12 years in storage, ensuring they are ready when you need them most. Duracell also guarantees these batteries against defects in material and workmanship, providing quality you can trust.

The re-closable packaging allows for quick, easy access and organized storage, making them convenient for various uses, from storm season preparedness to powering essential devices during holidays.



Image: Duracell battery highlighting its manufacturing origin, 'Built in the USA' with US & Global Parts.

Key Features

- **POWER BOOST™ Ingredients:** Formulated with Duracell's exclusive POWER BOOST™ Ingredients for lasting performance.
- **12-Year Storage Guarantee:** Guaranteed to last 12 years in storage, ensuring readiness when needed.
- **Re-closable Packaging:** Designed for quick, easy access and organized storage.
- **Quality Assurance:** Guaranteed against defects in material and workmanship.

Setup and Installation

Duracell Coppertop AA and AAA batteries are designed for easy installation in compatible devices. Follow these general guidelines:

1. **Identify Battery Type:** Ensure your device requires AA or AAA batteries. This pack contains both types.

2. **Open Battery Compartment:** Locate and open the battery compartment on your device. Refer to your device's manual if unsure.
3. **Observe Polarity:** Insert the batteries according to the polarity indicators (+ and -) inside the compartment. Incorrect insertion can prevent the device from functioning and may damage the batteries or device.
4. **Close Compartment:** Securely close the battery compartment.
5. **Test Device:** Turn on your device to confirm proper battery installation and functionality.



Image: Duracell Coppertop AA and AAA batteries in their re-closable packaging, ready for use.

Operating Instructions

Once installed, Duracell Coppertop batteries provide reliable power for various applications. They are suitable for both low-drain devices (like remote controls and clocks) and high-drain devices (like digital cameras and gaming controllers) due to their POWER BOOST™ Ingredients.

- **General Use:** Use these batteries in any device requiring AA or AAA alkaline batteries.
- **Performance:** Expect consistent and long-lasting power output.
- **Device Compatibility:** Ideal for toys, remote controls, smoke detectors, flashlights, calculators, clocks, radios, wireless mice, keyboards, and more.



Image: A diagram illustrating the unique blend of Nickel & Lithium in Duracell Power Boost batteries compared to other batteries.

Maintenance and Storage

Proper maintenance and storage can extend the life and ensure the readiness of your Duracell Coppertop batteries.

- **Storage:** Store batteries in a cool, dry place at room temperature. Avoid extreme temperatures.
- **Shelf Life:** These batteries are guaranteed for 12 years in storage. Check the "Best Before" date on the packaging.
- **Leakage Prevention:** Duracell batteries are designed to be leak-resistant. However, it is good practice to remove batteries from devices that will not be used for extended periods to prevent potential damage from leakage.
- **Disposal:** Dispose of used batteries according to local regulations. Many communities offer battery recycling programs. Do not dispose of batteries in fire.



Image: A Duracell battery highlighting its 12-year storage guarantee.

Troubleshooting

If you encounter issues with your Duracell Coppertop batteries, consider the following:

Problem	Possible Cause	Solution
Device not powering on.	Incorrect battery insertion, depleted batteries, or device malfunction.	Check polarity (+/-). Replace with new batteries. Test device with known working batteries.
Short battery life.	High-drain device, old batteries, or environmental factors.	Ensure batteries are fresh. For high-drain devices, battery life will naturally be shorter. Avoid extreme temperatures.

Problem	Possible Cause	Solution
Battery leakage.	Over-discharge, extreme temperatures, or prolonged non-use in device.	Remove leaking batteries carefully (wear gloves). Clean compartment. Dispose of batteries properly. Avoid mixing old and new batteries.

Specifications

Attribute	Detail
Product Dimensions	9.5 x 5.06 x 2.13 inches
Item Weight	2.6 pounds
ASIN	B0B2KWJ252
Item Model Number	SIOC AA+AAA 56ct
Batteries Included	28 AA batteries, 28 AAA batteries
Brand	DURACELL
Battery Cell Composition	Alkaline
Recommended Uses	Baby Monitor, Camera, Clock, Gaming Controller, Power Tool
Unit Count	56.0 Count
Manufacturer	Duracell Distributing, Inc
Date First Available	May 27, 2022

Warranty and Support

Duracell guarantees these batteries against defects in material and workmanship. For specific warranty details or support, please refer to the official Duracell website or contact Duracell customer service directly.
Manufacturer: Duracell Distributing, Inc
Return Policy: 30-day refund/replacement policy when purchased from Amazon.
For further assistance, visit the DURACELL Store on Amazon.

© 2024 Duracell. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B2KWJ252

More documents and user manuals: **https://manuals.plus/**