Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Biolomix T5600

BioloMix High-Performance Blender T5600 User Manual

Model: T5600

1. Important Safety Instructions

Please read all instructions carefully before operating the BioloMix T5600 High-Performance Blender. Retain this manual for future reference.

- **Electrical Safety:** Ensure the voltage matches your power supply. Do not immerse the motor base, cord, or plug in water or other liquids. Unplug from outlet when not in use, before cleaning, or before assembling/disassembling parts.
- **Blade Safety:** The blades are extremely sharp. Handle with extreme care when assembling, disassembling, or cleaning. Always ensure the blender is unplugged before touching the blades.
- **Operation Safety:**
  - Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
  - Always operate the blender with the lid securely in place.
  - Do not overfill the container. Observe the MAX fill line.
  - Never place hands or other utensils into the container while blending to avoid serious injury. Use the tamper only when the lid is on and the blender is running.
  - The blender features an **overheat protection** system. If the motor overheats, it will automatically shut off. Allow it to cool down for at least 20-30 minutes before resuming operation.
  - A **safety lock mechanism** ensures the blender will not operate unless the pitcher is correctly seated on the motor base.
- **Material Safety:** The pitcher and lid are made from BPA-free food-grade material, ensuring safe food preparation.
- **Children:** This appliance is not intended for use by children. Close supervision is necessary when any appliance is used near children.

2. Product Overview

The BioloMix T5600 High-Performance Blender is designed for versatile blending tasks, from smoothies and juices to grinding and hot soups. Familiarize yourself with its components:

- **Motor Base:** Houses the powerful 2200W motor and control panel.

- **2L Blending Pitcher:** Large capacity container with 304 stainless steel blades, suitable for most blending needs.
- **500ml Grinding Cup:** Smaller container with a dedicated blade for grinding coffee beans, spices, and nuts.
- **Lid:** Securely fits both containers, featuring a removable cap for adding ingredients during blending.
- **Tamper:** Used to push down thick or frozen ingredients towards the blades for smoother blending.



Figure 2.1: BioloMix T5600 Blender and its main accessories.

The control panel offers intuitive operation:

- **ON/OFF Switch:** Powers the unit on or off.
- **Speed Dial:** Provides variable speed control for precise blending.
- **PULSE Button:** Activates short bursts of high-speed blending for chopping or quick mixing.
- **Pre-set Program Buttons:** Six intelligent programs for common blending tasks (Juice, Smoothie, Ice Crush, Soup, Grinding, Sauce).



Figure 2.2: Detailed view of the BioloMix T5600 control panel.

3. Setup

Follow these steps to set up your BioloMix T5600 Blender for first use:

1. **Unpack:** Carefully remove all components from the packaging. Retain packaging for storage or future transport.
2. **Initial Cleaning:** Before first use, wash the blending pitcher, grinding cup, lids, and tamper with warm soapy water. Rinse thoroughly and dry all parts. The motor base should only be wiped with a damp cloth.
3. **Place the Motor Base:** Position the motor base on a clean, dry, stable, and flat surface. Ensure there is adequate ventilation around the unit.
4. **Assemble the Container:**
    - Choose either the 2L blending pitcher or the 500ml grinding cup based on your blending needs.
    - Place the chosen container onto the motor base. Align the container with the base and rotate it slightly until it clicks securely into place. The safety lock mechanism will prevent operation if not correctly seated.
    - Ensure the lid is properly secured on the container before operation.

5. **Connect Power:** Plug the power cord into a suitable electrical outlet.



Figure 3.1: Correct placement of the blending pitcher on the motor base.

4. Operating Instructions

The BioloMix T5600 offers both manual control and convenient pre-set programs for various blending tasks.

4.1 General Operation

1. **Add Ingredients:** Place your desired ingredients into the blending pitcher or grinding cup. Do not exceed the MAX fill line. For best results, add liquids first, then soft ingredients, then harder ingredients, and finally ice or frozen items.
2. **Secure Lid:** Place the lid firmly onto the container. Ensure the removable cap is also in place unless you intend to add ingredients during blending or use the tamper.
3. **Power On:** Flip the ON/OFF switch to the 'ON' position. The display will illuminate.
4. **Select Speed or Program:**

- **Variable Speed Control:** Rotate the speed dial to adjust the blending speed from low to high. Start at a lower speed and gradually increase as needed.
- **PULSE Function:** Press and hold the PULSE button for short bursts of high-speed blending. Release the button to stop. This is ideal for chopping, quick mixing, or breaking down stubborn ingredients.
- **Pre-set Programs:** Press one of the six pre-set program buttons (Juice, Smoothie, Ice Crush, Soup, Grinding, Sauce). The blender will automatically run through a pre-programmed cycle optimized for that task. The display will show the remaining time.

5. **Using the Tamper:** For very thick mixtures or when processing frozen ingredients, remove the cap from the lid and use the tamper to push ingredients towards the blades. *Never use any other utensil.*
6. **Stop Blending:** Once desired consistency is achieved, turn the speed dial to 'OFF' or press the ON/OFF switch to 'OFF'. Unplug the blender from the power outlet.



Figure 4.1: Manual speed and time adjustment on the control panel.

4.2 Pre-set Programs

The BioloMix T5600 features 6 intelligent pre-set programs for optimal results with minimal effort:

- **Juice:** Ideal for extracting fresh juices from fruits and vegetables.
- **Smoothie:** Perfect for creamy, lump-free smoothies, including those with ice.
- **Ice Crush:** Specifically designed to crush ice cubes efficiently for frozen drinks or desserts.
- **Soup:** Blends and heats ingredients to a steaming hot soup in approximately six minutes.
- **Grinding:** For dry ingredients like coffee beans, spices, and nuts, producing fine powders or coarse grinds. Use the 500ml grinding cup for best results.
- **Sauce:** Creates smooth sauces, purees, and dips.



Figure 4.2: The six pre-set intelligent programs available on the BioloMix T5600.



Figure 4.3: Examples of results achievable with the BioloMix T5600 Blender, including juices, smoothies, and ground items.

5. Maintenance and Cleaning

Proper cleaning and maintenance will ensure the longevity and optimal performance of your BioloMix T5600 Blender.

5.1 Self-Cleaning Function

The self-cleaning function makes daily cleaning quick and easy:

1. After use, rinse the container to remove large food particles.
2. Fill the container with approximately 700ml of warm water and add a drop of dish soap.
3. Secure the lid and place the container on the motor base.
4. Select the PULSE function and run for 5-10 seconds.
5. Empty the soapy water, rinse the container thoroughly with clean water, and let it air dry.



Figure 5.1: The self-cleaning process for the BioloMix T5600 Blender.

5.2 Manual Cleaning

- **Containers and Lids:** For a more thorough clean, disassemble the pitcher/grinding cup and lid. Wash them with warm, soapy water using a non-abrasive sponge or brush. Rinse well and dry completely. *The containers and lids are not dishwasher safe.*
- **Motor Base:** Wipe the motor base with a soft, damp cloth. Do not use abrasive cleaners or scouring pads. *Never immerse the motor base in water or any other liquid.*
- **Blades:** Exercise extreme caution when cleaning the blades due to their sharpness. Use a brush to clean around the blades.

6. Troubleshooting

If you encounter issues with your BioloMix T5600 Blender, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Blender does not turn on.	• Not plugged in. • Container not properly seated. • Overheat protection activated.	• Ensure power cord is securely plugged into a working outlet. • Check that the pitcher/grinding cup is correctly aligned and locked onto the motor base. • Unplug the unit and allow it to cool down for 20-30 minutes before restarting.
Ingredients are not blending smoothly.	• Too little liquid. • Ingredients are too large or packed too tightly. • Air pocket around blades.	• Add more liquid. • Cut ingredients into smaller pieces. • Use the tamper to push ingredients towards the blades. • Use the PULSE function to break up ingredients.

Problem	Possible Cause	Solution
Loud noise or vibration during operation.	• Container not properly seated. • Unstable surface. • Hard ingredients.	• Ensure container is securely locked onto the base. • Place the blender on a flat, stable, and level surface. • This is normal for hard ingredients like ice or frozen fruit; ensure ingredients are not too large.
Burning smell from motor.	• Overloading the motor. • Overheat protection.	• Reduce the amount of ingredients. • Unplug and allow the motor to cool down completely (20-30 minutes).

If the problem persists after trying these solutions, please contact customer support.

7. Specifications

Feature	Detail
Model Number	T5600
Brand	Biolomix
Power	2200 Watts
Voltage	220V
Main Pitcher Capacity	2000 Milliliters (2L)
Grinding Cup Capacity	500 Milliliters
Blades	6 Hardened Pro Stainless Steel Blades
Dimensions (L x W x H)	19 x 21 x 47 cm
Weight	4.41 Kilograms
Material	BPA-free Food-Grade Plastic (Containers), Metal (Motor components)
Special Features	Self-cleaning function, Integrated timer, 6 automatic iQ pre-set programs, Variable speed control, Overheat protection, Safety lock mechanism.

8. Warranty and Support

BioloMix stands behind the quality of its products. Your T5600 High-Performance Blender comes with the following warranty:

- **Extended Motor Warranty:** 2 years
- **Parts and Accessories Warranty:** 1 year

The product warranty is automatically valid via your Amazon order ID. No additional certification or registration is required.

For any questions, concerns, or warranty claims, please contact BioloMix customer service. Our team aims to respond to inquiries within 24 hours.

You can find more information and products on the official BioloMix brand store: BioloMix Brand Store

© 2025 BioloMix. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B3J9F87R

More documents and user manuals: **https://manuals.plus/**