Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Lexus RX 350, RX 350L

2021 Lexus RX 350 and RX 350L Owner's Manual

Your comprehensive guide to operating and maintaining your Lexus vehicle.

1. Introduction

This owner's manual provides detailed information about the operation, features, and maintenance of your 2021 Lexus RX 350 or RX 350L. To ensure safe and proper use of your vehicle, please read this manual thoroughly before operating the vehicle and keep it in the vehicle for future reference. This manual covers all equipment, including options. Therefore, you may find some explanations for equipment not installed on your vehicle.
For your safety, pay close attention to warnings and cautions throughout this manual. They are designed to prevent personal injury and damage to your vehicle.

2. Getting Started and Initial Setup

This section guides you through the initial familiarization with your Lexus RX 350/350L.

2.1. Key and Door Operations

- **Smart Key System:** Learn how to use the smart key for locking, unlocking, and starting the vehicle without removing the key from your pocket or bag.
- **Mechanical Key:** Understand how to use the mechanical key for emergency entry.
- **Door Locks:** Manual and automatic locking/unlocking features.

2.2. Seat Adjustments and Driving Position

- **Front Seats:** Adjusting seat position, height, recline, and lumbar support.
- **Steering Wheel:** Tilt and telescopic adjustments for optimal driving posture.
- **Mirrors:** Adjusting side mirrors and rearview mirror for clear visibility.

3. Operating Your Vehicle

This section details the procedures for driving and utilizing the various features of your Lexus RX 350/350L.

3.1. Starting and Stopping the Engine

1. Ensure the shift lever is in P (Park).
2. Press the brake pedal firmly.

3. Press the engine START/STOP button.
4. To stop the engine, ensure the vehicle is stationary and the shift lever is in P, then press the engine START/STOP button.

3.2. Driving Controls

- **Transmission:** Understanding the shift lever positions (P, R, N, D, S).
- **Brakes:** Operation of the foot brake and parking brake.
- **Cruise Control:** Setting and adjusting vehicle speed.
- **Drive Mode Select:** Switching between ECO, Normal, and Sport modes.

3.3. Infotainment System

Your vehicle is equipped with a sophisticated infotainment system. Refer to the dedicated multimedia owner's manual for detailed instructions on navigation, audio, and connectivity features.

4. Maintenance and Care

Regular maintenance is crucial for the longevity and performance of your Lexus. Follow the recommended service schedule.

4.1. Scheduled Maintenance

Refer to the separate "Warranty and Services Guide" for the official maintenance schedule. Key items include:

- Engine oil and filter replacement
- Tire rotation and inspection
- Brake inspection
- Fluid level checks (coolant, brake fluid, power steering fluid, washer fluid)

4.2. Tire Care

- **Tire Pressure:** Check tire pressure regularly, including the spare tire, when tires are cold. Refer to the tire placard on the driver's side door jamb for recommended pressures.
- **Tire Rotation:** Rotate tires every 5,000 to 7,500 miles (8,000 to 12,000 km) to ensure even wear.

4.3. Cleaning and Protection

- **Exterior:** Wash regularly with mild car wash soap. Wax periodically to protect the paint.
- **Interior:** Vacuum carpets and upholstery. Wipe down surfaces with appropriate cleaners.

5. Troubleshooting

This section provides solutions to common issues you might encounter with your vehicle.

5.1. Warning Lights

If a warning light illuminates on the instrument cluster, consult this manual or your dealer immediately. Some common lights include:

- **Check Engine Light:** Indicates an issue with the engine or emissions system.
- **Low Tire Pressure Warning:** One or more tires are significantly underinflated.
- **Oil Pressure Warning:** Indicates low engine oil pressure. Stop the vehicle safely and turn off the engine immediately.

5.2. Common Issues

- **Engine won't start:** Check battery terminals, ensure shift lever is in P or N, check fuel level.
- **Flat tire:** Refer to the "Emergency Procedures" section in your full owner's manual for instructions on changing a tire.
- **Overheating:** If the engine temperature gauge indicates overheating, pull over safely, turn off the engine, and allow it to cool. Do not open the radiator cap when hot.

6. Specifications

Key specifications for the 2021 Lexus RX 350 and RX 350L are provided below. Note that specifications may vary based on trim level and region.

Category	RX 350	RX 350L
Engine Type	3.5L V6	3.5L V6
Horsepower	295 hp	290 hp
Transmission	8-speed automatic	8-speed automatic
Fuel Tank Capacity	19.2 gal (72.7 L)	19.2 gal (72.7 L)
Seating Capacity	5 passengers	6 or 7 passengers
Curb Weight (approx.)	4,222 lbs (1,915 kg)	4,525 lbs (2,052 kg)

Note: These specifications are for general reference. Please consult your vehicle's official documentation for precise figures.

7. Warranty and Support

Your Lexus vehicle is backed by a comprehensive warranty. For detailed information regarding warranty coverage, terms, and conditions, please refer to the separate "Warranty and Services Guide" provided with your vehicle.

7.1. Warranty Information

- **Basic Warranty:** Covers repairs and adjustments needed to correct defects in materials or workmanship of any part supplied by Lexus.
- **Powertrain Warranty:** Covers components such as engine, transmission, and drive systems.
- **Corrosion Perforation Warranty:** Covers perforation from corrosion.

Specific warranty periods and mileage limits apply. Please consult your official warranty booklet.

7.2. Customer Support

For assistance, service appointments, or further information, please contact your authorized Lexus dealer. You can also visit the official Lexus website for owner resources and support.
Lexus Official Website: www.lexus.com/owners
Roadside Assistance: Information for roadside assistance services can be found in your warranty booklet or on the Lexus owner's website.

Important Note on Media

This digital manual does not include embedded images or videos due to the absence of provided media assets. For

visual aids, please refer to your physical owner's manual or the official Lexus owner's website.

© 2021 Lexus. All rights reserved. Information is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B3QPP17M

More documents and user manuals: **https://manuals.plus/**