SOOMFON SF-PT002

SOOMFON SF-PT002 Extendable Selfie Stick Tripod User Manual

Model: SF-PT002

1. Introduction

Thank you for choosing the SOOMFON SF-PT002 Extendable Selfie Stick Tripod. This device is designed to enhance your mobile photography and videography experience, offering versatility as both a handheld selfie stick and a stable tripod. It features a detachable Bluetooth remote control for convenient operation. Please read this manual carefully to ensure proper use and optimal performance.

2. Product Overview

The SOOMFON SF-PT002 combines a selfie stick and a tripod into one compact unit. It is constructed from durable aluminum alloy and ABS materials, ensuring both lightness and stability.



Image: The SOOMFON SF-PT002 selfie stick tripod shown in its compact, folded state and fully extended as a tripod, demonstrating its dual functionality.

Key Components:

- **Extendable Rod:** Allows adjustment of length for selfie stick or tripod use.

- **Phone Holder:** Adjustable and rotatable clamp to secure your smartphone.
- **Foldable Tripod Legs:** Provides stable support when used as a tripod.
- **Detachable Bluetooth Remote Control:** For wireless photo and video capture.

3. Setup Instructions

3.1 Bluetooth Remote Pairing

1. Ensure the remote control has power. If it's new, remove any small plastic insulator from the battery compartment.
2. Press and hold the button on the Bluetooth remote until the indicator light turns green, indicating it is in pairing mode.
3. On your smartphone, go to Bluetooth settings and search for available devices.
4. Select "SF-PT002" (or similar name) from the list to pair. The indicator light on the remote will turn off or stop flashing once successfully paired.

Image: The detachable Bluetooth remote control, highlighting its compact design and battery life of over 30,000 photos per 120mAh coin cell battery.

3.2 Installing Your Smartphone

1. Gently pull open the phone holder clamp.
2. Place your smartphone securely into the clamp. The holder supports phones with widths between 17.72 to 35.43 inches (45-90mm).
3. Ensure your phone is centered and stable within the holder to prevent accidental drops.



Image: A visual guide demonstrating the simple steps to connect the Bluetooth remote, extend the rod, and install a smartphone onto the holder.

4. Operating Instructions

4.1 Selfie Stick Mode

- With the tripod legs folded, extend the rod to your desired length. The stick can extend from 8.66 inches (22cm) to 27.56 inches (70cm).
- Hold the handle firmly and use the Bluetooth remote to capture photos or start/stop video recording.

4.2 Tripod Mode

- Gently unfold the integrated legs at the base of the stick until they are fully extended and stable.
- Place the tripod on a flat, stable surface.
- Extend the rod to the desired height.
- Use the Bluetooth remote to operate your phone camera from a distance of up to 33 feet (10 meters).

Image: The selfie stick tripod illustrating its use in various scenarios, including as a compact selfie stick and an extended tripod, with height measurements.

4.3 Adjusting Phone Angle

- The phone holder features a 270-degree rotation capability.
- You can also adjust the phone's orientation between horizontal and vertical.
- Rotate the phone holder to achieve the optimal shooting angle for your photos or videos.

Image: A detailed view of the phone holder's adjustable angle, demonstrating its 270-degree rotation and 90-degree tilt for flexible shooting positions.

5. Maintenance

- Clean the device with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials.
- Store the selfie stick tripod in a cool, dry place away from direct sunlight and extreme temperatures.
- Ensure the Bluetooth remote control is securely stored when not in use to prevent loss.
- If the remote battery runs low, replace the coin cell battery.

6. Troubleshooting

6.1 Remote Control Not Working

- **Check Battery:** Ensure the remote's battery is not depleted. If new, verify that any plastic insulator tab has been removed from the battery compartment.
- **Re-pair:** Unpair the remote from your phone's Bluetooth settings and then attempt to pair it again following the instructions in Section 3.1.
- **Distance:** Ensure you are within the 33-foot (10-meter) operating range.

6.2 Phone Instability in Tripod Mode

- **Weight Limit:** The tripod has a maximum weight capacity of 450g (approximately 15.8 ounces). Exceeding this limit, especially with larger phones, may cause slight wobbling.
- **Surface:** Ensure the tripod is placed on a flat, stable, and level surface.
- **Phone Placement:** Verify that your phone is securely and centrally clamped in the holder.

7. Specifications

Feature	Specification
Model Number	SF-PT002
Material	Aluminum Alloy, ABS
Weight	200 Grams (approx. 6 ounces)
Folded Size	8.66 inches (22cm)
Minimum Height	8.66 inches (22cm)
Maximum Height	27.56 inches (70cm)
Phone Holder Width	17.72 - 35.43 inches (45-90mm)
Max Load Capacity	450 Grams
Bluetooth Remote Range	Up to 33 feet (10 meters)
Compatible Devices	Most iPhone and Android smartphones

8. Warranty and Support

SOOMFON products come with a standard manufacturer's warranty. For specific warranty details, please refer to the documentation included with your purchase or visit the official SOOMFON website. If you encounter any issues or have questions regarding your SF-PT002 selfie stick tripod, please contact SOOMFON customer support through the retailer where you purchased the product or via the contact information provided on the official SOOMFON website.