Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ENJBRICK 1018

ENJBRICK Bookshop Friends House Toy Building Set

Model: 1018

Brand: ENJBRICK

Introduction

Thank you for choosing the ENJBRICK Bookshop Friends House Toy Building Set. This detailed 640-piece kit allows you to construct a charming bookshop with intricate features, including a display window, bookshelves, a cozy reading nook, and two pet cats. Designed for enthusiasts aged 8 years and up, this set provides an engaging and rewarding building experience.



Image: The completed ENJBRICK Bookshop Friends House Toy Building Set, showcasing its detailed exterior and interior elements.

What's in the Box

Your ENJBRICK Bookshop Friends House Toy Building Set includes the following components:

- 640 building pieces
- Instruction manual
- 3 LR44 batteries (included for lighting features)
- Two pet cat figures

Setup and Assembly

Follow these steps to assemble your ENJBRICK Bookshop Friends House:

1. **Unpack Components:** Carefully open the packaging and sort the building pieces. It is recommended to organize

pieces by color and type to facilitate assembly.

2. **Review Instructions:** Familiarize yourself with the instruction manual. Each step is illustrated to guide you through the building process.
3. **Follow Step-by-Step:** Begin assembly by following the numbered steps in the manual. Ensure each piece is securely connected to prevent the model from becoming unstable.
4. **Attention to Detail:** Pay close attention to the placement of smaller, decorative pieces to accurately recreate the bookshop's intricate details, such as the display window, bookshelves, and reading nook.
5. **Install Pet Cats:** Once the main structure is complete, place the two pet cat figures in your desired locations within the bookshop.

Operating Instructions

This building set includes internal lighting features to enhance its display. Follow these instructions to operate the lights:

1. **Battery Installation:** Locate the battery compartment, typically on the underside or rear of the model. Open the compartment and insert the 3 LR44 batteries, ensuring correct polarity (+/-). Close the compartment securely.
2. **Activating Lights:** Find the small switch or button designed to activate the internal lights. Press or toggle the switch to turn the lights on or off.
3. **Display Features:** Explore the various detailed features of your bookshop, including the fully stocked bookshelves, the comfortable reading nook, and the inviting display window.

Maintenance

To ensure the longevity and appearance of your ENJBRICK Bookshop Friends House, follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth or a small, soft brush to gently remove dust from the model. Avoid using water or chemical cleaners, as these may damage the plastic pieces or electronic components.
- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration or warping of the plastic. If disassembling for storage, keep all pieces organized to prevent loss.
- **Battery Replacement:** If the lights dim or stop working, replace the LR44 batteries with new ones. Dispose of old batteries responsibly.

Troubleshooting

If you encounter any issues with your building set, refer to the following common solutions:

- **Missing Pieces:** Double-check all packaging materials. If a piece is genuinely missing, contact ENJBRICK customer support with your model number and the specific piece required.
- **Difficulty Connecting Pieces:** Ensure pieces are correctly oriented and aligned. Apply gentle, even pressure. Avoid excessive force, which can damage pieces.
- **Lights Not Working:** Verify that the batteries are correctly installed with the proper polarity. Check if the batteries are new and fully charged. Ensure the light switch is in the 'ON' position.
- **Unstable Structure:** Review the assembly steps to ensure all connections are secure and no steps were missed. Loose connections can lead to instability.

Specifications

Feature	Detail
Product Dimensions	5.91 x 6.3 x 6.3 inches
Item Weight	1.54 pounds
ASIN	B0B45W7FHH
Item Model Number	1018
Manufacturer Recommended Age	8 years and up
Batteries	3 LR44 batteries required (included)
Manufacturer	ENJBRICK

Warranty and Support

ENJBRICK stands behind the quality of its products. For any warranty claims, missing parts, or technical support, please refer to the contact information provided on the product packaging or visit the official ENJBRICK website. Keep your purchase receipt as proof of purchase.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B45W7FHH

More documents and user manuals: **https://manuals.plus/**