Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LOKITHOR LO-Case003

LOKITHOR J-Series EVA Protection Case Instruction Manual

Model: LO-Case003

Introduction

This manual provides comprehensive instructions for the LOKITHOR J-Series EVA Protection Case. This case is specifically designed to offer robust protection and convenient storage for your LOKITHOR J-Series jump starter and its accessories. Please read this manual thoroughly to ensure proper use and longevity of your product.

Package Contents

The LOKITHOR J-Series EVA Protection Case package includes:

- 1 x LOKITHOR J-Series EVA Protection Case (Model: LO-Case003)

Note: Jump starter and accessories are not included with the protection case.

Key Features

- **All-Round Protection:** Constructed from rugged and hard-wearing EVA material, this case effectively shields against accidental collisions, dents, and scratches. It offers waterproof, shockproof, and dustproof functionality to safeguard your device.
- **Easy Portability:** Equipped with a non-slip handle, the case allows for easy transportation of your jump starter and its accessories, keeping them together and secure.
- **Dual Functional Compartments:** The case features two distinct compartments. The top layer is designed to hold various accessories, while the bottom compartment provides a perfect, custom fit for your jump starter unit.
- **Customized Fit:** Specifically designed to accommodate LOKITHOR J-Series jump starters, including models J400, J401, J401X, J402, J1350 PRO, J2250 PRO, JP400, JT400, and JC400. Each model has a dedicated slot for thorough protection.

Setup and Usage

1. **Opening the Case:** Unzip the dual zippers completely to open the case. The zippers are designed for smooth operation and secure closure.
2. **Placing the Jump Starter:** Carefully place your LOKITHOR J-Series jump starter into the bottom compartment. The compartment is molded to fit the device snugly, preventing movement during transport.
3. **Organizing Accessories:** Utilize the zippered mesh pocket in the top lid to store charging cables, jumper clamps, and other small accessories. This helps keep all components organized and easily accessible.

4. **Closing the Case:** Ensure all items are securely placed within their compartments. Close the case by pulling the dual zippers together until fully sealed. The non-slip handle can then be used for carrying.

Maintenance

- **Cleaning:** Wipe the exterior of the case with a damp cloth to remove dust or dirt. For stubborn stains, a mild soap solution can be used. Ensure the case is completely dry before closing or storing.
- **Storage:** Store the case in a cool, dry place away from direct sunlight and extreme temperatures to maintain the integrity of the EVA material.
- **Inspection:** Periodically check the zippers and the case material for any signs of wear or damage.

Troubleshooting

This product is a passive protection case. Troubleshooting is generally not applicable. If you encounter any issues with the case's functionality (e.g., zipper malfunction, material damage), please refer to the warranty information for support.

Specifications

Attribute	Detail
Brand	LOKITHOR
Model Number	LO-Case003
Material	EVA (Ethylene-vinyl acetate)
Product Dimensions	6.17"D x 10.20"W x 4.70"H (External)
Item Weight	435 Grams (15.3 ounces)
Protection Features	Waterproof, Shockproof, Dustproof (IP65 rated)

Warranty and Support

The LOKITHOR J-Series EVA Protection Case comes with a **24-month extended warranty**. For any questions, concerns, or to claim warranty service, please feel free to contact LOKITHOR customer support.

Product Media

Images



Figure 1: Front view of the LOKITHOR J-Series EVA Protection Case when closed. The case features the LOKITHOR logo prominently on its hard shell surface.



Figure 2: Technical drawing illustrating the external dimensions of the LOKITHOR J-Series EVA Protection Case: 10.2 inches (260mm) long, 6.7 inches (170mm) wide, and 4.7 inches (120mm) high.



Figure 3: The LOKITHOR J-Series EVA Protection Case opened, revealing two functional compartments. The bottom section is designed for the jump starter, while the top zippered pocket holds accessories like clamps and cables.



Figure 4: The LOKITHOR J-Series EVA Protection Case being splashed with water, highlighting its waterproof and durable construction.



Figure 5: The LOKITHOR J-Series EVA Protection Case resting securely on a car seat, demonstrating its compact size and portability for in-vehicle storage.



Figure 6: A person carrying the LOKITHOR J-Series EVA Protection Case by its sturdy handle, illustrating its ease of transport.



Figure 7: The LOKITHOR J-Series EVA Protection Case positioned within a vehicle's engine bay, showcasing its compact design and convenient placement during use or storage.

Videos

Your browser does not support the video tag.

Video 1: An overview of the LOKITHOR J-Series Bag EVA Protection Case, demonstrating its features and how it securely holds the jump starter and accessories.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4B61KHG

More documents and user manuals: **https://manuals.plus/**