Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ZOKOP YPO2-09C

ZOKOP 8000BTU Portable Air Conditioner

Model: YPO2-09C

1. Important Safety Information

Please read all instructions carefully before operating this appliance and retain for future reference. Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- This appliance is for indoor use only.
- Ensure the power supply matches the voltage specified on the rating label.
- Do not operate the unit with a damaged cord or plug.
- Do not block air inlets or outlets. Maintain at least 20cm clearance from walls and other objects.
- Do not insert fingers or other objects into the air outlet.
- Always unplug the unit before cleaning or servicing.
- Keep the unit away from heat sources and direct sunlight.
- Do not use the unit in wet environments such as bathrooms or laundries.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

2. Package Contents

Verify that all items listed below are included in your package:

- 1 x Portable Air Conditioner
- 1 x Remote Control
- 2 x AAA Battery
- 1 x Exhaust Hose
- 1 x Exhaust Hose Connector
- 2 x Window Seal-Plate
- 1 x Drain Pipe

- 4 x Fixing Screw
- 1 x Manual

3. Product Overview



Figure 3.1: Front view of the ZOKOP portable air conditioner, showing the air outlet and control panel at the top.



Figure 3.2: Rear view of the ZOKOP portable air conditioner, highlighting the exhaust hose connection port and air filters.



Figure 3.3: Close-up of the top-mounted control panel with digital display and touch buttons for Timer, Fan, Mode, Power, and temperature adjustment, along with indicator lights.

The ZOKOP portable air conditioner is designed for efficient cooling and dehumidification. It features a compact design with casters for easy mobility, a user-friendly control panel, and a remote control for convenient operation.

4. Setup and Installation

Follow these steps to set up your portable air conditioner:

1. **Unpacking:** Carefully remove the unit from its packaging. Keep all packaging materials for future storage or transport.
2. **Positioning:** Place the unit on a flat, stable surface. Ensure there is at least 20cm (8 inches) of space around the unit for proper airflow.
3. **Window Kit Assembly:**
    - Connect the exhaust hose to the exhaust hose connector.
    - Attach the other end of the exhaust hose to the window seal-plate.
    - Adjust the window seal-plate to fit your window opening (suitable for both horizontal and vertical sliding windows). Secure it in place.
    - Connect the exhaust hose assembly to the exhaust outlet on the back of the air conditioner.



Figure 4.1: Illustration of the portable air conditioner with exhaust hose and window kit installed in both horizontal and vertical sliding windows.

4. **Power Connection:** Plug the power cord into a grounded 115V/60Hz electrical outlet.
5. **Drain Pipe (Dehumidification Mode):** For continuous drainage during dehumidification, connect the drain pipe to the continuous drain port at the back of the unit and lead it to a suitable drain or container.

5. Operating Instructions

The unit can be operated using the control panel on top of the unit or the included remote control.



Figure 5.1: The portable air conditioner with its remote control, demonstrating ease of operation for all users.

Control Panel and Remote Control Functions:

- **POWER Button:** Press to turn the unit ON or OFF.
- **MODE Button:** Press to cycle through operating modes: Cool, Fan, Dry (Dehumidify).
- **Temperature Adjustment Buttons (▲ / ▼):**Use to increase or decrease the desired temperature. Temperature setting range: 62.5℉-86℉ (17℃-30℃).
- **FAN Speed Button:** Press to select fan speed: High or Low.
- **TIMER Button:** Press to set the auto-on or auto-off timer. Timing can be set from 0-24 hours.

Operating Modes:

- **Cool Mode:** Provides powerful cooling. Set your desired temperature and fan speed. The unit will cool the room to the set temperature.
- **Fan Mode:** Circulates air without cooling. Choose between High or Low fan speed.
- **Dry (Dehumidify) Mode:** Removes excess moisture from the air. The fan speed is fixed to low in this mode. For continuous drainage, ensure the drain pipe is connected.

Memory Function: The unit has a memory function. When restarted, it will automatically resume the previously selected mode and settings, reducing the need for re-configuration.

6. Maintenance

Regular maintenance ensures optimal performance and extends the lifespan of your air conditioner.

Cleaning the Air Filter:

The air filter should be cleaned regularly, approximately twice a month, or more frequently depending on usage and air quality.

1. Turn off the unit and unplug it from the power outlet.
2. Locate the air filter panels on the back of the unit.
3. Slide out the filter(s) gently.
4. Rinse the filter thoroughly under running water to remove dust and debris. For heavily soiled filters, a mild detergent can be used, followed by thorough rinsing.
5. Allow the filter to air dry completely before reinserting it into the unit. Do not expose to direct sunlight or excessive heat.
6. Once dry, slide the filter(s) back into their original position.

Cleaning the Unit Exterior:

- Wipe the exterior of the unit with a soft, damp cloth.
- Do not use harsh chemicals, abrasive cleaners, or solvents, as these may damage the surface.

Storage:

If the unit will not be used for an extended period:

- Drain any accumulated water from the unit.
- Clean the air filter.
- Store the unit in a dry, cool place, away from direct sunlight.

7. Troubleshooting

Before contacting customer support, please refer to the following table for common issues and their solutions:

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply. Power cord not plugged in. Circuit breaker tripped.	Check power outlet. Ensure power cord is securely plugged in. Reset circuit breaker.
Unit does not cool effectively.	Air filter is dirty. Room temperature is too high/low for set temperature. Windows/doors are open. Exhaust hose is blocked or disconnected. Unit size is too small for the room.	Clean the air filter. Adjust set temperature. Close all windows and doors. Check exhaust hose for blockages or proper connection. Ensure unit is appropriate for room size (up to 300 sq. ft.).
Unit is noisy.	Unit is not on a level surface. Air filter is dirty. Internal components vibrating.	Place unit on a flat, level surface. Clean the air filter. This may be normal operation noise (51-56 dB). If excessive, contact support.
Water leakage.	Drain plug is loose or missing. Drain pipe is clogged or improperly connected (in Dry mode). Water tank is full (if not using continuous drain).	Check and secure the drain plug. Clear any clogs in the drain pipe and ensure proper connection. Empty the water tank.

Problem	Possible Cause	Solution
Remote control not working.	Batteries are dead or incorrectly inserted. Obstruction between remote and unit.	Replace batteries (AAA). Ensure correct polarity. Remove any obstructions. Point remote directly at the unit's receiver.

8. Specifications

Technical specifications for the ZOKOP Portable Air Conditioner Model YPO2-09C:




Figure 8.1: Dimensions and key performance metrics of the ZOKOP portable air conditioner.

Feature	Specification
Brand	ZOKOP
Model	YPO2-09C
Cooling Capacity	8000 BTU/H (ASHARE) / 5500 BTU/H (SACC - DOE)
Power Supply	115V/60Hz
Rated Input	970W
Rated Current	8.0A
Refrigerant	R410A / 19Oz
Air Flow	380 m³/H
AC Coverage Area	Up to 300 sq. ft.
Noise Level	51-56 dB
Temperature Setting Range	62.5℉-86℉ (17℃-30℃)
Timer Range	0-24 Hours

Feature	Specification
Fan Speed Settings	High, Low
Filter Type	Washable
Exhaust Hose Length	150cm / 59inch (Φ15cm / 5.9inch)
Product Dimensions (L x W x H)	11.81" x 29.76" x 13.86" (30 x 75.6 x 35.2 cm)
Product Weight	26kg / 57.32lb

9. Warranty and Support

This ZOKOP portable air conditioner comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions, including coverage period and limitations.
For technical assistance, troubleshooting beyond this manual, or warranty claims, please contact the retailer or manufacturer's customer support. Keep your purchase receipt as proof of purchase.

© 2024 ZOKOP. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B4HRJN46

More documents and user manuals: **https://manuals.plus/**