Frigidaire EFIC120-SS-SC

Frigidaire EFIC120-SS-SC Ice Maker User Manual

Model: EFIC120-SS-SC

Introduction

Thank you for choosing the Frigidaire EFIC120-SS-SC Self Cleaning Stainless Steel Ice Maker. This manual provides important information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and keep it for future reference.
This portable ice maker is designed to produce up to 26 lbs (11.8 kg) of bullet-shaped ice cubes per day, offering a convenient solution for your ice needs without requiring permanent installation.

Important Safety Information

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using the appliance.
- Do not touch the evaporator or ice basket when the unit is operating.
- Do not immerse cord, plug, or any part of the unit in water or other liquids.
- Close supervision is necessary when any appliance is used by or near children.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use only attachments recommended or sold by the manufacturer.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Ensure the appliance is placed on a stable, level surface.
- Unplug from outlet when not in use and before cleaning.

Parts Identification



Figure 1: Frigidaire EFIC120-SS-SC Self Cleaning Stainless Steel Ice Maker. This image shows the compact, stainless steel design of the ice maker with its transparent lid, control panel on top, and ventilation on the side.

Familiarize yourself with the components of your ice maker:

- **Control Panel:** Located on the top, with buttons for operation and indicator lights.
- **Transparent Lid:** Allows you to view the ice-making process and ice level.
- **Ice Basket:** Removable basket for collecting and storing ice.
- **Water Reservoir:** Located beneath the ice basket, where water is added for ice production.
- **Ice Scoop:** (Assumed, common accessory) For convenient ice retrieval.

- **Drain Plug:** For draining water during cleaning or storage.

Setup and First Use

1. **Unpacking:** Carefully remove all packaging materials. Ensure all parts are present and undamaged.
2. **Placement:** Place the ice maker on a flat, stable surface away from direct sunlight and heat sources. Ensure there is adequate ventilation around the unit (at least 4 inches of space on all sides).
3. **Initial Cleaning:** Before first use, clean the interior of the unit. Refer to the "Maintenance and Cleaning" section for detailed instructions.
4. **Power Connection:** Plug the ice maker into a grounded electrical outlet.
5. **Add Water:** Open the lid and remove the ice basket. Fill the water reservoir with potable water up to the MAX fill line. Do not overfill.

Operating Instructions

Your Frigidaire ice maker is designed for simple operation.

1. **Power On:** Press the "ON/OFF" button on the control panel to turn on the unit.
2. **Select Ice Size:** Use the "SELECT" button to choose between two ice cube sizes (small or large bullet-shaped ice). The corresponding indicator light will illuminate.
3. **Ice Production:** The ice maker will begin the ice-making cycle. The first batch of ice may take slightly longer (approximately 6-10 minutes). Subsequent batches will be faster.
4. **Ice Full Indicator:** When the ice basket is full, the "ICE FULL" indicator light will illuminate, and the unit will pause ice production. Remove ice from the basket to resume operation.
5. **Add Water Indicator:** If the water level in the reservoir is too low, the "ADD WATER" indicator light will illuminate, and the unit will stop producing ice. Add more water to the reservoir to resume operation.
6. **Power Off:** Press the "ON/OFF" button again to turn off the unit.

Note: *For optimal performance, use filtered or distilled water to prevent mineral buildup and ensure clearer ice.*

Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and efficiency of your ice maker.

Automatic Self-Cleaning Program

1. Ensure the unit is plugged in and the water reservoir is filled with clean water.
2. Press and hold the "ON/OFF" button for more than 5 seconds. The unit will enter the self-clean program.
3. The self-cleaning cycle takes approximately 30 minutes.
4. Once the program is complete, drain out the water from the reservoir by removing the drain plug.
5. Clean the interior surfaces with a soft cloth and mild detergent, then rinse thoroughly.

General Cleaning

- Unplug the unit before cleaning.
- Remove the ice basket and clean it with warm, soapy water. Rinse and dry.
- Clean the interior of the water reservoir and ice chute with a soft cloth and a solution of water and mild detergent or

vinegar.

- Wipe the exterior of the unit with a damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all parts are completely dry before reassembling and storing or using the unit.

Troubleshooting

Problem	Possible Cause	Solution
Ice maker not working	Not plugged in; Power outage; Unit too hot.	Ensure unit is plugged in; Check power supply; Allow unit to cool down.
"ADD WATER" indicator on	Water reservoir is empty or low.	Add water to the reservoir up to the MAX fill line.
"ICE FULL" indicator on	Ice basket is full.	Remove ice from the basket.
Ice cubes are small or cloudy	Water temperature too high; Mineral buildup.	Use colder water; Perform self-cleaning cycle; Use filtered water.
Unit is noisy	Normal operation sounds; Unit not level.	Some noise is normal during operation; Ensure unit is on a level surface.

Specifications

Feature	Detail
Model Name	EFIC120-SS-SC
Brand	Frigidaire
Ice Production Capacity	Up to 26 lbs (11.8 kg) per 24 hours
Ice Shape	Bullet-shaped
Ice Size Settings	2 (Small, Large)
Voltage	120 Volts
Refrigerant	R410a
Parcel Dimensions	38.2 x 36.6 x 28.2 cm
Weight	8.4 kg
UPC	058465819422

Warranty and Support

For warranty information, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Frigidaire website. Keep your purchase receipt as proof of purchase for warranty claims. For further assistance, you may contact Frigidaire customer service through their official channels. Please have your model number (EFIC120-SS-SC) and UPC (058465819422) ready when contacting support.

© 2024 Frigidaire. All rights reserved.
This manual is subject to change without notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question