Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Philips Beauty BRL146/00

Philips Beauty Lady Electric Shaver Series 6000 User Manual

Model: BRL146/00

Introduction

The Philips Lady Shaver Series 6000 (Model BRL146/00) is designed for convenient and comfortable hair removal across various body areas. This electric shaver prioritizes skin comfort, featuring a floating foil and rounded trimmer tips that glide smoothly over your skin for an even and gentle shave. It supports both wet and dry use, offering flexibility for your grooming routine. This manual provides essential information on setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your device.



Image: Philips Lady Electric Shaver Series 6000, showcasing the shaver, its 7 accessories, and the product packaging.

Important Safety Information

Always use the shaver with caution to avoid potential skin irritation. Do not use the shaver in the shower or while charging to prevent electrical hazards. Always follow the cleaning and care instructions to maintain the shaver's hygiene and performance.

Package Contents

Your Philips Lady Electric Shaver Series 6000 package includes the following items:

- Philips Lady Electric Shaver Series 6000
- Trimmer head
- 2 Trimming combs
- Skin stretcher cap
- Soft glide cap
- Exfoliation glove

- Pouch
- USB-A charging cable (wall adapter not included)



Image: Detailed view of the shaver and its included accessories, highlighting each component.

Setup

Charging the Shaver

The shaver is equipped with a rechargeable battery, providing up to 40 minutes of cordless use. Before first use, or when the battery is low, charge the device fully.

1. Connect the provided USB-A charging cable to the shaver's charging port.
2. Plug the USB-A end of the cable into a compatible USB wall adapter (not included) or a powered USB port.
3. Allow the shaver to charge until the charging indicator light indicates a full charge.

Note: Do not use the shaver while it is charging.




Image: The included USB-A charging cable. A wall adapter is required and sold separately.

Operating Instructions

General Shaving Tips

- Ensure your skin is clean. For wet shaving, apply shaving foam or gel.
- Turn on the shaver by pressing the power button.
- Hold the shaver at a 90-degree angle to your skin.
- Gently glide the shaver against the direction of hair growth. The floating foil head adapts to your body's contours for a close and comfortable shave.
- The rounded trimmer tips help ensure a skin-friendly experience, minimizing irritation.
- This shaver is designed for both **Wet & Dry** use, featuring an anti-slip grip for secure handling in the shower or bath.



Image: A user demonstrating the gentle and comfortable application of the Philips Lady Electric Shaver on the skin.



Image: A close-up view of the shaver head, illustrating the rounded trimmer tips designed for a skin-friendly shave.

Using Accessories

Refer to the specific accessory instructions for optimal use:

- **Trimmer Head & Trimming Combs:** Attach the trimmer head for precise trimming. Use the trimming combs to achieve desired hair lengths.
- **Skin Stretcher Cap:** Helps to stretch the skin for a closer shave, especially in delicate areas.
- **Soft Glide Cap:** Designed for extra comfort and smooth gliding over sensitive skin.
- **Exfoliation Glove:** Use before shaving to prepare the skin and prevent ingrown hairs.

Maintenance and Cleaning

Regular cleaning ensures optimal performance and hygiene of your shaver.

1. After each use, turn off the shaver and detach the shaving head.
2. Rinse the shaving head and the main unit under running water. Ensure all hair residues are removed.

3. For a more thorough cleaning, use the small cleaning brush (if included) to remove stubborn hairs from the foil and trimmer blades.
4. Allow all parts to air dry completely before reassembling or storing the shaver.
5. Store the shaver in its pouch to protect it from dust and damage.

Troubleshooting

If you encounter issues with your Philips Lady Electric Shaver, refer to the following common solutions:

Problem	Possible Cause	Solution
Shaver does not turn on.	Battery is depleted.	Charge the shaver fully using the provided USB-A cable.
Poor shaving performance.	Shaver head is clogged with hair or damaged.	Clean the shaving head thoroughly. If damaged, consider replacing the head.
Skin irritation after shaving.	Incorrect shaving technique or sensitive skin.	Ensure you are gliding the shaver gently and at the correct angle. Use the exfoliation glove before shaving. If irritation persists, consult a dermatologist.

Specifications

Model Name	Philips Lady Electric Shaver Series 6000, Cordless with 7 Accessories
Item Model Number	BRL146/00
Brand	Philips Beauty
Power Source	Battery Powered
Battery Type	1 Lithium Ion battery (included)
Cordless Use Time	Up to 40 minutes
Special Feature	Designed to be gentle and comfortable on skin in different body areas
Recommended Uses	Body
Product Dimensions	2.36 x 4.72 x 0.1 inches
Item Weight	8.64 ounces
UPC	075020102331
Manufacturer	Norelco

Warranty and Support

For detailed warranty information and customer support, please refer to the official Philips Beauty website or the documentation included with your purchase. You can also download the full User Manual in PDF format for comprehensive details: Download Official User Manual (PDF)

© 2023 Philips Beauty. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B6456LZB

More documents and user manuals: **https://manuals.plus/**