**Manuals+**
Q & A | Deep Search | Upload



## ELENKER All-Terrain Rollator Walker

# ELENKER All-Terrain Rollator Walker Instruction Manual

Model: All-Terrain Rollator Walker

## Introduction

This manual provides essential information for the safe and effective use of your ELENKER All-Terrain Rollator Walker. Please read these instructions carefully before assembly and operation to ensure proper function and user safety.

## Safety Information

- Always ensure all parts are securely fastened before use.
- Engage brakes when sitting or standing to prevent movement.
- Do not exceed the maximum weight capacity of the rollator.
- Use caution on uneven or sloped surfaces.
- Regularly inspect wheels, brakes, and frame for wear or damage.

## Setup and Assembly

The ELENKER All-Terrain Rollator Walker is designed for straightforward assembly. No special tools are required.

1. **Unfold the Frame:** Carefully unfold the rollator frame until it locks into its open position.
2. **Attach Handles:** Insert the handle tubes into the main frame. Ensure the spring buttons snap securely into the desired height adjustment holes.
3. **Install Backrest:** Secure the backrest into its designated slots on the handle tubes.
4. **Attach Storage Bag:** Position the storage bag under the seat and secure it using the attached fasteners.
5. **Verify Stability:** Before first use, ensure all connections are firm and the rollator is stable.

*Figure 1: The ELENKER All-Terrain Rollator Walker in its fully assembled state, ready for use.*

## Operating Instructions

### 1. Walking and Maneuvering

The rollator features large, non-pneumatic wheels designed for various terrains, providing smooth movement over grass, gravel, and uneven pavement.

*Figure 2: Close-up view of the 12-inch non-pneumatic rubber wheels, highlighting their robust design for all-terrain use.*

*Figure 3: An individual using the rollator walker on a grassy outdoor path, demonstrating its all-terrain capability.*

## 2. Using the Foot Lift

For navigating curbs or small obstacles, utilize the integrated foot lift. Place your foot on the designated lever near the rear wheel and gently press down to slightly elevate the front wheels, preventing tipping.

*Figure 4: A user demonstrating the foot lift mechanism to easily raise the front wheels over a curb, enhancing safety and maneuverability.*

### 3. Braking System

The rollator is equipped with a dual braking system for safety. Squeeze the hand levers to slow down. To engage the parking brake, push the levers down until they lock, securing the rollator in place for sitting or standing.

Your browser does not support the video tag.

*Video 1: Demonstration of the rollator's features, including the braking system, all-terrain wheels, and compact folding design. This video illustrates how to effectively use the brakes for both slowing and parking the device.*

### 4. Comfortable Seating and Storage

The rollator includes a breathable mesh seat and a wide backrest, providing a comfortable resting spot. The under-seat storage bag offers convenient space for personal items, and a cane holder is integrated for easy access.

*Figure 5: An individual comfortably seated on the rollator, utilizing the wide backrest for support. The rear wheels are locked for stability during rest.*

*Figure 6: The rollator showcasing its hands-free features, including the under-seat basket for storage and a dedicated holder for a cane or umbrella.*

### 5. Compact Folding Design

For easy transport and storage, the rollator features a compact folding design. Simply lift the seat strap to fold the unit, allowing it to fit into most car trunks.




*Figure 7: An illustration detailing the rollator's dimensions and demonstrating its compact folding mechanism, showing how it fits into a car trunk.*

Your browser does not support the video tag.

*Video 2: This video highlights the ELENKER All-Terrain Rollator Walker's features, including its 12-inch non-pneumatic wheels, comfortable seat, and compact folding design for easy transport.*

## Maintenance

- **Cleaning:** Wipe down the frame and seat with a damp cloth and mild detergent. Avoid abrasive cleaners.
- **Brakes:** Periodically check brake cables for proper tension and function. Adjust if necessary according to manufacturer guidelines.
- **Wheels:** Ensure wheels spin freely and are free of debris. The non-pneumatic tires do not require inflation.
- **Fasteners:** Regularly check all screws and bolts to ensure they are tight.

## Troubleshooting

- **Rollator pulls to one side:** Check for uneven handle height adjustments or debris in wheels.
- **Brakes not engaging properly:** Inspect brake cables for slack or damage. Adjust cable tension as needed.
- **Difficulty folding:** Ensure the seat is fully lifted and no items are obstructing the folding mechanism.

## Specifications

| Feature | Detail |
|---|---|
| Product Dimensions | 25 x 25 x 35.5 inches |
| Item Weight | 20 Pounds |
| Brand | ELENKER |
| Color | Black |
| Material | Rubber (for wheels) |
| Age Range (Description) | Senior |

## Warranty and Support

The ELENKER All-Terrain Rollator Walker is 100% tested before leaving the factory to ensure quality. For any inquiries or assistance, please contact our customer service via email. We offer 24-hour friendly email customer service.

© 2023 ELENKER. All rights reserved.