Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Dpofirs Dpofirscrkwq6oxtb3126-13

Dpofirs Electronic Reader User Manual

Model: Dpofirscrkwq6oxtb3126-13

1. Introduction

The Dpofirs Electronic Reader is a versatile device designed for an optimal reading experience. Featuring a 7-inch TFT LCD color screen with 800x480 resolution, it offers clear and delicate graphic display. This multifunctional e-reader comes with a protective case, navigation buttons, and supports various file formats for both reading and multimedia playback. Its compact and lightweight design ensures easy portability and comfortable use.



Figure 1: Dpofirs Electronic Reader and Protective Case. The image shows the black e-reader from the front, displaying its menu interface, with its black protective case visible behind it.

2. What's in the Box

Please check the package contents upon unboxing to ensure all items are present:

- 1 x Dpofirs Electronic Reader
- 1 x Protective Case
- 1 x Earphones
- 1 x Data Cable (Micro USB)
- 1 x User Manual
- 1 x Screen Protector Film

3. Setup

3.1 Initial Charging

Before first use, it is recommended to fully charge your Dpofirs Electronic Reader. Connect the provided data cable to the micro USB port on the device and the other end to a compatible USB power adapter (not included) or a computer USB port. The charging indicator will illuminate.

3.2 Powering On/Off

To power on the device, press and hold the power button located at the bottom of the e-reader until the screen lights up. To power off, press and hold the power button again until a power-off prompt appears, then confirm.

3.3 Inserting a Memory Card (Optional)

The device supports memory card expansion up to 16GB. Locate the memory card slot on the side of the device. Gently insert a compatible memory card until it clicks into place. To remove, press the card inward until it springs out.

4. Operating Instructions

4.1 Navigation

The Dpofirs Electronic Reader features mechanical navigation buttons for easy control. Use the directional buttons to move through menus and select options. The 'Previous Page' and 'Next Page' buttons are specifically designed for comfortable reading navigation.




Figure 2: Simple Button Navigation. This image highlights the physical navigation buttons on the side of the e-reader, emphasizing ease of use.

4.2 Reading Books

The e-reader supports various e-book formats including EPUB, PDF, TXT, FB2, and PDB. To open a book, navigate to the 'Library' or 'File Explorer' section and select your desired file. While reading, you can:

- **Turn Pages:** Use the dedicated 'Previous Page' and 'Next Page' buttons.
- **Adjust Font Size:** Access settings to change the font size for comfortable viewing.
- **Bookmarks:** Add bookmarks to easily return to your reading progress.
- **Screen Rotation:** Rotate the screen orientation as needed.




Figure 3: Adjustable Font Size for Comfortable Reading. A user is shown comfortably reading on the e-reader, illustrating the ability to adjust font size for personalized viewing.

4.3 Multimedia Playback

Beyond reading, the device supports various multimedia formats:

- **Audio:** MP3, WMA, AAC, WAV, OGG. Connect earphones to the 3.5mm audio jack for private listening.
- **Images:** JPG, BMP, GIF, PNG. View photos in a slideshow with automatic flipping.
- **Video:** MPEG1, MPEG2, MPEG4XVID, H.264, H.263, RM/RMVB, MKV, MOV, VOB, FLV.

4.4 Additional Functions

The e-reader includes features such as a clock, slideshows, music slideshows, zoom in/out for images, and screen rotation.

5. Maintenance

5.1 Cleaning

Use a soft, dry, lint-free cloth to clean the screen and body of the device. Avoid using liquid cleaners or abrasive materials, as they may damage the screen or finish.

5.2 Storage

When not in use, store the e-reader in its protective case in a cool, dry place away from direct sunlight and extreme temperatures. Avoid placing heavy objects on top of the device.

5.3 Water Resistance

The device is designed with daily water resistance. However, it is not fully waterproof. Avoid submerging the device in water or exposing it to heavy rain or splashes. If it gets wet, wipe it dry immediately.



Figure 4: Daily Water Resistance Feature. The image shows the e-reader with water droplets on its surface, illustrating its resistance to daily splashes.

6. Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Device does not power on.	Low battery; Power button not held long enough.	Charge the device for at least 30 minutes. Press and hold the power button for 5-10 seconds.
Screen is unresponsive or frozen.	Software glitch.	Perform a soft reset by pressing and holding the power button until the device restarts.
Cannot open certain files.	Unsupported file format; Corrupted file.	Ensure the file format is supported (EPUB, PDF, TXT, FB2, PDB for books; MP3, WMA, AAC, WAV, OGG for audio; JPG, BMP, GIF, PNG for images; MPEG1, MPEG2, MPEG4XVID, H.264, H.263, RM/RMVB, MKV, MOV, VOB, FLV for video). Try another file or re-download the file.
Memory card not detected.	Card not inserted correctly; Incompatible card; Corrupted card.	Re-insert the memory card. Ensure it is a compatible type and size (up to 16GB). Try another memory card.

7. Specifications

Feature	Detail
Model Name	Dpofirs E Reader
Screen Type	7-inch TFT LCD Color Screen
Resolution	800 x 480
Operating System	uCOS
Processor Architecture	ARM 9 + DSP
Processor Speed	380 MHz
Internal Storage	16 GB (as per product color/variant)
Memory Card Support	Up to 16 GB (card not included)
Supported E-book Formats	EPUB, PDF, TXT, FB2, PDB (Adobe DRM supported)
Supported Audio Formats	MP3, WMA, AAC, WAV, OGG
Supported Image Formats	JPG, BMP, GIF, PNG
Supported Video Formats	MPEG1, MPEG2, MPEG4XVID, H.264, H.263, RM/RMVB, MKV, MOV, VOB, FLV
Interfaces	1 x Micro USB, 1 x 3.5mm Audio Jack, 1 x Memory Card Slot

Feature	Detail
Battery Type	Built-in 2100 mAh Battery
Special Features	Clock, Bookmarks, Slideshow, Music Slideshow, Zoom In/Out, Screen Rotation, Daily Water Resistance

8. Warranty and Support

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official Dpofirs brand store on Amazon:

Visit Dpofirs Brand Store

Please note that software updates are not guaranteed for this product. Information regarding spare parts availability is not provided.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0B8YKDMR2

More documents and user manuals: **https://manuals.plus/**