Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

STN X-JING08/9

STN Electric Lunch Box Accessories (X-JING08/9) User Manual

Model: X-JING08/9

1. Introduction

1.1 Product Overview

This manual provides instructions for the STN Electric Lunch Box Accessories, specifically the X-JING08/9 stainless steel container and associated power cables. These accessories are designed to enhance the functionality of your STN X-JING electric lunch box, allowing for safe food storage and heating.

1.2 Package Contents

- 1 x Stainless Steel Food Container (X-JING08/9)
- 1 x AC Power Cable (for home/office use)
- 1 x DC Car Power Cable (for vehicle use)



Image 1.1: The STN X-JING08/9 accessory set, featuring a stainless steel food container and two distinct power cables for AC and DC power sources. The container is designed for food storage and heating within the compatible electric lunch box.

2. Safety Instructions

Please read and understand all safety instructions before using these accessories with your electric lunch box. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the stainless steel container is properly seated within the electric lunch box before heating.
- Do not immerse the electric lunch box or its electrical components in water or other liquids. The stainless steel container is washable, but the main unit is not.
- Use only the provided power cables with the STN X-JING electric lunch box. Using unauthorized cables may

cause damage or fire.

- Keep the power cables away from hot surfaces.
- Ensure the power outlet matches the voltage specified for the electric lunch box.
- Do not touch hot surfaces of the container or lunch box immediately after heating. Use caution when handling heated food.
- Keep out of reach of children.
- Inspect the container and cables for any damage before each use. Do not use if damaged.

3. Setup

3.1 Installing the Stainless Steel Container

1. Open the lid of your STN X-JING electric lunch box.
2. Carefully place the stainless steel food container (X-JING08/9) into the designated compartment within the lunch box. Ensure it sits flat and securely.
3. Add your food into the stainless steel container. Do not overfill.
4. Close the lid of the electric lunch box, ensuring it is properly sealed.



Image 3.1: The stainless steel food container (X-JING08/9) designed to fit perfectly within the STN electric lunch box. Its smooth, metallic surface is ideal for food contact and heating.

3.2 Connecting Power Cables

The STN X-JING electric lunch box supports two types of power input:

- **AC Power Cable:** For use with standard wall outlets (100-240V).
- **DC Car Power Cable:** For use with 12V/24V car cigarette lighter sockets.

Steps:

1. Ensure the electric lunch box is turned off and unplugged from any power source.
2. Select the appropriate power cable for your environment (AC for home/office, DC for car).
3. Insert the connector end of the chosen power cable firmly into the power input port on the electric lunch box.
4. Plug the other end of the power cable into the corresponding power outlet (wall socket or car cigarette lighter).

Note: *Never connect both AC and DC cables simultaneously. Only use one power source at a time.*

4. Operating

Once the stainless steel container is filled with food and the appropriate power cable is connected, you can begin heating your meal.

1. Ensure the lunch box lid is securely closed.
2. Turn on the electric lunch box (refer to your main STN X-JING electric lunch box manual for specific power button location and operation).
3. Allow sufficient time for heating. Heating times may vary depending on the food type, quantity, and initial temperature.
4. Once heated, turn off the lunch box and unplug the power cable.
5. Carefully open the lid. Use caution as steam may escape and the container will be hot.
6. Remove the stainless steel container using heat-resistant gloves or appropriate utensils.
7. Serve and enjoy your meal.

5. Maintenance

5.1 Cleaning the Stainless Steel Container

The X-JING08/9 stainless steel container is designed for easy cleaning.

1. After each use, allow the container to cool completely.
2. Remove any food residue.
3. Wash the container with warm, soapy water using a soft sponge or cloth.
4. Rinse thoroughly with clean water.
5. Dry completely before storing or reusing to prevent water spots or odors.
6. The stainless steel container is also dishwasher safe.

5.2 Cleaning Power Cables

The power cables require minimal maintenance.

- Wipe the cables with a dry or slightly damp cloth if they become dirty.
- Do not immerse the cables or their connectors in water.
- Store cables neatly to prevent kinks or damage.

6. Troubleshooting

This section addresses common issues related to the accessories. For issues with the main electric lunch box unit, please refer to its dedicated manual.

Problem	Possible Cause	Solution
Container does not fit properly.	Incorrect orientation or obstruction.	Ensure the container is oriented correctly and no foreign objects are in the compartment.
Food not heating evenly (if related to container).	Overfilling the container.	Reduce the amount of food in the container. Ensure food is spread evenly.
Power cable does not connect securely.	Incorrect cable or damaged port/cable.	Ensure you are using the correct STN power cable. Check the cable and port for any visible damage. Do not force the connection.

7. Specifications

Model	X-JING08/9
Brand	STN
Material	Stainless Steel (X-JING08/9)
Capacity	1.5 Litres
Dimensions (Container)	Approx. 22 x 16 x 7 cm (based on package dimensions)
Weight (Item)	Approx. 410 g
Compatibility	STN X-JING Electric Lunch Box

8. Warranty and Support

As an accessory, the warranty for the STN X-JING08/9 stainless steel container and power cables is typically covered under the warranty of the main STN X-JING electric lunch box unit. Please refer to the warranty information provided with your original electric lunch box purchase.
For technical support, replacement parts, or further inquiries, please contact STN customer service through the retailer where you purchased the product or visit the official STN website (if available).
Note: *Information regarding spare parts availability for this accessory is currently unavailable.*

© 2023 STN. All rights reserved.

This manual is for informational purposes only. STN reserves the right to make changes to products without prior notice.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Can I purchase replacement power cords for the STN X-JING08/9 electric lunch box, and what type of power cord is compatible?

The STN X-JING08/9 electric lunch box uses two specific types of power cables: AC Power Cable: Designed for standard wall outlets with a voltage range of 100-240V (home/office use). DC Car Power Cable: Designed...

Read full answer

Open the live page

https://manuals.plus/asin/B0B9QX3TBH

More documents and user manuals: **https://manuals.plus/**