**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



### Dpofirs Dpofirsg9u4stayxh3124-12

# User Manual: Dpofirs 21.5 Inch Digital Photo Frame

Model: Dpofirsg9u4stayxh3124-12

## Introduction

This user manual provides detailed instructions for setting up, operating, and maintaining your Dpofirs 21.5 Inch Digital Photo Frame. Please read this manual thoroughly before using the product to ensure proper operation and to maximize its features.



Figure 1: The Dpofirs 21.5 Inch Digital Photo Frame, showcasing its ability to display vibrant images.

## Package Contents

Before proceeding with the setup, please verify that all items listed below are included in your package:

- 1 x IPS Digital Photo Frame (21.5 Inch)

- 1 x Stand
- 1 x Power Supply (EU Size)
- 1 x User Manual
- 1 x Remote Control (with built-in 160mAh battery)




Figure 2: Overview of all items included in the product package.

## Setup Guide

1. **Attach the Stand:** Carefully attach the provided stand to the back of the digital photo frame. Ensure it is securely fastened to provide stable support.



Figure 3: Rear view of the frame with the stand attached.

2. **Power Connection:** Connect the power supply adapter to the DC IN port on the back of the frame, then plug the adapter into a standard 100-240V electrical outlet.
3. **Insert Memory Card/USB Drive:** The frame supports memory cards (SD/MMC, not included) and USB 2.0 drives up to 128GB. Insert your memory card into the designated slot or your USB drive into the USB port on the side/back of the frame.




Figure 4: Input interfaces on the back of the frame.

4. **Initial Power On:** The frame will typically power on automatically once connected to power. If not, press the

power button on the back of the frame or on the remote control.

## Operating Instructions

### Display and Resolution

The Dpofirs Digital Photo Frame features a 21.5-inch 16:9 IPS display with a high resolution of 1920x1080. This IPS screen offers a 180-degree wide viewing angle and adjustable brightness, ensuring crisp, rich, and vibrant photos and videos from various perspectives.




Figure 5: The high-definition IPS display provides excellent viewing quality.

### Media Playback

The frame supports a wide range of media formats for both photos and videos:

- **Image Format:** Supports JPEG format.
- **Video Formats:** MKV, MOV, MPG, FLV, AVI, VOB, MP4.3GP, and other encoding formats, supporting up to

1080P HD video files.

- **Audio Formats:** MP3, WMA, OGG, APE, FLAC.

You can enjoy your media files with background sound images, or use the frame as a dedicated music or video player.




Figure 6: The frame supports various functions including photo, music, video, calendar, and clock modes.

## Control Methods

The digital photo frame can be controlled manually using the buttons on the back of the unit or conveniently via the included remote control.

- **Manual Control:** Buttons on the back allow for basic navigation and settings adjustments.
- **Remote Control:** The remote control provides full functionality, allowing you to easily navigate menus, search for specific images, adjust settings, and control playback from up to 26 feet away.




Figure 7: Operating the frame with the remote control.




Figure 8: Close-up of the remote control in use.

## Additional Features

Beyond displaying photos and videos, the Dpofirs Digital Photo Frame offers several useful features:

- **Clock and Calendar:** Display the current time and date.
- **Alarm Clock:** Set alarms for reminders.
- **Timer Switch:** Schedule automatic power on/off times.
- **Advertising Machine:** Can be used to promote products in a commercial setting.

## Maintenance

To ensure the longevity and optimal performance of your digital photo frame, please follow these maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to clean the screen and frame. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid abrasive cleaners or solvents.

- **Ventilation:** Ensure the ventilation holes on the back of the frame are not blocked to prevent overheating.
- **Storage:** When not in use for extended periods, store the frame in a cool, dry place away from direct sunlight and extreme temperatures.
- **Power Off:** Always power off the device properly before unplugging it.

## Troubleshooting

If you encounter any issues with your Dpofirs Digital Photo Frame, please refer to the following common troubleshooting steps:

| Problem | Possible Cause | Solution |
|---|---|---|
| No Power | Power adapter not connected properly; Power outlet not working. | Ensure the power adapter is securely plugged into the frame and a working electrical outlet. Try a different outlet. |
| No Image/Video Display | Memory card/USB drive not inserted correctly; Incompatible file format; Corrupted files. | Reinsert the memory card/USB drive. Ensure files are in supported formats (JPEG for images, listed video/audio formats). Try different files or a different memory device. |
| Remote Control Not Working | Obstruction between remote and frame; Remote battery low. | Ensure there is a clear line of sight to the frame's IR receiver. The remote has a built-in battery; if issues persist, contact customer support. |

If the problem persists after trying these steps, please contact Dpofirs customer support for further assistance.

## Specifications

| Feature | Detail |
|---|---|
| Brand | Dpofirs |
| Model Number | Dpofirsg9u4stayxh3124-12 |
| Item Type | IPS Digital Photo Frame |
| Material | Plastic |
| Colour | Black |
| Screen Type | 21.5 inch 16:9 IPS display |
| Resolution | 1920 x 1080 |
| Voltage | 100-240V |
| Remote Control Battery | Built-in 160mAh |
| Memory Support | Memory card (SD/MMC), USB 2.0 (up to 128GB) |
| Image Format | JPEG |
| Video Formats | MKV, MOV, MPG, FLV, AVI, VOB, MP4.3GP, and others (up to 1080P HD) |
| Audio Formats | MP3, WMA, OGG, APE, FLAC |

| Feature | Detail |
|---|---|
| Input Interface | Mini HD multimedia interface, USB 2.0 |
| Control Mode | Manual, Remote Control, Auto Play |
| Package Dimensions | 58.6 x 44.8 x 9.2 cm |
| Package Weight | 2.96 kg |

## Warranty and Support

Your Dpofirs Digital Photo Frame comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official Dpofirs website.
For technical support, troubleshooting assistance, or any inquiries regarding your product, please contact Dpofirs customer service. Contact information can typically be found on the product packaging or the brand's official website.

## Important Safety Information

Please observe the following safety precautions:

- Do not expose the device to water or excessive moisture.
- Avoid placing the device in direct sunlight or near heat sources.
- Do not attempt to disassemble or repair the device yourself. Refer all servicing to qualified personnel.
- Keep the device out of reach of children and pets.
- Dispose of packaging materials properly to avoid choking hazards.




Figure 9: Important warning regarding packaging disposal.

© 2024 Dpofirs. All rights reserved.

## Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0BGYGT5YR**

More documents and user manuals: **https://manuals.plus/**