Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Chicco 11314000000

CHICCO Baby Rodeo & Friends Instruction Manual

Model: 11314000000

Introduction

The CHICCO Baby Rodeo & Friends is a versatile 3-in-1 evolutive toy designed to provide engaging play for toddlers. It functions as a rocking horse and a ride-on toy, featuring an electronic activity center that stimulates auditory and creative development. This product is made from recycled plastic, and its packaging is recyclable, reflecting a commitment to environmental responsibility.



Image: The CHICCO Baby Rodeo & Friends toy, showing its white horse body, orange cowboy hat with electronic buttons, yellow saddle, and green rocking base with blue wheels.

Safety Information

Important: Carefully read the instructions and warnings in the package leaflet and on the packaging before use. Always supervise children during play. Ensure all components are securely assembled before allowing a child to use the toy.

Setup and Assembly

The CHICCO Baby Rodeo & Friends toy offers two primary modes: Rocking Horse and Ride-On. Assembly steps are straightforward, but adult supervision is required.

1. Rocking Horse Mode

For rocking horse mode, ensure the green rocking base is securely attached to the main body of the horse. The blue wheels should be positioned within the grooves of the rocking base to provide stability for rocking motion.

2. Ride-On Mode

To convert to ride-on mode, carefully remove the green rocking base from the horse's body. This allows the blue wheels to make direct contact with the floor, enabling the child to gallop freely. Ensure the base is stored safely away from the play area.



Image: Close-up of the CHICCO Baby Rodeo & Friends' base, illustrating how the blue wheels are integrated with the green rocking base for rocking mode, and how they would be exposed for ride-on mode.

Operating Instructions

The CHICCO Baby Rodeo & Friends features an electronic activity center located on the horse's hat.

Electronic Activity Center

To activate sounds and different music genres, press the animal-shaped buttons located on the orange cowboy hat. This feature is designed to develop movement skills and creativity through interactive play.



Image: Close-up of the CHICCO Baby Rodeo & Friends' orange cowboy hat, highlighting the colorful animal-shaped buttons that activate sounds and music.

Maintenance

To ensure the longevity and hygiene of your CHICCO Baby Rodeo & Friends toy, follow these maintenance guidelines:

- **Cleaning:** Wipe the toy surfaces with a damp cloth and mild soap. Do not immerse the electronic components in water.
- **Storage:** Store the toy in a dry place away from direct sunlight and extreme temperatures.

- **Battery Replacement:** If the electronic activity center's sounds become faint or stop working, replace the batteries. Refer to the battery compartment for specific battery type and installation instructions.

Troubleshooting

If you encounter any issues with your CHICCO Baby Rodeo & Friends, please refer to the following common solutions:

- **No Sound from Activity Center:**
  - Check if batteries are correctly installed.
  - Replace old batteries with new ones.
  - Ensure the power switch (if present) is in the "ON" position.
- **Toy Does Not Rock Smoothly:**
  - Ensure the rocking base is properly attached and not obstructed.
  - Check for any debris under the rocking base.
- **Toy Does Not Roll Smoothly in Ride-On Mode:**
  - Verify that the rocking base has been completely removed.
  - Check the wheels for any obstructions or damage.

Specifications

Feature	Detail
Product Dimensions	24.8 x 13.78 x 20.87 inches
Item Weight	11.84 pounds
Model Number	11314000000
ASIN	B0BH9GR8LW
Manufacturer Recommended Age	12 months and up
Release Date	November 5, 2023
Manufacturer	Artsana
Materials	Made from recycled plastic from industrial production surplus

Warranty and Support

For warranty information or further support regarding your CHICCO Baby Rodeo & Friends toy, please contact Chicco customer service or visit the official Chicco website. Details can typically be found on the product packaging or the manufacturer's official online resources.
Manufacturer: Artsana
Brand: Chicco

Visit the Chicco Store for more information:Chicco USA Store

© 2023 Chicco. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BH9GR8LW

More documents and user manuals: **https://manuals.plus/**