Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

TRESKO EKATM

TRESKO 20L 2500W Stainless Steel Hot Beverage Dispenser Instruction Manual

Model: EKATM (927)

1. Important Safety Instructions

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- **Electrical Safety:** Ensure the voltage specified on the appliance matches your local power supply (220-240V ~ 50Hz). Do not operate with a damaged cord or plug. Do not immerse the appliance, cord, or plug in water or other liquids.
- **Hot Surfaces:** The appliance surfaces become hot during operation. Use caution when handling and avoid direct contact with hot parts. Always use the heat-resistant handle.
- **Placement:** Place the dispenser on a stable, flat, heat-resistant surface, away from edges and out of reach of children. Ensure adequate ventilation around the unit.
- **Filling:** Do not overfill the dispenser beyond the MAX level indicator. Do not operate the appliance empty.
- **Cleaning:** Always unplug the appliance and allow it to cool completely before cleaning.
- **Supervision:** Close supervision is necessary when the appliance is used by or near children.
- **Intended Use:** This appliance is designed for heating and keeping beverages warm. Do not use it for purposes other than its intended use.
- **Repairs:** Do not attempt to repair the appliance yourself. Contact qualified service personnel for any repairs.

2. Product Overview

The TRESKO Hot Beverage Dispenser is designed for efficient heating and keeping warm of various drinks such as mulled wine, punch, tea, or coffee. It features a durable stainless steel construction, ensuring no alteration to the taste of your beverages.



Figure 1: Front view of the TRESKO Hot Beverage Dispenser, showing the temperature dial, indicator lights (Heating, Keep Warm), On/Off switch, and water level indicator.



Figure 2: Detail of the splash-proof On/Off switch and the Heating/Keep Warm indicator lights, designed for electrical safety.

Components:

- **Main Body:** Double-walled stainless steel construction for insulation and taste neutrality.
- **Lid:** Designed to protect against high temperatures and facilitate carrying.
- **Tap/Spigot:** Integrated for easy dispensing, with options for continuous or single pour.
- **Temperature Control Knob:** Adjustable from 30°C to 110°C.

- **On/Off Switch:** Splash-proof for enhanced safety.
- **Indicator Lights:** "Heating" (red) and "Keep Warm" (orange) to show current status.
- **Water Level Indicator:** Transparent gauge for monitoring liquid volume.
- **Heat-Resistant Handle:** For safe transport.

3. Setup

1. **Unpacking:** Carefully remove the appliance from its packaging. Retain packaging for future storage or transport.
2. **Initial Cleaning:** Before first use, clean the interior of the dispenser and the tap thoroughly with warm water and a mild detergent. Rinse well and dry. Refer to the "Maintenance" section for detailed cleaning instructions.
3. **Placement:** Place the dispenser on a firm, level, and heat-resistant surface. Ensure there is sufficient space around the unit for ventilation. Do not place it near flammable materials or heat sources.
4. **Power Connection:** Ensure the On/Off switch is in the "Off" position. Plug the power cord into a grounded electrical outlet.

4. Operating Instructions

4.1 Filling the Dispenser

1. Remove the lid.
2. Pour your desired beverage into the dispenser. Do not exceed the "MAX" mark on the water level indicator. The capacity is approximately 20 liters.
3. Securely replace the lid.



Figure 3: The transparent water level indicator allows for easy monitoring of the liquid volume inside the dispenser.

4.2 Heating and Keep Warm Function

1. Turn the temperature control knob to your desired temperature setting, ranging from 30°C to 110°C.
2. Flip the On/Off switch to the "On" position. The red "Heating" indicator light will illuminate, indicating that the appliance is actively heating the beverage.
3. Once the set temperature is reached, the red "Heating" light will turn off, and the orange "Keep Warm" light will illuminate. The appliance will automatically maintain the set temperature.
4. The appliance features overheat protection for safety.

4.3 Dispensing Beverages

The integrated tap allows for convenient dispensing:

- **Single Pour:** Push the tap lever down to dispense a single serving. Release the lever to stop the flow.
- **Continuous Flow:** Lift the tap lever upwards until it locks into place for continuous dispensing. Push it down again to stop the flow.



Figure 4: Interior view of the dispenser, showing the tap mechanism and the stainless steel construction, which ensures no taste alteration.

5. Maintenance

Regular cleaning and maintenance will ensure the longevity and optimal performance of your TRESKO Hot Beverage Dispenser.

5.1 Cleaning the Interior and Exterior

1. Always unplug the appliance and allow it to cool completely before cleaning.
2. Empty any remaining liquid from the dispenser.
3. Clean the interior with warm, soapy water and a soft sponge or brush. Rinse thoroughly with clean water.
4. Wipe the exterior with a damp cloth. Do not use abrasive cleaners or scouring pads, as these can damage the stainless steel finish.

5. Ensure all parts are completely dry before storing or reusing the appliance.

5.2 Cleaning the Tap

The tap can be disassembled for thorough cleaning:

1. Unscrew the tap from the dispenser.
2. Disassemble the tap components (if applicable, refer to diagrams if provided with the physical product).
3. Clean all tap parts with warm, soapy water and a small brush to remove any residue.
4. Rinse thoroughly and allow to dry completely before reassembling and reattaching to the dispenser.

5.3 Descaling

Over time, mineral deposits (limescale) may build up, especially in areas with hard water. Descale the appliance regularly to maintain efficiency:

1. Fill the dispenser with a solution of water and white vinegar (e.g., 1 part vinegar to 2 parts water) or a commercial descaling agent according to its instructions.
2. Heat the solution to approximately 60-80°C and let it stand for 30-60 minutes (do not boil).
3. Drain the solution through the tap.
4. Rinse the interior thoroughly several times with clean water to remove any descaling residue and odor.

6. Troubleshooting

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power switch off; no power at outlet.	Check power cord connection; ensure switch is "On"; test outlet with another appliance.
Beverage is not heating.	Temperature knob set too low; "Heating" light not on.	Increase temperature setting; ensure appliance is "On" and "Heating" light is active.
Beverage is not staying warm.	"Keep Warm" light not on; lid not properly sealed.	Ensure "Keep Warm" function is active; check lid for proper closure.
Tap is leaking.	Tap not properly tightened; seal damaged; residue in tap mechanism.	Ensure tap is securely tightened. If leaking persists, disassemble and clean the tap thoroughly, checking for any visible damage to seals. If damaged, contact support for replacement parts.
Unpleasant taste in beverage.	Appliance not cleaned properly; residue from previous use.	Thoroughly clean the interior and tap as per maintenance instructions. Ensure all cleaning agent residues are rinsed out.

7. Specifications

Feature	Detail
Brand	TRESKO
Model	EKATM (927)
Capacity	20 Liters
Power	2500 W
Voltage	220-240 V ~ 50 Hz
Temperature Range	30-110 °C
Material	Stainless Steel (Metal)
Product Dimensions (L x W x H)	29 x 29 x 53 cm
Power Cable Length	Approx. 1.25 m
Special Features	Automatic heating, keep-warm function, water level indicator, overheat protection, splash-proof switch, double-walled insulation.

8. Warranty and Support

For warranty information, please refer to the terms and conditions provided at the time of purchase or contact your retailer. If you encounter any issues or require technical assistance, please contact TRESKO customer support or the seller directly.
Manufacturer: DWD-Company

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BHDRZPNH

More documents and user manuals: **https://manuals.plus/**