Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

VEVOR VV-HP-F-2200

VEVOR 2400W Electric 2-in-1 Grill and Hot Pot Instruction Manual

Model: VV-HP-F-2200
Brand: VEVOR

1. Introduction

Thank you for choosing the VEVOR 2-in-1 Electric Grill and Hot Pot. This versatile appliance combines a hot pot and grill, allowing you to enjoy various cooking styles simultaneously. Designed for convenience and efficiency, it features dual temperature control and a non-stick surface for easy use and cleaning. Please read this manual thoroughly before operation to ensure safe and optimal performance.



Image 1.1: The VEVOR 2-in-1 Electric Grill and Hot Pot in use, showcasing its dual functionality for grilling and hot pot cooking with various ingredients.

2. Safety Information

To prevent injury or damage, always follow basic safety precautions when using electrical appliances:

- Read all instructions before use.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or heating unit in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to “off,” then remove plug from wall outlet.
- Do not use appliance for other than intended use.

3. Package Contents

The VEVOR 2-in-1 Electric Grill and Hot Pot package includes the following items:

- 1 x BBQ Grill Hot Pot Unit
- 1 x Tempered Glass Lid
- 2 x Spoons
- 1 x Food Clip
- 1 x Spatula
- 1 x Pair of Gloves
- 1 x Set of Cutlery
- 1 x Brush
- 1 x Cleaning Cloth
- 1 x Power Cord with Dual Temperature Controls



Image 3.1: A visual representation of the various accessories included with the VEVOR 2-in-1 Electric Grill and Hot Pot, such as spoons, food clip, spatula, gloves, cutlery, brush, and cleaning cloth.

4. Product Overview

The VEVOR 2-in-1 Electric Grill and Hot Pot is designed for versatile cooking, featuring a dual-purpose unit for both hot pot and grilling.

Key Features:

- **2-in-1 Design:** Combines a 2.5Qt (2.8L) hot pot with a divider for two different broths/tastes, and two wide grill areas.
- **Dual Temperature Control:** Two independent knobs allow precise temperature adjustment from 356℉ to 464℉ (5 speeds) for the grill and hot pot separately.
- **High-Efficient Heating:** Equipped with three heating tubes (800W for hot pot, two 800W for grill, totaling 2400W) for fast and even heating. Includes overheat protection.
- **Durable Construction:** Made of thickened cast aluminum with a non-stick coating for heat resistance and easy cleaning. Features a tempered glass lid and scald-proof bakelite handles.
- **Humanized Design:** Includes oil leakage ports to drain excess oil, a detachable hot pot for easy cleaning, and grooves on the grill plate for skewers.



Image 4.1: An illustration detailing the multipurpose design of the appliance, highlighting the double-flavor hot pot and barbecue grill tray with key dimensions.



Image 4.2: Close-up view of the high-quality materials and components, including bakelite handles, tempered glass lid, aluminum alloy body, and non-stick coating.

5. Setup

Before first use, ensure all packaging materials are removed. Assemble the lid handle if it came detached. Place the unit on a stable, heat-resistant surface.

Connecting the Power Cord:

1. Locate the power input ports on the side of the unit.
2. Insert the temperature control plugs firmly into their respective ports for the hot pot and grill sections.
3. Plug the power cord into a suitable electrical outlet (110V).

The hot pot is detachable for easier cleaning and can be removed from the main unit if only the grill function is desired,

or for separate cleaning.



Image 5.1: The detachable hot pot component, illustrating how it can be separated from the main grilling unit for cleaning or alternative use.

6. Operating Instructions

The VEVOR 2-in-1 Electric Grill and Hot Pot offers independent control for each cooking zone.

Using the Hot Pot:

1. Ensure the hot pot is securely placed in the center of the unit.
2. Fill the hot pot with your desired broth or liquid, ensuring it does not exceed the maximum fill line.
3. Turn the hot pot temperature control knob to your desired heat setting (356℉ to 464℉, 5 speeds).
4. Once the liquid is boiling, add your ingredients.

Using the Grill:

1. Lightly grease the non-stick grill surface if necessary.
2. Turn the grill temperature control knob to your desired heat setting (356℉ to 464℉, 5 speeds).
3. Place your meats, vegetables, or other ingredients directly onto the grill surface.
4. Use the included food clip or spatula to turn ingredients as needed.

Dual Temperature Control:

The independent temperature controls allow you to cook different items at different temperatures simultaneously. For example, you can simmer broth in the hot pot while grilling meats at a higher temperature.



Image 6.1: An illustration of the separate and rapid heating system, detailing the powerful heating tubes and the dual temperature control switches for independent adjustment of hot pot and grill temperatures.

7. Cleaning and Maintenance

Proper cleaning and maintenance will extend the life of your appliance.

General Cleaning:

1. Always unplug the appliance from the power outlet and allow it to cool completely before cleaning.
2. The hot pot is detachable for easy cleaning. Wash it with warm, soapy water and a soft sponge. Rinse thoroughly and dry.
3. The grill surface has a non-stick coating. Wipe it clean with a damp cloth or soft sponge. For stubborn residue, use a mild detergent. Avoid abrasive cleaners or metal scouring pads.
4. The oil leakage ports on the grill plate allow excess oil to drain into a removable tray. Empty and clean this tray after each use.

5. Do not immerse the main heating unit or power cords in water or any other liquid. Wipe the exterior with a damp cloth.

Storage:

Ensure the appliance is completely clean and dry before storing. Store in a cool, dry place away from direct sunlight.



Image 7.1: An illustration highlighting the humanized design features, including the detachable hot pot, oil leakage outlet, and skewer-placing grooves, all contributing to effortless cleaning and convenient operation.

8. Troubleshooting

If you encounter any issues with your VEVOR 2-in-1 Electric Grill and Hot Pot, please refer to the following common troubleshooting steps:

- **Appliance not turning on:** Ensure the power cord is securely plugged into both the appliance and a working electrical outlet. Check if the temperature control knobs are turned to an 'ON' setting.
- **Food not heating evenly:** Ensure the appliance is placed on a flat, stable surface. Verify that the temperature

settings are appropriate for the food being cooked.

- **Excessive smoke:** Ensure the oil leakage ports are clear and the oil collection tray is empty. Reduce the amount of oil used on the grill surface.
- **Non-stick coating damage:** Avoid using metal utensils or abrasive cleaning materials. Use only wooden, silicone, or heat-resistant plastic utensils.

If the problem persists after following these steps, please contact VEVOR customer support for assistance.

9. Specifications

Specification	Detail
Model	VV-HP-F-2200
Body Material	Cast Aluminum
Finish	Nonstick Coating
Power	2400W (800W Hot Pot + 1600W BBQ Grill)
Adjustable Temp Range	356-464℉ (5 Speeds)
Hot Pot Capacity	2.5Qt / 2.8L
Product Dimensions	28.9 x 10.4 x 7.5 inches (73.5 x 26.5 x 19 cm)
Product Weight	7.5 lbs / 3.4 kg
Voltage	110 Volts



Image 9.1: A graphic detailing the product specifications, including weight, dimensions, and suitable applications for family parties, picnics, and friend gatherings.

10. Warranty and Support

This VEVOR product comes with a limited warranty. For detailed warranty information or technical support, please refer to the product packaging or visit the official VEVOR website. You can also visit the VEVOR Store on Amazon for more information and customer service.

© 2026 VEVOR. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BL3HXK3K

More documents and user manuals: **https://manuals.plus/**