Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

PKPOWER XSD-05021109178USD

PKPOWER AC Adapter for Sungale CD705 Digital Photo Frame User Manual

Model: XSD-05021109178USD

1. Introduction

This manual provides essential information for the proper installation, operation, and maintenance of your PKPOWER AC Adapter. This adapter is specifically designed for use with the Sungale CD705 7-inch Digital Photo Picture Frame. Please read this manual thoroughly before using the product to ensure safe and efficient operation.

2. Safety Information

WARNING: California Proposition 65
This product may contain chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information, visit www.P65Warnings.ca.gov.

- Do not expose the adapter to rain or moisture.
- Do not disassemble the adapter. Refer all servicing to qualified personnel.
- Ensure the adapter is used within its specified input voltage range (100-240V).
- Avoid placing the adapter in areas with poor ventilation or near heat sources.
- Keep out of reach of children.

3. Product Overview

The PKPOWER AC Adapter is a reliable power supply unit designed to provide stable power to your compatible digital photo frame. It features multiple protection mechanisms to ensure the safety of your device.

Key Features:

- **Input:** 100-240V 50-60Hz, suitable for worldwide use.
- **Certifications:** CE / FCC / RoHS certified, meeting international safety and quality standards.
- **Protection:** Equipped with OVP (Over Voltage Output Protection), OCP (Over Current Output Protection), and SCP (Short Circuit Output Protection) to safeguard your device.

- **Compatibility:** Specifically designed for Sungale CD705 7-inch Digital Photo Picture Frame.

What's Included:

- 1 x PKPOWER AC Adapter (Model: XSD-05021109178USD)



Figure 1: PKPOWER AC Adapter. This image shows the black AC adapter with its two-prong plug and the attached coiled power cable, ready for connection.

4. Setup

1. **Inspect the Adapter:** Before use, visually inspect the adapter and cable for any signs of damage. Do not use if damaged.
2. **Connect to Device:** Locate the power input port on your Sungale CD705 Digital Photo Picture Frame. Carefully insert the adapter's DC output connector into the device's power port. Ensure a snug fit.
3. **Connect to Power Outlet:** Plug the AC adapter's two-prong plug into a standard electrical wall outlet (100-240V, 50/60Hz).
4. **Verify Power:** Once connected, your digital photo frame should receive power. Check for any power indicator lights on your device to confirm it is powered on.

5. Operation

The PKPOWER AC Adapter operates automatically once connected. It converts the AC power from your wall outlet into the DC power required by your Sungale CD705 Digital Photo Picture Frame. There are no user-adjustable settings on the adapter itself.

- Ensure the adapter remains plugged in for continuous power to your device.
- Disconnect the adapter from the wall outlet when not in use for extended periods.

6. Maintenance

- **Cleaning:** Disconnect the adapter from the power outlet and the device before cleaning. Use a soft, dry cloth to wipe the adapter. Do not use liquid cleaners or sprays.
- **Storage:** When not in use, store the adapter in a cool, dry place, away from direct sunlight and extreme temperatures. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Always grasp the plug when disconnecting from the wall outlet; do not pull on the cable.

7. Troubleshooting

No Power to Device:

- **Check Connections:** Ensure the adapter is securely plugged into both the wall outlet and the digital photo frame.
- **Test Outlet:** Plug another working appliance into the same wall outlet to confirm the outlet is functional.
- **Inspect Adapter:** Look for any visible damage to the adapter or cable. If damaged, discontinue use.
- **Verify Compatibility:** Confirm that your device is indeed the Sungale CD705 7-inch Digital Photo Picture Frame, as this adapter is specifically designed for it.

If the issue persists after performing these checks, please contact customer support.

8. Specifications

Brand	PKPOWER
Model Number	XSD-05021109178USD
Input Voltage	100-240V AC, 50/60Hz
Product Dimensions	4 x 2 x 0.5 inches
Item Weight	3 ounces
Color	Black
Manufacturer	PKPOWER



Figure 2: Rear view of the PKPOWER AC Adapter. This image highlights the adapter's label, which displays model information, input specifications, and compliance certifications.

9. Support

For any questions, concerns, or technical assistance regarding your PKPOWER AC Adapter, please contact our customer service team. Our friendly and reliable customer service will respond to you within 24 hours.
You can also visit the official PKPOWER store for more information and products:PKPOWER Store on Amazon

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0BLV16ZWB

More documents and user manuals: **https://manuals.plus/**